

F u j i I n v e r t e r F V R - B 7 S

200V Series 0.2 ~ 0.75kW

I n s t r u c t i o n M a n u a l


C o n t e n t s

-
1. Introduction..... p.1
 2. Inspection Upon Delivery..... p.2
 3. Construction & Handling..... p.2
 - (1) Removing Ventilation Cover
 - (2) Option
 - (3) Instruction Shorting Switch(SW1)
 - (4) Switching of Inverter Abnormal Signal Output
 4. Operating Precautions..... p.3
 5. Installation Instructions..... p.4
 - (1) Installation Conditions
 - (2) Mounting Direction & Space
 - (3) Mounting Screws & Holes
 - (4) Cable Openings
 6. Wiring p.5
 - (1) Connecting Main Circuits
 - (2) Connecting Control Circuits
 - (3) Connecting External Braking Resistor Unit (option)
 - (4) Basic Wiring Diagram
 7. Operationp. 8
 - (1) Pre-Operation Inspection
 - (2) Test Run Check Points
 - (3) Selecting Operation Method
 - (4) Setting Data Codes
 - (5) Control Circuit Connection & Operation
 - (6) Actual Operation
 8. Function Explanationp.17
 - (1) Function Code Tables
 - (2) Function Explanation
 - (3) Trip Record verification method
 - (4) Function Setting For Frequency Setting In Link Operation
 - (5) Function Setting For Monitoring Signal In Link Operation
 - (6) Function Setting For Link Operation
 9. Maintenance & Inspection.....p. 5 6
 - (1) Inspection Items
 - (2) Periodic Replacement Part
 - (3) Measurement Points & MetersTroubleshooting.....p. 5 8
 - (1) Protective Function
 - (2) Troubleshooting
 10. Appendixp. 6 1
 - (1) Standard Specifications
 - (2) External Dimensions
 - (3) Application Of Wiring And
 11. Equipment
 - (4) Terminal Function
 - (5) Control Block Diagram

Fuji Electric Co., Ltd.

Part Name

This Inverter is without Keypad Panel, it is option. Please order Keypad Panel "TPJ-GS" or "TPE-GS".



1. Introduction

Thank you for purchasing the FUJI "FVR-B7S" inverter. This inverter uses 32 bit DSP for multi-function and high performance in every field.

This instruction manual is included with the inverter and equipment, and is provided for the use of the end user. Please be sure it accompanies the inverter.


2. Inspection Items Upon Delivery

Please inspect the following items upon receipt of your inverter.

- ① Check the name plate to insure that the specifications correspond to those ordered.
- ② Inspect the unit for damage which may have occurred during shipping.

If you have any problems or questions regarding the inverter, please contact the distributor where the unit was purchased.

Name Plate




- ① Applicable Motor :
 - 0 0 2 → 0.2 kW
 - 0 0 4 → 0.4 kW
 - 0 0 8 → 0.75 kW
- ② Power Series : 2 → 200 V series
- ③ Phase : 3 φ → 3 phases
- ④ Voltage range
 - 200 ~ 230 V → AC 200 V series
- ⑤ Frequency : 50 / 60 Hz
- ⑥ Rated output current
 - AC 200 V series :
 - 1.5 A → 0 0 2 (0.2 kW)
 - 3 A → 0 0 4 (0.4 kW)
 - 5 A → 0 0 8 (0.75 kW)
- ⑦ Output frequency range
 - 0.2 to 400 Hz
- ⑧ Serial No.

3. Construction & Handling

(1) Removing Ventilation Cover

Ventilation Covers are upper and lower part of Unit Cover, remove the covers using the following procedure.


- ① Insert minus driver to the edge of the cover, lifting part of the cover, remove the cover.




(2) Installation & Removing Option Cover

Remove the covers using the following procedure.
Reverse the procedure to install the cover.

- ① Insert your fingers between Unit Cover and Option Cover, pulling up the cover, remove the cover.




- (3) Instruction Shorting Switch (SW1) for THR, FWD, REV
 After remove the cover, with SW1-1, SW1-2, SW1-3 on the board, short-circuit between each signal and CM.
 (Factory setting is THR-ON, FWD-OFF, REV-OFF.)



(4) Switching of Inverter Abnormal Signal Output

As factory setting is contact A output, in case of using contact B, switch the connector of 30A & 30B using the following procedure.

- ① While pressing following figure part of Unit Cover, slide Unit Cover in the direction of Terminal Block, remove the cover.
- ② Change the connector(30A→30B), it's lower part of Inverter. Reverse the procedure to install the cover.



4. Operating Precautions

Misconnections in the wiring, etc. will result in damage to, and failure of the unit. Please carefully note the items listed below, and use the unit as indicated.

- ① Do not impress power supply voltage that exceeds the standard specification voltage permissible fluctuation. If excessive voltage is applied to the inverter, damage to the internal elements will result.
- ② Do not connect power source to the output terminals (U, V, W). Connect power source only to the power terminals (R, S, T).
- ③ Do not connect power source to the breaking resistor connection terminals (P, DB). Never short-circuit between P-N or P-DB terminals, and do not connect any resistance with a resistance value (Ω) less than standard application breaking resistor.
- ④ Do not connect AC power source voltage to the control circuit terminals (except 30A, B, C).
- ⑤ For RUN and STOP, use the FWD-CM (forward) and REV-CM (reverse) terminals. Avoid using a contactor (ON/OFF) installed on the line side of the inverter for RUN and STOP.
- ⑥ Do not use a magnet switch on the output side of the inverter for ON/OFF operation.
- ⑦ Use only power capacity within the inverter capacity range of 1.5 times to 500kVA. If a power capacity greater than 500KVA is to be used, install a coordination reactor (ACR...option) on the line side of the inverter.
- ⑧ Do not connect a phase advance condenser to the output side of the inverter.
- ⑨ Do not operate without the ground wire connected.
- ⑩ If the inverter protective function is activated, consult Section 11 "Troubleshooting", and after correcting the problem, resume operation. Do not reset the alarm automatically by external sequence, etc.
- ⑪ Do not perform a megger test between the inverter terminals or on the control circuit terminals.


5. Installation Instructions

(1) Installation Conditions

Install the inverter in a location which meets the following requirements.

- ① The ambient temperature should be between -10°C and $+50^{\circ}\text{C}$. (Remove the ventilation cover when the temperature exceeds $+40^{\circ}\text{C}$)
- ② The humidity should be between 20 and 90% RH. Avoid any location subject to dew condensation, freezing or where the inverter would come in contact with water.
- ③ Do not install in any location subject to any of the following conditions: direct sunlight, dust, corrosive gas, inflammable gas or oil mist.
- ④ The inverter should be installed at an elevation below 1,000m, and vibration should be less than 0.6G.

(2) Installation Direction & Mounting Space



① Installation Method

Install the inverter perpendicular to the ground, and with the lettering "FVR-B7S" right side up. If the inverter is installed upside down, or horizontally, heat build-up will occur.

② Installation

To allow the escape of heat generated by the inverter, install at a sufficient distance from other equipment, walls or wiring ducts as shown in the figure on the left.

③ Installation Wall

During operation the temperature of the cooling fins of the inverter rises to approx. 90°C . For this reason, the mounting wall must be of heat resistant material.

④ Multiple Installations

When installing 2 or more inverters in close proximity, allow sufficient space as described in ② above, and install them in a horizontal row. If they must be installed in a vertical row, at least 50cm internal must be provided between each one, or a ventilation system should be provided to prevent the ambient temperature from rising.

(3) Mounting Screws & Holes

- ① Mounting screws or bolts should be M 4
- ② For the location of mounting holes, see "External Dimensions" in Section 11.

Ambient Temperature Cautions


Because the ambient temperature greatly affects inverter life and reliability, do not install in any location which exceeds the allowable temperature.

Leave the ventilation cover attached for temperatures of 40°C or lower, and remove the cover for temperatures between 40 and 50°C .

6. Wiring

(1) Main Circuit Wiring

- ① Power supply connection (R, S, T)
Connections can be made regardless of phase sequence.
- ② Motor wiring (U, V, W)
When connected normally, the motor will rotate counterclockwise when viewed from the load side. If the motor rotates in reverse, interchange any 2 of the U, V or W terminal connections.
- ③ Ground terminal connection (E, (G))
For safety reasons, do not operate without the unit being grounded. The ground wire must be as thick and short as possible as shown in the Applicable Wiring Equipment List (see Section 11 Appendix).



Caution Note: Be sure that the power supply is never connected to the U, V, W terminals or the N, P, P, DB terminals.

(2) Control Circuit Wiring

- ① Factory Wiring at the time of shipment
Both RUN/STOP and the frequency setting is performed through the control circuit terminals.
(Please order the options, keypad panel and extension cable.)
*Function setting at the factory



- ② Handling of external thermal input terminal
THR-CM is short-circuited with SW1 inside option cover. In case of using external thermal, remove option cover, switch SW1-1 off.




- 1. When both RUN/STOP and the frequency setting is performed through the control circuit terminals, the function setting should be **1501**, **1601** or **1602**.
- 2. If RUN/STOP is performed through the keypad panel, and the only frequency setting is performed through the control circuit terminals, set the function at **1500**, **1601** or **1602**.
- 3. If RUN/STOP is performed through control circuit terminals, and the frequency setting is performed through the operation panel, set the function at **1501**, **1600**.

(3) Wiring the external braking resistor unit (optional)

When frequent braking or high torque braking is required, connect the optional braking resistor as shown in the diagram on the right.


※1 Switch the factory set SW1-1 off. If it's not switched off, during operation the OH2 alarm will not function.



[Caution Notes]

1. If the P-DB terminals, or the P-N terminals are inadvertently short-circuited, damage to the inverter will result.

(4) Basic Connection Diagram



[Caution Notes]

- ① The control circuit terminal wiring should be kept as far as possible from the main circuit wiring to prevent operational error due to noise interference. Never install them in the same duct or conduit. (A separation distance of 10cm or more is recommended.)
If the control circuit wiring must cross the main circuit wiring, make sure it crosses at a right angle.
- ② Use shielded or twisted wire for the control circuit wiring, which should be as short as possible (20m or less).
(Connect outer covering of the shielded wires to the inverter ground terminal and leave the other end open.)
- ③ Install a spark killer in parallel with any magnet switches or solenoid type coils, etc. which may be close to the inverter.

7. Operation

(1) Pre-Operation Inspection

After mounting and wiring is completed, check the following items before supplying power to the inverter.

- ① Check wiring for errors. (especially main circuit wiring)
- ② Make sure there are no wiring chips, screws, etc. remaining in the inverter.
- ③ Make sure all screw and terminal connections are tight.
- ④ Make sure no compressed wire ends are touching other terminals.

[Caution Notes]

Megger Test

Do not conduct megger tests between the inverter terminals or control circuit terminals. For megger testing method, see Section 10 Maintenance & Inspection.

(2) Test Run Check Points

Conduct the test run at a low frequency of around 5Hz. Conduct the test run in a safe manner, and check the following points.

- ① Smooth rotation
- ② Correct rotation direction
- ③ Abnormal vibration or noise in the motor
- ④ Smooth speed increase and speed reduction

(3) Selecting Operation Method

For the FVR-G7S series, the following methods select the RUN/STOP signal transmission method and the frequency setting signal transmission method.


	RUN/STOP	Operation Method Code Setting	Frequency Setting	Operation Method Code Setting
1	Operation Panel Method RUN STOP keys	1500	<input type="checkbox"/> <input type="checkbox"/> keys	1600
2			VR or analog signal (DC 0 to +10V)	1601
3			VR or analog signal (DC 0 to +10V)	1602
4	External Signal Method (FWD, REV)	1501	<input type="checkbox"/> <input type="checkbox"/> keys	1600
5			VR or analog signal (DC 0 to +10V)	1601
6			VR or analog signal (DC 0 to +10V)	1602
Multistage frequency operation (8 stages possible) <ul style="list-style-type: none"> • For RUN/STOP and manual speed frequency setting, the function codes are 15, 16 for setting as above. • For the 1st to the 7th stage frequencies, the function codes are 29 31 33 35 37 39 41 and then select the external terminal (X1, X2, X3). 				

(4) Data Setting Method

In order that the inverter (including the motor) may operate under optimum conditions, in addition to the codes mentioned earlier, **15**, **16**, other setting changes are required. The following is a general explanation of the code setting method.

The details for code setting are given in Section 9. In addition to **15** and **16**, also be sure to fully understand the other basic codes **08**, **09**, **11**, **12**, **13** etc.

① Data change setting in STOP mode



② Data change setting in RUN mode

Function code **00** to **10**, **73** to **75** and **80** to **82** data setting is possible in RUN mode
 Verification of all function codes and data is also possible.

After end of data setting, press **PRG** key to return to frequency display.


(5) Control Circuit Connection & Operation

① Factory connections

11	12	13	FM	OL	RUN	RST	RT1	X2	HLD	FWD	BX	SHT
CM	CM1	CM2	P12	LV	FAR	NC	RT2	X3	X1	REV	THR	


* **1500**, **1600** Basic connection required for

② Common terminal connection example irrespective of operation method




- FM Used for external analog meter when frequency indication is needed.
- THR..... Connected to CM with SW1-1 at the factory. Connects to "b" contact when inverter STOP is desired through external alarm.
- RST..... Connects to RESET key for alarm STOP reset
- BX Connects to "a" contact signal when inverter free-run is desired during normal operation.

③ Operation Through Operation Panel (1500)




- a. Common terminal connections are as explained in (5)-②.
 - b. Rotation direction: short circuit between FWD-CM for forward rotation, short circuit between REV-CM for reverse rotation.
 - c. For frequency setting, select from the following 3 types of function code 15.
- 1500 : keys for digital setting
- 1501 : Connection of 1kΩ(1/2W) rheostat to 13, 12, 11 terminals; or input of DC 0 to +10V DC voltage signals to terminals 12, 11(12 is +.)

d. RUN Operation Example (1500)




* When FWD-CM, REV-CM are both ON or OFF, deceleration STOP will result.

④ External Signal Operation (:SIO:)



- Common terminal connections are as explained in (5)-②.
- Rotation direction: short circuit between FWD-CM for forward rotation, short circuit between REV-CM for reverse rotation.
- For frequency setting, the same 3 types can be selected as in (5)-③.
- RUN Operation Example




* When FWD-CM, REV-CM are both ON or OFF, deceleration STOP will result.


(6) Actual Operation

① **Multi-step frequency operation (X1, X2, X3 terminals)**

Multi-step frequency operation up to the 8th step is possible.




- a. Setting is **[15]** for operation method, and **[16]** for manual frequency setting method.
- b. The settings are: **[29]** for multi-step frequency 1, **[31]** for multi-step frequency 2, **[33]** for multi-step frequency 3, **[35]** for multi-step frequency 4, **[37]** for multi-step frequency 5, **[39]** for multi-step frequency 6, and **[41]** for multi-step frequency 7.
- c. RUN Operation Example




② Step Acceleration. Deceleration Operation (RT1, RT2 terminals)

4 different types of acceleration and deceleration times can be externally switched.




- Setting is **15** for operation method, and **16** for manual frequency setting method.
- The settings are: **08** for acceleration time 1, **23** for acceleration time 2, **24** for acceleration time 3, **25** for acceleration time 4, **09** for deceleration time 1, **26** for deceleration time 2, **27** for deceleration time 3, **28** for deceleration time 4.
- RUN Operation Example



③ Pattern Operation

Pattern operation can be accomplished by aligning the step frequency setting and the timer setting.




- a. With function **1901** pattern operation can be selected. (With **1900** data **30**, **32**, **34**, **35**, **38**, **40** and **42** cannot be accessed.)
- b. **29** sets the frequency setting for Multistep Frequency 1 and sets the rotation direction, and acceleration/deceleration time. **30** sets the time for the Multistep Frequency 1 timer. **31** sets the frequency setting for Multistep Frequency 2 and sets the rotation direction, and acceleration/deceleration time. **32** sets the timer for the Multistep Frequency 2 timer. **33** sets the frequency setting for Multistep Frequency 3 and sets the rotation direction, and acceleration/deceleration time. **34** sets the time for the Multistep Frequency 3 timer. **35** sets the frequency setting for Multistep Frequency 4 and sets the rotation direction, and acceleration/deceleration time. **36** sets the time for the Multistep Frequency 4 timer. **37** sets the frequency setting for Multistep Frequency 5 and sets the rotation direction, and acceleration/deceleration time. **38** sets the time for the Multistep Frequency 5 timer. **39** sets the frequency setting for Multistep Frequency 6 and sets the rotation direction, and acceleration/deceleration time. **40** sets the time for the Multistep Frequency 6 timer. **41** sets the frequency setting for Multistep Frequency 7 and sets the rotation direction, and acceleration/deceleration time. **42** sets the time for the Multistep Frequency 7 timer.

(NOTE) When in timer display mode, use the **SET** key for changing rotation direction or acceleration/deceleration time.

- c. When in operation panel operation mode (**1500**)
 - RUN** key : starts pattern operation
 - RESET** key : stops pattern operation (can be used after **STOP** key)
 - STOP** key : temporarily stops pattern operation
- d. When in control terminal operation mode (**1501**)
 - FWD-CM ON : starts pattern operation
 - FWD-CM OFF : force stops pattern operation
 - REV-CM ON : temporarily stops pattern operation

e. Operation Example



* In operation, the multistep frequency order is always in numerical order, 1 thru 7.

8. Function Explanation

(1) Function Code Tables

GRAPHIC DISPLAY	Function Code	Function	Display-Setting-Range	Minimum Unit	Factory Setting	Remarks
① Initial Setting						
00 ■ DGLT MNTR GRHC MNTR MTR SOUND FM CALIBR	00	LED digital monitor selection	00: output frequency [Hz] 01: output current [A] 02: output voltage [V] 03: synchronous rpm [rpm] 04: line speed [m/min]	—	00	Can be set by SHIFT key during RUN/STOP 00: If the SHIFT key is press when the maximum frequency is 60Hz or less, [Hz] will flash and the output frequency = can be displayed down to the 3rd decimal place
	01	Graphics monitor selection	00: Hz AMP monitor 01: terminal signal ① 02: terminal signal ②	—	00	Output frequency: output current (1 to 10 levels) ON/OFF (■) : lights / out ON/OFF (■) : lights / out
	02	Motor noise reduction	00 to 05 (code)	—	03	6 levels OK
	03	FM terminal output level calibration	00 to 99 (code)	—	85	100 levels (approx. 6.5V - 10.3V)
04 ■ AUTO TRQ TRQ BOOST TRQ FINE AUTO ACC	04	Automatic torque boost control	00 : nonoperate 01 : operate	—	00	
	05	Torque boost	00 to 31 (code)	—	13	32 levels (00/01 is reduction torque curve)
	06	Fine adjustment of torque boost	00 to 09 (code)	—	00	10 division fine adjustment for each torque boost (05)
	07	Automatic accel/ decel control	00 : nonoperate 01 : operate	—	00	
08 ■ ACCEL 1 DECEL 1 DATA PRCT	08	Acceleration time 1	(LCD)0.01~3600S	0.01	6.00	(11kW or over 12.00)
	09	Deceleration time 1	(LCD)0.01~3600S	0.01	6.00	(11kW or over 12.00)
	10	Data protection	00 : change possible 01 : protect	—	00	<input type="checkbox"/> STOP key and <input type="checkbox"/> / <input type="checkbox"/> keys (code change) <input type="checkbox"/> SET key (code setting)

GRAPHIC DISPLAY	Function Code	Function	Display-Setting-Range	Minimum Unit	Factory Setting	Remarks
-----------------	---------------	----------	-----------------------	--------------	-----------------	---------

② Basic Functions

11 ■ MAX Hz BASE Hz RATED V MTR POLES	11	Maximum frequency	00 : 50Hz 01 : 60Hz 02 : 100Hz 03 : 120Hz 04 : free (Hz)	1Hz	01	04 (code) when setting (LCD) 0 ~ 400Hz
	12	Base frequency	00 : 50Hz 01 : 60Hz 02 : free (Hz)	1Hz	01	02 (code) when setting (LCD) 0 ~ 400Hz
	13	Rated output voltage	00 : 200V 01 : 220V 02 : 230V 03 : free (V)	1V	03 (OV)	03 (code) when setting (LCD) 0~230 0V setting : no AVR
	14	Normal of motor poles	02.04.06.08. 10.12	—	04	02 : 2 pole, 04 : 4 pole, 06 : 6 pole, 08 : 8 pole, 10 : 10 pole, 12 : 12 pole
15 ■ OPR COMND Hz COMND ACC PTN H TRQ BRK	15	Operation command	00 : Keypad panel operation 01 : terminal block operation 02 : link operation	—	01	
	16	Frequency command	00 : digital 01 : analog (voltage) 02 : analog (voltage)	—	01	Even when link operation mode is selected, monitoring of the set frequency is possible.
	17	Accel/Decel pattern	00 : linear 01 : weak "S" shape 02 : strong "S" shape	—	00	
	18	Normal/High torque dynamic brake	00 : normal brake 01 : hard brake	—	00	
19 ■ PTN OPR RESTART MNTR COEF FUNC BLK	19	Pattern operation	00 : nonoperate 01 : operate	—	00	
	20	Restart after instantaneous power failure	00 : nonoperate 01 : operate	—	00	
	21	Coefficient for line speed	(LCD)0.00~200	0.0	0.01	
	22	Function blocks used	00 : up to basic function 01 : up to standard function 02 : up to high level function	—	00	

GRAPHIC DISPLAY	Function Code	Function	Display Setting Range	Minimum Unit	Factory Setting	Remarks
③ Standard Function						
23 ■ ACCEL 2 ACCEL 3 ACCEL 4	23	Acceleration time 2	(LCD)0.01~3600Sec	0.01	10.0	Terminals RT1 · RT2 ON · OFF
	24	Acceleration time 3	(LCD)0.01~3600Sec	0.01	15.0	Terminals RT1 · RT2 ON · OFF
	25	Acceleration time 4	(LCD)0.01~3600Sec	0.01	3.00	Terminals RT1 · RT2 ON · ON
26 ■ DECEL 2 DECEL 3 DECEL 4	26	Deceleration time 2	(LCD)0.01~3600Sec	0.01	10.0	Terminals RT1 · RT2 ON · OFF
	27	Deceleration time 3	(LCD)0.01~3600Sec	0.01	15.0	Terminals RT1 · RT2 OFF · ON
	28	Deceleration time 4	(LCD)0.01~3600Sec	0.01	3.00	Terminals RT1 · RT2 ON · ON
29 ■ MULT SPD1 TIMER 1 MULT SPD2 TIMER 2	29	Multistep speed setting 1	(LCD)0.00~400Hz	0.002	10.0	<p>Only for pattern operation (19) mode select Timer 1 to 7 setting possible When setting Timer 1 to 7 Setting code (rotation direction - acceleration/deceleration time) 00 : FWD- acceleration/deceleration 1 01 : FWD- acceleration/deceleration 2 02 : FWD- acceleration/deceleration 3 03 : FWD- acceleration/deceleration 4 04 : REV- acceleration/deceleration 1 05 : REV- acceleration/deceleration 2 06 : REV- acceleration/deceleration 3 07 : REV- acceleration/deceleration 4</p> <p>Pattern operation summary When operation panel mode is selected (1500) RUN key : start operation STOP key : discontinue operation (pause) RESET key : pattern operation forced stop When terminal block operation is selected (1501) FWD terminal : start operation REV terminal : discontinue operation (pause)</p>
	30	Timer 1	(LCD)0.01~3600Sec	0.01	5.00	
	31	Multistep speed setting 2	(LCD)0.00~400Hz	0.002	20.0	
	32	Timer 2	(LCD)0.01~3600Sec	0.01	5.00	
33 ■ MULT SPD3 TIMER 3 MULT SPD 4 TIMER 4	33	Multistep speed setting 3	(LCD)0.00~400Hz	0.002	30.0	
	34	Timer 3	(LCD)0.01~3600Sec	0.01	5.00	
	35	Multistep speed setting 4	(LCD)0.00~400Hz	0.002	40.0	
	36	Timer 4	(LCD)0.01~3600Sec	0.01	5.00	
37 ■ MULT SPD5 TIMER 5 MULT SPD6 TIMER 6	37	Multistep speed setting 5	(LCD)0.00~400Hz	0.002	50.0	
	38	Timer 5	(LCD)0.01~3600Sec	0.01	5.00	
	39	Multistep speed setting 6	(LCD)0.00~400Hz	0.002	60.0	
	40	Timer 6	(LCD)0.01~3600Sec	0.01	5.00	
41 ■ MULT SPD7 TIMER 7	41	Multistep speed setting 7	(LCD)0.00~400Hz	0.002	60.0	
	42	Timer 7	(LCD)0.01~3600Sec	0.01	5.00	
43 ■ ERCTRN OL H LIMITER L LIMITER FREQ BIAS	43	Electronic thermal overload relay	00 : nonoperate 01 : operate (%)	1%	00	When setting 01 (code) (LCD) 30 to 150%
	44	High limiter	(LCD)0~100%	1%	100	
	45	Low limiter	(LCD)0~100%	1%	0	
	46	Bias frequency	(LCD)0~100%	1%	0	
47 ■ FREQ GAIN JUMP Hz 1 JUMP Hz 2 JUMP Hz 3	47	Gain for frequency setting signal	(LCD)0~200%	1%	100	
	48	Jump frequency 1	(LCD)0~400Hz	1Hz	0	
	49	Jump frequency 2	(LCD)0~400Hz	1Hz	0	
	50	Jump frequency 3	(LCD)0~400Hz	1Hz	0	
51 ■ J HYSTR DC BRAKE DC BRK Hz DC BRK U	51	Jump frequency range	(LCD)0~5Hz	1Hz	0	
	52	DC brake	00 : nonoperate 01 : operate	-	00	
	53	DC brake starting frequency	(LCD)0~60Hz	1Hz	0	0.2 Hz at 00
	54	DC brake voltage	0 to 15% (code)	1%	00	
55 ■ DC BRK T START Hz I LIMITER SLIP COMP	55	DC braking time	(LCD)0.01~30Sec	0.01	0.10	
	56	Starting frequency	(LCD) 0.2~60 Hz	1Hz	1	0.2 Hz at 00
	57	Current limiter	00 : nonoperate 01 : operate (%)	1%	00	When setting 01 (code) (LCD) 30 to 150%
	58	Slip compensation control	00 : nonoperate 01 : operate		00	
59 ■ FDT Hz FDT HYSTR RUN FINSH OL WARN	59	Frequency level detection	(LCD)0~400Hz	1Hz	60	
	60	FDT and FAR signal hysteresis	(LCD)0~30Hz	1Hz	10	
	61	Run signal finishing frequency	(LCD)0~400Hz	1Hz	0	
	62	Overload early warning signal	(LCD)70~150%	1%	100	

GRAPHIC DISPLAY	Function Code	Function	Setting Data	Standard Function Terminals	Function Change Terminals	Data	Factory Setting	Other, LCD Display
-----------------	---------------	----------	--------------	-----------------------------	---------------------------	------	-----------------	--------------------

④ High Function

4.1 Terminal Function Change

63 ■ X1-X2-X3 HOLD FUNC LV-OL-FAR	63	X1, X2 and X3 terminal function	00	X1~X3		Multistep Speed (7 steps)	00	
			01	X1 X2	ΔHz ▽Hz	0.002 Hz step addition 0.002 Hz step subtraction		
			02	X1	BrI	DC Brake ON		
	64	FWD/REV command hold (3-wire control)	00	HLD		2 wire	00	
01 02			DRV TM		3 wire Cycle operation signal selection			
66 ■ LV FUNC OL FUNC FAR FUNC	65	LV, OL and FAR terminal output code	00	Independent terminal between	/	LV	00	Function is determined by function code (66 to 68)
			01			FAR		
	66	LV terminal function	00	LV	/	Undervoltage signal	00	When selecting 3 bit code output, 0 to 7 step binary code is output at LV-OL-FAR. Accordingly, the data which has been set is ignored.
			01	OV		Overvoltage signal		
02			CL IP	Overload early warning signal Current-limiting monitoring signal Undervoltage or restarting signal				
67	OL terminal function	00	OL	/	Frequency equivalence detection signal Frequency level detection signal Inverter stop signal (inverse of RUN signal)	00		
		01 02	FAR					
68	FAR terminal function	00	FAR	/	FDT STOP	00		
		01 02						
69 ■ RUN FUNC FM FUNC	69	RUN terminal function	00	RUN	TP TO	Inverter running signal Finish signal of each stage in pattern operation Finish signal of each cycle in pattern operation	00	
			01 02					
70	FM terminal function	00	FM	AMP	Frequency monitor signal (analog) Current monitor signal (analog)	00		
		01						

4.2 Link Function

71 ■ NO. ENTRY TL UNITS	71	Master & Auxiliary & Slave	Inverter unit No. entry for link operation (All inverters)	00	-	-	Master	15	Slave inverter numbers are recorded in order from small to large. When auxiliaries are not needed, they are recorded as slaves.
				01 02 03 04 1 15			Aux. 1 (slave) Aux. 2 (slave) Aux. 3 (slave) Slave 1 Slave		
72	72	Master	Number of units linked (Central inverter)	00	-	-	Number of connect auxiliary/slave	00	Maximum number of connected inverters is 16. (Including maser)
				1 15					
73 ■ LINK MODE INPUT SEL NO. SELECT	73	All kinds	Link mode (All inverters)	00	-	-	Inactive	00	During operation / During stop 7301 SET : 80XX setting possible 7302 SET : 81XX setting possible 7303 SET : 82XX setting possible
				01 02 03			Individual frequency setting Individual monitoring signal Link operation		
				00	-	-	Keypad panel Terminal		
74	74	Master	Run command input in link operation (Central inverters)	00	-	-	Keypad panel Terminal	00	During operation / During stop 1502 (link) SET : setting required
				01					
75	75	Master	Inverter unit No. (Central inverter only)	00	-	-	Individual command	00	During operation / During stop When parameter command (8201) When 75XX SET Release Link (00 : transmission end) During Link (01 : start transmission) setting possible
				1 15 16			All command With link operation, this setting is necessary.		

4.3 Option Function





GRAPHIC DISPLAY	Function code	Function	Display · Setting · Range	Data	Factory Setting	Other, LCD Display
76 ■ OPTION 1 OPTION 2 OPTION 3 OPTION 4	76	Spares	00~99		00	
	77	Spares	00~99		00	
	78	Spares	00~99		00	
	79	Spares	00~99		00	

4.4 Link Function





GRAPHIC DISPLAY	Function code	Setting Data	Function			Factory Setting	Other, LCD Display		
			Function Name	Standard Function Terminals	Data				
80 ■ FREQ BITS CODE OPR MODE	80	Frequency Setting	00	Aux. 1	X1 X2 X3 RT1	Frequency Input	4 bit binary input	00	resolution = $\frac{\text{max. frequency}}{15}$
			01	Aux. 1 Aux. 2	X1 X2 X3 RT1		8 bit binary input		resolution = $\frac{\text{max. frequency}}{255}$
			02	Aux. 1 Aux. 2 Aux. 3	X1 X2 X3 RT1		12 bit binary input		resolution = $\frac{\text{max. frequency}}{4095}$
			00	Master	—	—	4 bit frequency input		Master X1, X2, X3 and RT1 are 4 bit binary inputs for inverter numbers (00 to 15). Slave X1, X2, and X3 are for function setting by function code (6300). Slave RT1 and RT2 are standard function
			01				8 bit frequency input		
			02				12 bit frequency input		
81 ■ FREQ BITS CODE OPR MODE (Advances on display by function code 7302 SET)	81	Monitoring Signal	00	Master	LV OL FAR RUN 30A 30B 30C		Output terminal data monitor	00	Master X1, X2, X3, and RT1 are 4 bit binary input for inverter numbers (00 to 15). Designated inverter output terminal data (LV, OL, FAR, RUN) monitored at master. 30 A, B, C are — batch monitored. Set data is fixed at 00.
82 ■ FREQ BITS CODE OPR MODE (Advances on display by function code 7303 SET)	82	Link Operation	00	Master	—		Operation Command		Individual / All can be operated from master keypad panel or terminal block. Slave operates via mater frequency setting as well as keypad command.
			01				Load Command		The master parameter (except function code : 71 to 75, 80 to 82) is transmitted Individual / All. Parameter transmission to slave in operation is not possible. (Err4 will be displayed on master)

(2) Function Explanation




① Initial Setting




Function Code	Display	Function Explanation	Function Data
 <div data-bbox="146 357 373 493" style="border: 1px solid black; padding: 5px;"> <input checked="" type="checkbox"/> DIGTL MNTR <input type="checkbox"/> GRHC MNTR <input type="checkbox"/> MTR SOUND <input type="checkbox"/> FM CALIBR </div> <p data-bbox="146 504 373 556">LED Digital Monitor Selection</p>	<div data-bbox="414 388 527 430">0000</div> <div data-bbox="414 472 527 514">0001</div> <div data-bbox="414 546 527 588">0002</div> <div data-bbox="414 609 527 651">0003</div> <div data-bbox="414 682 527 724">0004</div>	<p data-bbox="649 262 1209 346">After the power supply is turned on, or after completion of program, the 7 segment LED (4 digit) initial display data can be changed.</p> <p data-bbox="649 378 1209 430">Set frequency [Hz] (during STOP), output frequency [Hz] (during RUN) displayed</p> <p data-bbox="649 472 1209 504">Output current [A] display (virtual value)</p> <p data-bbox="649 535 1209 567">Output voltage [V] display (virtual value)</p> <p data-bbox="649 609 1209 640">Synchronous rotation speed [rpm] display</p> <p data-bbox="649 682 1209 714">Line speed [m/min] display</p> <div data-bbox="649 703 1209 1354">  </div>	<div data-bbox="1258 378 1437 451">00:00</div>
		<p data-bbox="649 1396 1209 1459">For each display mode, normally the display can be changed by using the SHIFT key.</p> <div data-bbox="665 1459 1177 1732">  </div> <p data-bbox="649 1764 1209 1837">For frequency display, one digit shift to the right for verification is possible by using the SHIFT key. (At this time the digit on the left will not be displayed)</p> <div data-bbox="763 1879 1088 1942">  </div>	

















Function Code	Display	Function Explanation	Function Data
<div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; padding: 2px;">04:</div> <div style="font-size: 8px;">Hz A V RPM M/min</div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <input checked="" type="checkbox"/> AUTO TRQ <input type="checkbox"/> TRQ BOOST <input type="checkbox"/> TRQ FINE <input type="checkbox"/> AUTO ACC </div> <p>Automatic torque boost control</p>	<div style="display: flex; justify-content: space-around; margin-bottom: 5px;"> 0400 0401 </div>	<p>Automatically regulates the output voltage to correspond to the operating load conditions.</p> <p>Nonoperate : operates at set torque boost value (05)</p> <p>Operate : auto torque boost</p>	<div style="border: 1px solid black; padding: 5px; font-size: 24px;">04:00</div>
<div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; padding: 2px;">05:</div> <div style="font-size: 8px;">Hz A V RPM M/min</div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <input type="checkbox"/> AUTO TRQ <input checked="" type="checkbox"/> TRQ BOOST <input type="checkbox"/> TRQ FINE <input type="checkbox"/> AUTO ACC </div> <p>Torque Boost</p>	<div style="display: flex; justify-content: space-around; margin-bottom: 5px;"> 0500 0501 </div> <div style="display: flex; justify-content: space-around; margin-bottom: 5px;"> 0502 </div> <div style="display: flex; justify-content: center; margin-bottom: 5px;"> 0531 </div>	<p>Setting can be made from 32 types, depending on type of load, motor characteristics, etc.</p> <p>} For reduction torque load use (fan, pump, etc.)</p> <p>Weak ↓ Strong</p> <div style="text-align: center;"> </div>	<div style="border: 1px solid black; padding: 5px; font-size: 24px;">05:13</div>
<div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; padding: 2px;">06:</div> <div style="font-size: 8px;">Hz A V RPM M/min</div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <input type="checkbox"/> AUTO TRQ <input type="checkbox"/> TRQ BOOST <input checked="" type="checkbox"/> TRQ FINE <input type="checkbox"/> AUTO ACC </div> <p>Fine Adjustment Of Torque Boost</p>	<div style="display: flex; justify-content: space-around; margin-bottom: 5px;"> 0600 </div> <div style="display: flex; justify-content: center; margin-bottom: 5px;"> 0609 </div>	<p>For torque boost value set at 05 the torque boost value can be further fine adjusted. (10 Steps)</p> <p>[Example] For torque boost value set at 05</p> <div style="text-align: center;"> </div>	<div style="border: 1px solid black; padding: 5px; font-size: 24px;">06:00</div>
<div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; padding: 2px;">07:</div> <div style="font-size: 8px;">Hz A V RPM M/min</div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <input type="checkbox"/> AUTO TRQ <input type="checkbox"/> TRQ BOOST <input type="checkbox"/> TRQ FINE <input checked="" type="checkbox"/> AUTO ACC </div> <p>Automatic Accel/Decel Control</p>	<div style="display: flex; justify-content: space-around; margin-bottom: 5px;"> 0700 </div> <div style="display: flex; justify-content: center; margin-bottom: 5px;"> 0701 </div>	<p>Automatically determines the acceleration/deceleration time corresponding to the load characteristics, GD². The minimum times are 3 sec. for acceleration, and 8 sec. for deceleration. (0 ↔ 60Hz)</p> <p>Nonoperate (at 08 09 operation is at set acceleration/deceleration time)</p> <p>Operate (auto acceleration/deceleration operation)</p>	<div style="border: 1px solid black; padding: 5px; font-size: 24px;">07:00</div>




Function Code	Display	Function Explanation	Function Data										
		<p>① For heavy inertia load.</p> <p>② Does not function when momentary power failure restart $\boxed{2001}$ is active, or current limit $\boxed{5701}$ is selected.</p> <p>③ Does not function for S time acceleration/deceleration $\boxed{1701}$ $\boxed{1702}$</p>											
<p>$\boxed{08}$ Hz A V rpm M/min</p> <p><input checked="" type="checkbox"/> ACCEL 1 <input type="checkbox"/> DECEL 1 DATA PRTC</p> <p>Acceleration Time 1</p>	<p>$\boxed{08}$ Hz A V rpm M/min</p> 	<p>Setting is possible within the 0.01S to 3,600S range to correspond to load characteristics. GD^2.</p> <table border="1" data-bbox="657 535 1047 766"> <thead> <tr> <th>Setting time</th> <th>Setting Resolution</th> </tr> </thead> <tbody> <tr> <td>0.01 ~ 9.99 s</td> <td>By 0.01s</td> </tr> <tr> <td>10.00 ~ 99.90 s</td> <td>By 0.1s</td> </tr> <tr> <td>100.0 ~ 999.0 s</td> <td>By 1s</td> </tr> <tr> <td>1000 ~ 3600 s</td> <td>By 10s</td> </tr> </tbody> </table>	Setting time	Setting Resolution	0.01 ~ 9.99 s	By 0.01s	10.00 ~ 99.90 s	By 0.1s	100.0 ~ 999.0 s	By 1s	1000 ~ 3600 s	By 10s	<p>$\boxed{08}$ Hz A V rpm M/min</p> 
Setting time	Setting Resolution												
0.01 ~ 9.99 s	By 0.01s												
10.00 ~ 99.90 s	By 0.1s												
100.0 ~ 999.0 s	By 1s												
1000 ~ 3600 s	By 10s												
<p>$\boxed{09}$ Hz A V rpm M/min</p> <p><input type="checkbox"/> ACCEL 1 <input checked="" type="checkbox"/> DECEL 1 DATA PRTC</p> <p>Deceleration Time 1</p>	<p>$\boxed{09}$ Hz A V rpm M/min</p> 	<p>Is selected when both RT1-CM and RT2-CM are OFF.</p>	<p>$\boxed{09}$ Hz A V rpm M/min</p> 										
<p>$\boxed{10}$ Hz A V rpm M/min</p> <p>ACCEL 1 DECEL 1 <input checked="" type="checkbox"/> DATA PRTC</p> <p>Data Protection</p>	<p>$\boxed{1000}$ $\boxed{1001}$</p>	<p>For data that does not need to be changed, the set data can be locked.</p> <p>No protect</p> <p>Protect</p> <p>① $\boxed{\wedge}$ $\boxed{\vee}$ keys + \boxed{STOP} key changes data. Data is stored with the SET key.</p> <p>② Change of data other than $\boxed{10}$ is not possible.</p>	<p>$\boxed{10:00}$</p>										

② Basic Function

















Function Coda	Display	Function Explanation	Function Data
<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> 11 Hz RPM A V M/min </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <input checked="" type="checkbox"/> MAX Hz <input type="checkbox"/> BASE Hz <input type="checkbox"/> RATED V <input type="checkbox"/> MTR POLES </div> <p>Maximum Frequency</p>	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; text-align: center;">1100</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; text-align: center;">1101</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; text-align: center;">1102</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; text-align: center;">1103</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; text-align: center;">1104</div>	<p>Sets maximum value for output frequency</p> <p>50Hzmax 60Hzmax 100Hzmax 120Hzmax</p>  <p>Between 0 to 400Hz, the maximum frequency can be set with 1Hz step.</p> <p>Damage may result if commonly used motors, etc. which are designed for low speed use, are operated at maximum frequency. Operate motors at a frequency setting conforming to the motor characteristics.</p>	<div style="border: 1px solid black; padding: 5px; text-align: center; font-size: 24px; font-weight: bold;">1101</div>
<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> 12 Hz RPM A V M/min </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <input type="checkbox"/> MAX Hz <input checked="" type="checkbox"/> BASE Hz <input type="checkbox"/> RATED V <input type="checkbox"/> MTR POLES </div> <p>Base Frequency</p>	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; text-align: center;">1200</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; text-align: center;">1201</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; text-align: center;">1202</div>	<p>Sets the base frequency. (frequency for specified torque characteristics and specified output characteristic divergent point)</p> <p>50Hz 60Hz</p>  <p>Between 0 to 400Hz, the base frequency can be set with 1Hz step.</p> <p>① Operate at a setting conforming to the motor characteristics. ② A setting exceeding the maximum frequency is not possible.</p>	<div style="border: 1px solid black; padding: 5px; text-align: center; font-size: 24px; font-weight: bold;">1201</div>
<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> 1303 Hz RPM A V M/min </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <input type="checkbox"/> MAX Hz <input type="checkbox"/> BASE Hz <input checked="" type="checkbox"/> RATED V <input type="checkbox"/> MTR POLES </div> <p>Rated Output Voltage</p>	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; text-align: center;">1300</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; text-align: center;">1301</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; text-align: center;">1302</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; text-align: center;">1303</div>	<p>Sets the maximum value for the output voltage.</p> <p>200V 220V 230V</p>  <p>When set at 0V, voltage proportioned to the power supply voltage is output. Between 1 to 230V, output voltage can be set with 1 V step.</p> <p>Output of voltage exceeding the power supply voltage is not possible.</p>	<div style="border: 1px solid black; padding: 5px; text-align: center; font-size: 24px; font-weight: bold;">1303</div> <p style="text-align: center;">(0V)</p>








Function Coda	Display	Function Explanation	Function Data
<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> 14 </div> <div style="display: flex; justify-content: space-between; font-size: 0.8em;"> Hz rpm </div> <div style="display: flex; justify-content: space-between; font-size: 0.8em;"> ▲ ▼ </div> <div style="display: flex; justify-content: space-between; font-size: 0.8em;"> M/min M/min </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p>MAX Hz BASE Hz RATED U <input checked="" type="checkbox"/> MTR POLES</p> </div> <p>Number of Motor Poles</p>	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1402</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1404</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1406</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1408</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1410</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1412</div>	<p>The number of motor poles is set using the display for synchronous rpm.</p> <p>2 pole conversion</p> <p>4 pole conversion</p> <p>6 pole conversion</p> <p>8 pole conversion</p> <p>10 pole conversion</p> <p>12 pole conversion</p> <p>[Example] Display when 4 pole motor is operated at 60Hz.</p> <div style="display: flex; align-items: center; margin-top: 10px;"> <div style="border: 1px solid black; padding: 2px; margin-right: 10px; display: inline-block;">1800</div> ■ RPM </div>	<div style="border: 1px solid black; padding: 5px; width: 100px; text-align: center; margin: 0 auto;">14:04</div>
<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> 15 </div> <div style="display: flex; justify-content: space-between; font-size: 0.8em;"> Hz rpm </div> <div style="display: flex; justify-content: space-between; font-size: 0.8em;"> ▲ ▼ </div> <div style="display: flex; justify-content: space-between; font-size: 0.8em;"> M/min M/min </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p><input checked="" type="checkbox"/> OPR COMND Hz COMND ACC PTN H TRQ BRK</p> </div> <p>Operation Command</p>	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1500</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1501</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1502</div>	<p>Selection can be made from the following 3 types.</p> <p>Panel operation mode (RUN STOP keys)</p> <p>Terminal block mode (FWD, REV, HLD terminals)</p> <p>Link mode (group operation : see p.54 to 57)</p>	<div style="border: 1px solid black; padding: 5px; width: 100px; text-align: center; margin: 0 auto;">15:01</div>
<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> 16 </div> <div style="display: flex; justify-content: space-between; font-size: 0.8em;"> Hz rpm </div> <div style="display: flex; justify-content: space-between; font-size: 0.8em;"> ▲ ▼ </div> <div style="display: flex; justify-content: space-between; font-size: 0.8em;"> M/min M/min </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p>OPR COMND <input checked="" type="checkbox"/> Hz COMND ACC PTN H TRQ BRK</p> </div> <p>Frequency Command</p>	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1600</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1601</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1602</div>	<p>Selection can be made from the following 3 types.</p> <p>Digital setting (▲ ▼ keys)</p> <p>Analog setting (DC 0 to 10V)</p> <p>Analog setting (DC 0 to 10V)</p> <p>Even when 1502 link operation is selected, monitor of setting frequency is possible.</p>	<div style="border: 1px solid black; padding: 5px; width: 100px; text-align: center; margin: 0 auto;">16:01</div>
<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> 17 </div> <div style="display: flex; justify-content: space-between; font-size: 0.8em;"> Hz rpm </div> <div style="display: flex; justify-content: space-between; font-size: 0.8em;"> ▲ ▼ </div> <div style="display: flex; justify-content: space-between; font-size: 0.8em;"> M/min M/min </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p>OPR COMND Hz COMND <input checked="" type="checkbox"/> ACC PTN H TRQ BRK</p> </div> <p>Accel/Decel Pattern</p>	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1700</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1701</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px; display: inline-block;">1702</div>	<p>Selection can be made from the following 3 types.</p> <p>Linear acceleration/deceleration (Fig. a)</p> <p>Weak S curve acceleration/deceleration (Fig. b)</p> <p>Strong S curve acceleration/deceleration (Fig. c)</p> <div style="display: flex; justify-content: space-around; margin-top: 20px;"> <div style="text-align: center;">  <p>Fig. a</p> </div> <div style="text-align: center;">  <p>Fig. b</p> </div> <div style="text-align: center;">  <p>Fig. c</p> </div> </div> <p>Does not function when 0701 auto acceleration/ deceleration is selected.</p>	<div style="border: 1px solid black; padding: 5px; width: 100px; text-align: center; margin: 0 auto;">17:00</div>

Function Code	Display	Function Explanation	Function Data						
<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> OPR COMND Hz COMND ACC PTN <input checked="" type="checkbox"/> H TRQ BRK </div> <p>Normal/High Torque Dynamic Brake</p>	 	<p>Selection can be made from the following 2 types of regenerative braking methods.</p> <p>Standard brake via internal DB impedance</p> <p>High brake via external DB impedance (option)</p> <ul style="list-style-type: none"> For standard braking via internal DB impedance, braking operates at below 66Hz output frequency. For high braking via external DB impedance, braking operates at full output frequency range. <p>For loads requiring an instantaneous stop, set the high brake mode and connect the optional external DB impedance.</p>							
<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <input checked="" type="checkbox"/> PTN OPR RESTART MNTR COEF FUNC BLK </div> <p>Pattern Operation</p>	 	<p>Selects between operate/nonoperate for timer multistep frequency operation set by function codes  to .</p> <p>Nonoperate (standard multistep frequency operation)</p> <p>Operate (timer multistep frequency operation)</p> <p>See function codes to  for pattern operation details.</p>							
<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <input checked="" type="checkbox"/> PTN OPR <input checked="" type="checkbox"/> RESTART MNTR COEF FUNC BLK </div> <p>Restart After Instantaneous Power Failure</p>	 	<p>Selects restart mode for instantaneous power failure and restoration.</p> <p>Nonoperate (No operation command: inverter stop With operation command: undervoltage trip)</p> <p>Operate (Picks up the free running motor rpm for a smooth restart)</p> <p>① For , operates only when LU lights up. The LU light times for each unit is listed in the table below. (sec.)</p> <p>200V series</p> <table border="1" data-bbox="797 1325 1036 1402" style="margin-left: auto; margin-right: auto;"> <tr> <td>002</td> <td>004</td> <td>008</td> </tr> <tr> <td>0.5</td> <td>1.2</td> <td>1.4</td> </tr> </table> <p>② Combined use with current limit function is possible.</p>	002	004	008	0.5	1.2	1.4	
002	004	008							
0.5	1.2	1.4							

Function Code	Display	Function Explanation	Function Data
<div style="border: 1px solid black; padding: 2px; display: inline-block;">  </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> PTN OPR RESTART <input checked="" type="checkbox"/> MNTR COEF FUNC BLK </div> <p>Coefficient for Line Speed</p>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> F coefficient Hz × 0.000 </div> <p style="text-align: center;">↓</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> F coefficient Hz × 200 </div>	<p>Coefficient K is for display of m/min Display value = output frequency × K Display output frequency × 0.00</p> <p style="text-align: center;">↓</p> <p>Displays output frequency × 200</p> <p style="text-align: right;">By 0.01 setting is possible when K = 0.00 to 200.</p> <hr/> <p>If the value for output frequency × K exceeds 9999, 9999 is displayed.</p> <p>[Example] K = 200 at output 100HZ 100Hz × K = 20,000 → display 9999</p>	
<div style="border: 1px solid black; padding: 2px; display: inline-block;">  </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> PTN OPR RESTART <input checked="" type="checkbox"/> MNTR COEF <input checked="" type="checkbox"/> FUNC BLK </div> <p>Function Blocks Used</p>	<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;"> 2200 </div> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;"> 2201 </div> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> 2202 </div>	<p>The function code block display range for function code setting as well as verification can be defined.</p> <p>(SHIFT key changes display range definition)</p> <p>Up to basic function display (00 → 22 setting and verification possible)</p> <p>Up to standard function display (00 → 62 setting and verification possible)</p> <p>Function display (00 → 82 setting and verification possible)</p>	<div style="border: 1px solid black; padding: 5px; display: inline-block;">  </div>

③ Standard Function

Function Code	Display	Function Explanation	Function Data									
 <input type="checkbox"/> ACCEL 2 <input type="checkbox"/> ACCEL 3 <input type="checkbox"/> ACCEL 4	 	<p>Setting between the 0.01S to 3600S range is possible to correspond to the load characteristics, GD^2.</p> <p>0.01 to 9.99S : By 0.01S 10.00 to 99.90S : By 0.1S 100.0 to 999.0S : By 1S 1000 to 3600S : By 10S</p> <p>Selection of acceleration times 1 through 4 is made via RT1 and RT2 terminal combinations.</p> <table border="1" data-bbox="657 472 1193 619"> <thead> <tr> <th>Terminal: ON/OFF</th> <th>RT2-CM ON</th> <th>RT2-CM OFF</th> </tr> </thead> <tbody> <tr> <td>RT1-CM ON</td> <td>Acceleration Time 4</td> <td>Acceleration Time 2</td> </tr> <tr> <td>RT1-CM OFF</td> <td>Acceleration Time 3</td> <td>Acceleration Time 1</td> </tr> </tbody> </table>	Terminal: ON/OFF	RT2-CM ON	RT2-CM OFF	RT1-CM ON	Acceleration Time 4	Acceleration Time 2	RT1-CM OFF	Acceleration Time 3	Acceleration Time 1	 
Terminal: ON/OFF	RT2-CM ON	RT2-CM OFF										
RT1-CM ON	Acceleration Time 4	Acceleration Time 2										
RT1-CM OFF	Acceleration Time 3	Acceleration Time 1										
<p>Acceleration Time 2</p>  <input type="checkbox"/> ACCEL 2 <input checked="" type="checkbox"/> ACCEL 3 <input type="checkbox"/> ACCEL 4	 	<p>* The setting time equals the time required to reach the set maximum frequency from zero. (0 → max. set freq.)</p> <p>Indicates time change (sec.) up to (<input type="text" value="1111"/> setting)</p>	 									
<p>Acceleration Time 3</p>  <input type="checkbox"/> ACCEL 2 <input type="checkbox"/> ACCEL 3 <input checked="" type="checkbox"/> ACCEL 4	 		 									
<p>Acceleration Time 4</p>												

Function Code	Display	Function Explanation	Function Data									
26: <input type="checkbox"/> DECEL 2 <input type="checkbox"/> DECEL 3 <input type="checkbox"/> DECEL 4		Setting between the 0.01S to 3600S range is possible to correspond to the load characteristics, GD^2 . 0.01 to 9.99S : By 0.01S 10.00 to 99.90S : By 0.1S 100.0 to 999.0S : By 1S 1000 to 3600S : By 10S Selection of deceleration times 1 thru 4 is made via RT1 and RT2 terminal combinations.										
Deceleration Time 2 27: <input type="checkbox"/> DECEL 2 <input checked="" type="checkbox"/> DECEL 3 <input type="checkbox"/> DECEL 4		<table border="1" data-bbox="591 508 1135 646"> <thead> <tr> <th>Terminal ON/OFF</th> <th>RT2-CM ON</th> <th>RT2-CM OFF</th> </tr> </thead> <tbody> <tr> <td>RT1-CM ON</td> <td>Deceleration time 4</td> <td>Deceleration time 2</td> </tr> <tr> <td>RT1-CM OFF</td> <td>Deceleration time 3</td> <td>Deceleration time 1</td> </tr> </tbody> </table>	Terminal ON/OFF	RT2-CM ON	RT2-CM OFF	RT1-CM ON	Deceleration time 4	Deceleration time 2	RT1-CM OFF	Deceleration time 3	Deceleration time 1	
Terminal ON/OFF	RT2-CM ON	RT2-CM OFF										
RT1-CM ON	Deceleration time 4	Deceleration time 2										
RT1-CM OFF	Deceleration time 3	Deceleration time 1										
Deceleration Time 3 28: <input type="checkbox"/> DECEL 2 <input type="checkbox"/> DECEL 3 <input checked="" type="checkbox"/> DECEL 4		* The setting time equals the time required to reach 0 from the maximum frequency. (max. frequency \rightarrow 0) Indicates time change (sec.) up to (<input type="text"/> / <input type="text"/> / <input type="text"/> / <input type="text"/> setting)										
Deceleration Time 4												

Function Code	Display	Function Explanation	Function Data																																													
29: <input checked="" type="checkbox"/> MULT SPD1 TIMER 1 <input type="checkbox"/> MULT SPD2 TIMER 2 Multistep Speed Setting 1	29: 10.00 Hz	8 step multi-step frequency operation is possible through switching of the control terminals X1, X2, X3 (for setting) 1900 [Set resolution]	29: 10.00 Hz																																													
<input checked="" type="checkbox"/> MULT SPD2 TIMER 2 Multistep Speed Setting 2	31: 20.00 Hz	<table border="1"> <thead> <tr> <th>Multi-step set value</th> <th>0~1.000Hz</th> <th>1.000~10.00Hz</th> <th>10.00~100.0Hz</th> <th>100.0~</th> </tr> </thead> <tbody> <tr> <td>Maximum frequency</td> <td>0.002Hz</td> <td>0.01Hz</td> <td>0.1Hz</td> <td>—</td> </tr> <tr> <td>60Hz</td> <td>0.002Hz</td> <td>0.01Hz</td> <td>0.1Hz</td> <td>—</td> </tr> <tr> <td>300Hz</td> <td>0.01Hz</td> <td>0.01Hz</td> <td>0.1Hz</td> <td>1Hz</td> </tr> <tr> <td>400Hz</td> <td>0.02Hz</td> <td>0.01Hz</td> <td>0.1Hz</td> <td>1Hz</td> </tr> </tbody> </table>	Multi-step set value	0~1.000Hz	1.000~10.00Hz	10.00~100.0Hz	100.0~	Maximum frequency	0.002Hz	0.01Hz	0.1Hz	—	60Hz	0.002Hz	0.01Hz	0.1Hz	—	300Hz	0.01Hz	0.01Hz	0.1Hz	1Hz	400Hz	0.02Hz	0.01Hz	0.1Hz	1Hz	31: 20.00 Hz																				
Multi-step set value	0~1.000Hz	1.000~10.00Hz	10.00~100.0Hz	100.0~																																												
Maximum frequency	0.002Hz	0.01Hz	0.1Hz	—																																												
60Hz	0.002Hz	0.01Hz	0.1Hz	—																																												
300Hz	0.01Hz	0.01Hz	0.1Hz	1Hz																																												
400Hz	0.02Hz	0.01Hz	0.1Hz	1Hz																																												
<input checked="" type="checkbox"/> MULT SPD3 TIMER 3 <input type="checkbox"/> MULT SPD4 TIMER 4 Multistep Speed Setting 3	33: 30.00 Hz	<table border="1"> <thead> <tr> <th>Function code</th> <th>16</th> <th>29</th> <th>31</th> <th>33</th> <th>35</th> <th>37</th> <th>39</th> <th>41</th> </tr> </thead> <tbody> <tr> <td>Multi-step frequency</td> <td>Analog Digital</td> <td>Speed 1</td> <td>Speed 2</td> <td>Speed 3</td> <td>Speed 4</td> <td>Speed 5</td> <td>Speed 6</td> <td>Speed 7</td> </tr> <tr> <td>X1-CM</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>X2-CM</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> </tr> <tr> <td>X3-CM</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> <td>ON</td> <td>ON</td> </tr> </tbody> </table>	Function code	16	29	31	33	35	37	39	41	Multi-step frequency	Analog Digital	Speed 1	Speed 2	Speed 3	Speed 4	Speed 5	Speed 6	Speed 7	X1-CM	OFF	ON	OFF	ON	OFF	ON	OFF	ON	X2-CM	OFF	OFF	ON	ON	OFF	OFF	ON	ON	X3-CM	OFF	OFF	OFF	OFF	ON	ON	ON	ON	33: 30.00 Hz
Function code	16	29	31	33	35	37	39	41																																								
Multi-step frequency	Analog Digital	Speed 1	Speed 2	Speed 3	Speed 4	Speed 5	Speed 6	Speed 7																																								
X1-CM	OFF	ON	OFF	ON	OFF	ON	OFF	ON																																								
X2-CM	OFF	OFF	ON	ON	OFF	OFF	ON	ON																																								
X3-CM	OFF	OFF	OFF	OFF	ON	ON	ON	ON																																								
<input checked="" type="checkbox"/> MULT SPD4 TIMER 4 Multistep Speed Setting 4	35: 40.00 Hz	Output frequency vs time (t) showing 8 speed steps: Analog Digital, Speed 1, Speed 2, Speed 4, Speed 6, Speed 3, Speed 5, Speed 7. Below the graph are timing diagrams for X1-CM, X2-CM, X3-CM, and FWD-CM.	35: 40.00 Hz																																													
<input checked="" type="checkbox"/> MULT SPD5 TIMER 5 <input type="checkbox"/> MULT SPD6 TIMER 6 Multistep Speed Setting 5	37: 50.00 Hz		37: 50.00 Hz																																													
<input checked="" type="checkbox"/> MULT SPD6 TIMER 6 Multistep Speed Setting 6	39: 60.00 Hz		39: 60.00 Hz																																													
<input checked="" type="checkbox"/> MULT SPD7 TIMER 7 Multistep Speed Setting 7	41: 60.00 Hz		41: 60.00 Hz																																													
			① When X1-CM, X2-CM, X3-CM are all OFF, setting is made by digital (keys), or analog (DC 0 to +10V, 4 to 20mA) which is selected by function 16																																													
			② A setting exceeding the maximum frequency set by 11 is not possible.																																													
			③ When 1901 is set, operation is by timer multi-step frequency.																																													
		④ When 6300 is set, multi-step frequency 1 thru 7 switching is possible via X1, X2, X3 terminals.																																														

Function Code	Display	Function Explanation	Function Data																					
30: <input checked="" type="checkbox"/> MULT SPD1 <input checked="" type="checkbox"/> TIMER 1 <input type="checkbox"/> MULT SPD2 <input type="checkbox"/> TIMER 2 Timer 1		When 1901 is set, timer multi-step frequency operation is possible by multi-step frequency 1 thru 7 combination. When in timer multi-step frequency operation, no frequency changeover via the X1, X2, X3 terminals is necessary.																						
32: <input type="checkbox"/> MULT SPD1 <input checked="" type="checkbox"/> TIMER 1 <input type="checkbox"/> MULT SPD2 <input checked="" type="checkbox"/> TIMER 2 Timer 2		Operation is in the multi-step frequency 1 → multi-step frequency 2 → multi-step frequency 7 order. 																						
34: <input type="checkbox"/> MULT SPD3 <input checked="" type="checkbox"/> TIMER 3 <input type="checkbox"/> MULT SPD 4 <input type="checkbox"/> TIMER 4 Timer 3		[Rotation direction and acceleration/deceleration time] Function codes 30 32 34 36 38 40 42																						
36: <input type="checkbox"/> MULT SPD3 <input checked="" type="checkbox"/> TIMER 3 <input type="checkbox"/> MULT SPD 4 <input checked="" type="checkbox"/> TIMER 4 Timer 4		By using the chart below to see the code, rotation direction and acceleration/deceleration time can be determined.																						
38: <input type="checkbox"/> MULT SPD5 <input checked="" type="checkbox"/> TIMER 5 <input type="checkbox"/> MULT SPD6 <input type="checkbox"/> TIMER 6 Timer 5																								
40: <input type="checkbox"/> MULT SPD5 <input checked="" type="checkbox"/> TIMER 5 <input type="checkbox"/> MULT SPD6 <input type="checkbox"/> TIMER 6 Timer 6																								
42: <input type="checkbox"/> MULT SPD7 <input checked="" type="checkbox"/> TIMER 7 Timer 7																								
	<table border="1"> <thead> <tr> <th>Data Code</th> <th>Rotation Direction</th> <th>Acceleration Time · Deceleration Time</th> </tr> </thead> <tbody> <tr> <td>00</td> <td rowspan="4">Forward (FWD)</td> <td>08 09</td> </tr> <tr> <td>01</td> <td>23 26</td> </tr> <tr> <td>02</td> <td>24 27</td> </tr> <tr> <td>03</td> <td>25 28</td> </tr> <tr> <td>04</td> <td rowspan="4">Reverse (REV)</td> <td>08 09</td> </tr> <tr> <td>05</td> <td>23 26</td> </tr> <tr> <td>06</td> <td>24 27</td> </tr> <tr> <td>07</td> <td>25 28</td> </tr> </tbody> </table>	Data Code	Rotation Direction	Acceleration Time · Deceleration Time	00	Forward (FWD)	08 09	01	23 26	02	24 27	03	25 28	04	Reverse (REV)	08 09	05	23 26	06	24 27	07	25 28		
Data Code	Rotation Direction	Acceleration Time · Deceleration Time																						
00	Forward (FWD)	08 09																						
01		23 26																						
02		24 27																						
03		25 28																						
04	Reverse (REV)	08 09																						
05		23 26																						
06		24 27																						
07		25 28																						

Function Code


Display

Function Explanation


Function Data

When the next frequency in the process is higher than the present frequency, the acceleration time will be automatically selected. If the next frequency is lower than the present frequency, the deceleration time will be automatically selected.

[Example 1] when data code is **3200**




Function code 08 setting
Acceleration Time



Function code 09 setting
Deceleration Time

[Example 2] when data code is **3204**



Function code 09 setting
Deceleration Time


Function code 08 setting
Acceleration Time

[Timer Setting]




After setting the rotation direction and acceleration/deceleration time, set the timer.




Timer Setting	Setting Resolution
0.01~9.99sec	0.01sec
10.00~99.90sec	0.1sec
100.0~999.0sec	1sec
1000~3600sec	10sec





The time set on the timer includes the time required for acceleration/deceleration. Therefore, if the time set on the timer is less than the time required for the acceleration/deceleration conditions, it will proceed to the next process before the set step frequency is reached.







































Required acceleration time





Function Code	Display	Function Explanation	Function Data
		<p>[Timer multi-step frequency operation method]</p> <p>① Panel Operation</p> <p>The key functions are changed as follows:</p> <p>RUN key : Start operation</p> <p>STOP key : Temporary stop of inverter operation (pause)</p> <p>RESET key : Timer operation reset</p> <p>(The next RUN input will start operation from Step 1)</p> <p># RESET function only during STOP.</p> <p>[Example 1]</p>  <p>[Example 2]</p>  <p>[Example 3]</p> 	







Function Code	Display	Function Explanation	Function Data
		<p>② Control Terminal Operation The terminal functions are changed as follows: FWD-CM = ON : Start operation FWD-CM = OFF : Stop timer operation REV-CM = ON : Temporary stop timer operation (pause)</p> <p>[Example 1]</p>  <p>[Example 2]</p>  <p>[Example 3]</p> 	
		<p>① During timer operation, if RT1-CM, RT2-CM terminals are ON/OFF, operation will switch to acceleration/deceleration times set by 23 to 28</p> <p>② During timer operation, if X1-CM, X2-CM, X3-CM terminals are ON/OFF, operation will switch to multi-step frequencies 1 to 7 set by 29 31 33 35 37 39 41</p> <p>The time for both ① and ② is counted on the timer.</p>	










Function Code	Display	Function Explanation	Function Data
<p data-bbox="77 226 251 289">43:</p> <p data-bbox="77 304 308 436"> <input checked="" type="checkbox"/> ELECTRONIC THERMAL OVERLOAD PROTECTION RELAY </p> <p data-bbox="84 464 243 510">Electronic Thermal Overload Relay</p>	<p data-bbox="342 262 451 304">4300</p> <p data-bbox="342 331 487 384">4301</p> 	<p data-bbox="581 184 1136 231">Commonly used motor (4 pole) over-heating protection is possible. (all frequency range protection possible)</p> <p data-bbox="581 275 686 300">Nonoperate</p> <p data-bbox="581 344 987 369">Operate (electronic thermal protection operation)</p> <p data-bbox="581 413 868 438">Setting range 30 to 105% (by 1%)</p> <p data-bbox="581 489 1039 546">Setting value % = $K \times \frac{\text{Motor rated current}}{\text{Inverter rated current}}$</p> <p data-bbox="581 596 906 642"> $K = 1.0$ (when 50Hz is base frequency) $K = 1.1$ (when 60Hz is base frequency) </p> <p data-bbox="651 680 1024 705">Continuous allowable current characteristics</p>  <p data-bbox="656 1169 1036 1194">Electronic Thermal Operation Characteristics</p> 	<p data-bbox="1193 247 1367 310">43:00</p> <p data-bbox="1177 464 1321 516">4301</p> 

Function Code	Display	Function Explanation	Function Data
<p>44:</p> <p>Hz A V RPM M/min</p> <p>ERCTRN OL <input checked="" type="checkbox"/> H LIMITER <input type="checkbox"/> L LIMITER <input type="checkbox"/> FREQ BIAS</p> <p>High Limiter</p>	<p>44:</p> <p>Hz A V RPM M/min</p> 	<p>The output frequency for the upper limit as well as the lower limit are set as a % of the maximum frequency</p> <p>0 to 100% (by 1%)</p>	<p>44:</p> <p>Hz A V RPM M/min</p> 
<p>45:</p> <p>Hz A V RPM M/min</p> <p>ERCTRN OL <input type="checkbox"/> H LIMITER <input checked="" type="checkbox"/> L LIMITER <input type="checkbox"/> FREQ BIAS</p> <p>Low limiter</p>	<p>45:</p> <p>Hz A V RPM M/min</p> 	<p>0 to 100% (by 1%)</p> 	<p>45:</p> <p>Hz A V RPM M/min</p> 
<p>46:</p> <p>Hz A V RPM M/min</p> <p>ERCTRN OL <input type="checkbox"/> H LIMITER <input type="checkbox"/> L LIMITER <input checked="" type="checkbox"/> FREQ BIAS</p> <p>Bias Frequency</p>	<p>46:</p> <p>Hz A V RPM M/min</p> 	<p>Outputs a biased frequency corresponding to the frequency setting Set as a % of the maximum frequency</p> <p>0 to 100% (by 1%)</p> 	<p>46:</p> <p>Hz A V RPM M/min</p> 

Function Code	Display	Function Explanation	Function Data
47:  Hz A V RPM M/min <input checked="" type="checkbox"/> FREQ GAIN JUMP Hz 1 JUMP Hz 2 JUMP Hz 3 Gain For Frequency Setting Signal	 Hz A V RPM M/min  100 %	A rationed frequency corresponding to the frequency setting is output. It is set as a % of the maximum frequency. (Higher than the maximum frequency is not output) 0 to 200% (by 1%) DC 0 to +5V correspondence is possible. 	 Hz A V RPM M/min  100 %
Frequency gain is operative only when frequency setting method is analog  , 			
48:  Hz A V RPM M/min FREQ GAIN <input checked="" type="checkbox"/> JUMP Hz 1 JUMP Hz 2 JUMP Hz 3 Jump Frequency 1	 Hz A V RPM M/min  0 Hz	The frequency jumps to prevent the load mechanical resonance point and the inverter output frequency from overlapping. (3 location setting possible) 0 to 400Hz (by 1Hz)	 Hz A V RPM M/min  0 Hz
49:  Hz A V RPM M/min FREQ GAIN JUMP Hz 1 <input checked="" type="checkbox"/> JUMP Hz 2 JUMP Hz 3 Jump Frequency 2	 Hz A V RPM M/min  0 Hz		 Hz A V RPM M/min  0 Hz
50:  Hz A V RPM M/min FREQ GAIN JUMP Hz 1 JUMP Hz 2 <input checked="" type="checkbox"/> JUMP Hz 3 Jump Frequency 3	 Hz A V RPM M/min  0 Hz		 Hz A V RPM M/min  0 Hz
51:  Hz A V RPM M/min <input checked="" type="checkbox"/> J HYSTR DC BRAKE DC BRK Hz DC BRK U Jump Frequency Range	 Hz A V RPM M/min  0 Hz		


Function Code	Display	Function Explanation	Function Data						
<p>52: <small>Hz A V</small> <small>rpm M/min</small></p> <p>J HYSTR <input checked="" type="checkbox"/> DC BRAKE DC BRK Hz DC BRK V</p> <p>DC Brake</p>	<p>5200</p> <p>5201</p>	<p>Switches current brake between Operate / Nonoperate.</p> <p>Nonoperate (only regenerative brake)</p> <p>Operate (DC brake after regenerative brake)</p> 	<p>52:00</p>						
<p>53: <small>Hz A V</small> <small>rpm M/min</small></p> <p>J HYSTR DC BRAKE <input checked="" type="checkbox"/> DC BRK Hz DC BRK V</p> <p>DC Brake Starting Frequency</p> <p>54: <small>Hz A V</small> <small>rpm M/min</small></p> <p>J HYSTR DC BRAKE <input checked="" type="checkbox"/> DC BRK V</p> <p>DC Brake Voltage</p> <p>55: <small>Hz A V</small> <small>rpm M/min</small></p> <p><input checked="" type="checkbox"/> DC BRK T START Hz I LIMITER SLIP COMP</p> <p>DC Braking Time</p>	<p>5400</p> <p>5415</p>	<p>Setting for the DC brake starting frequency 0 to 60Hz (by 1Hz) (except at 0Hz braking is from 0.2Hz)</p> <p>Weak ↓ Setting can be made from 16 types of DC brake strength. Strong</p> <p>Brake strength changes according to the motor characteristics</p> <p>Within a 0.01 to 30 sec. time span, setting is possible or match the load GD².</p> <table border="1" data-bbox="690 1396 1112 1533"> <thead> <tr> <th>Setting Range</th> <th>Setting Resolution</th> </tr> </thead> <tbody> <tr> <td>0.01~9.99sec</td> <td>0.01sec</td> </tr> <tr> <td>10.00~30.00sec</td> <td>0.1sec</td> </tr> </tbody> </table> 	Setting Range	Setting Resolution	0.01~9.99sec	0.01sec	10.00~30.00sec	0.1sec	<p>53: <small>Hz A V</small> <small>rpm M/min</small></p>  <p>54:00</p> <p>55: <small>Hz A V</small> <small>rpm M/min</small></p> 
Setting Range	Setting Resolution								
0.01~9.99sec	0.01sec								
10.00~30.00sec	0.1sec								

Function Code	Display	Function Explanation	Function Data
56: DC BRK T <input checked="" type="checkbox"/> START Hz <input type="checkbox"/> I LIMITER <input type="checkbox"/> SLIP COMP Starting Frequency	56: 	The start frequency setting can be by 1Hz within a 1Hz to 60Hz range 1 Hz ↓ 60Hz 	56: 
57: DC BRK T <input checked="" type="checkbox"/> I LIMITER <input type="checkbox"/> SLIP COMP Current Limiter	57:  5700 5701	When the output current reaches the current limit level, the output frequency is automatically lowered to avoid over-current trip. Nonoperate Operate (operates at 30 to 150% of the inverter rating. By 1% setting possible)  ① Does not operate for deceleration. ② When using this function, the automatic acceleration/deceleration function does not operated.	57:00
58: DC BRK T START Hz <input checked="" type="checkbox"/> I LIMITER <input type="checkbox"/> SLIP COMP Slip Compensation Control	58:00 5801	Automatically judges the relative size of the load by the output current fluctuations, and regulates the inverter frequency for consistent rpm operation. (controls speed fluctuations to 1/3 of normal slip) Nonoperate (no slip compensation) Operate (with slip compensation)  Operates only during constant speed operation.	58:00

Function Code	Display	Function Explanation	Function Data
<p>59:</p> <p> <input type="checkbox"/> FDT Hz <input type="checkbox"/> FDT HYSTR <input type="checkbox"/> RUN FINSH <input type="checkbox"/> OL WARN </p> <p>Frequency Level Detection</p>	<p>59:</p>  <p>60 Hz</p>	<p>The FAR-CM terminal ON signal is output when the output frequency goes above the frequency level detection.</p> <p>The OFF level is set by 60</p> <p>0 to 400Hz (by 1Hz)</p> <p>0 to 30Hz (by 1Hz)</p>  <p>↑ Output frequency</p> <p>FAR-CM → t</p> <p>When 6801 is set, the FDT signal is operative.</p>	<p>59:</p>  <p>60 Hz</p>
<p>60:</p> <p> <input type="checkbox"/> FDT Hz <input checked="" type="checkbox"/> FDT HYSTR <input type="checkbox"/> RUN FINSH <input type="checkbox"/> OL WARN </p> <p>FDT And FAR Signal Hysteresis</p>	<p>60:</p>  <p>10 Hz</p>	<p>0 to 400Hz (by 1Hz)</p>  <p>↑ Output frequency</p> <p>RUN-CM → t</p> <p>When 6900 is set, the RUN signal is operative.</p>	<p>60:</p>  <p>10 Hz</p>
<p>62:</p> <p> <input type="checkbox"/> FDT Hz <input type="checkbox"/> FDT HYSTR <input type="checkbox"/> RUN FINSH <input checked="" type="checkbox"/> OL WARN </p> <p>Overload Early Warning Signal</p>	<p>62:</p>  <p>100 %</p>	<p>The OL-CM terminal ON signal is output when the output current exceeds the overload early warning signal value for over 10 sec.</p> <p>70% to 150% by 1% (for inverter rating)</p>  <p>↑ Output current</p> <p>OL-CM → t</p> <p>10 Second</p> <p>1 Second</p> <p>When 6700 is set, the OL signal is operative.</p>	<p>62:</p>  <p>100 %</p>


④ High Function (See p.57 for Frequency Setting In Link Operation, Monitoring Signal In Link Operation and Link Operation function settings)



Function Code	Display	Function Explanation	Function Data
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> 63 </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>■ X1-X2-X3 HOLD FUNC LU-OL-FAR</p> </div> <p>X1, X2, and X3 Terminal Function</p>	<div style="border: 1px solid black; padding: 5px; margin-bottom: 20px; width: fit-content; margin-left: 20px;"> 6300 </div> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-left: 20px;"> 6301 </div>	<p>The terminal X1, X2, X3 functions can be changed to the following 3 types via the data setting.</p> <p>8 step multi-step frequency operation is possible through switching X1, X2, X3. See function codes 29 31 33 35 37 39 41 for details on multistep frequency operation.</p> <p>During operation, with RUN key or FWD, REV terminals:</p> <p>When X1-CM is ON: output frequency increase When X1-CM is OFF: output frequency fixed</p> <p>When X2-CM is ON: output frequency decrease When X2-CM is OFF: output frequency fixed</p> <p>The up/down variable speed is determined by the acceleration/deceleration time setting value.</p> <p>① X3-CM terminal ON/OFF is ignored.</p> <p>② When both X1-CM and X2-CM are ON at the same time, the frequency at that time is fixed.</p> <p>③ Hi Limiter And LO Limiter take precedence (44 45)</p> <p>④ Always at 0Hz for operation start</p> <p>⑤ Operative only when frequency setting is by digital method</p> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 5px 0;"> 1600 </div> <p>⑥ When there is no operation command (RUN , FWD, REV), X1, X2 input is ignored.</p> <p>⑦ ^ v key input is ignored.</p> <div style="text-align: center; margin-top: 20px;"> </div>	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin-left: auto; margin-right: auto;"> 63:00 </div>



Function Code	Display	Function Explanation	Function Data
	<div data-bbox="418 214 532 256" style="border: 1px solid black; padding: 2px; display: inline-block;">6302</div>	<p data-bbox="657 220 1047 252">When DC brake is selected by <div data-bbox="925 214 1039 256" style="border: 1px solid black; padding: 2px; display: inline-block;">5201</div>:</p> <p data-bbox="657 268 1023 315">with X1-CM = ON: DC brake during stop with X1-CM = OFF: brake reset</p> <div data-bbox="646 394 1182 714" style="margin-top: 20px;"> <p data-bbox="852 403 1063 430">[Example <div data-bbox="950 394 998 436" style="border: 1px solid black; padding: 2px; display: inline-block;">53</div>:0sec]</p>  <p>The diagram shows four signals over time: Output frequency (f), DC Brake, FWD-CM, and X1-CM. The frequency starts at a constant level, then ramps down to zero as DC Brake becomes active. FWD-CM and X1-CM are active during this braking period. After the braking period ends, the frequency ramps back up to its original level, and DC Brake, FWD-CM, and X1-CM return to their inactive states.</p> </div> <ol style="list-style-type: none"> <li data-bbox="657 924 1063 955">① The strength of the DC brake is set by <div data-bbox="1006 919 1055 961" style="border: 1px solid black; padding: 2px; display: inline-block;">54</div> <li data-bbox="657 970 1169 1018">② Operation command take precedence. (<div data-bbox="1015 966 1088 1008" style="border: 1px solid black; padding: 2px; display: inline-block;">RUN</div> , FWD, REV) <li data-bbox="657 1018 1136 1050">③ While X1-CM is ON, if FWD-CM is ON: DC brake reset <li data-bbox="657 1050 1039 1071">④ X2-CM, X3-CM terminal ON/OFF is ignored. <li data-bbox="657 1071 1177 1155">⑤ As DC current continues to flow to the motor during the X1-CM - ON period, be careful of temperature rise. (When long periods of DC braking are required, measure the temperature previously.) 	




Function Code	Display	Function Explanation	Function Data
<div data-bbox="105 205 279 268" style="border: 1px solid black; padding: 2px;">64</div> <div data-bbox="105 283 332 415" style="border: 1px solid black; padding: 2px;"> X1-X2-X3 <input checked="" type="checkbox"/> HOLD FUNC LU-OL-FAR </div> <p data-bbox="105 424 332 472">FWD/REV Command Hold (3-Wire Control)</p>	<div data-bbox="373 283 483 319" style="border: 1px solid black; padding: 2px;">6400</div> <div data-bbox="373 756 483 793" style="border: 1px solid black; padding: 2px;">6401</div>	<p data-bbox="613 199 1144 247">Depending on the data selection, the HLD terminal function can be changed to the following 3 types.</p> <p data-bbox="613 289 755 315">2 wire operation</p> <p data-bbox="613 352 1144 403">When terminal block operation (1501) is selected, the following operation results.</p> <div data-bbox="657 430 1096 640"> <p>(Connection)</p> </div> <p data-bbox="613 672 1112 724">When both FWD-CM and REV-CM are ON at the same time, deceleration stop results. HLD terminal input is ignored.</p> <p data-bbox="613 766 755 791">3 wire operation</p> <p data-bbox="613 829 1144 900">When Terminal block operation (1501) is selected, the following operation results.</p> <div data-bbox="613 1018 1096 1606"> <p>(Connection 1)</p> <p>(Connection 2)</p> </div> <ol data-bbox="597 1627 1144 1921" style="list-style-type: none"> ① When HLD-CM is ON : and FWD-CM is ON for over 10 msec. : Forward HLD-CM is OFF : Stop and REV-CM is ON for over 10 msec : Reverse HLD-CM is OFF : Stop During the period when HLD-CM is ON, either the FWD or REV signal whichever input first takes precedence. ② When HLD-CM is OFF, if FWD and REV signal are input, 2 wire operation will result. ③ Operation will not start if FWD, REV signal t (time) is less than 10 msec. 	<div data-bbox="1218 247 1396 310" style="border: 1px solid black; padding: 2px;">6400</div>






Function Code	Display	Function Explanation	Function Data
	<div data-bbox="394 226 500 268" style="border: 1px solid black; padding: 2px; display: inline-block;">6402</div>	<p data-bbox="630 218 894 239">Switches timer operation mode.</p> <p data-bbox="630 260 927 289">When 6400 6401</p> <div data-bbox="654 373 1133 558" style="text-align: center;"> </div> <p data-bbox="630 663 1159 743">When 6402 : with HLD-CM in OFF, returns to the 1st step after 1 cycle of operation.</p> <div data-bbox="630 821 1159 1100" style="text-align: center;"> </div> <p data-bbox="630 1241 1175 1289">With HLD-CM in ON, maintains the 7th step level after 1 cycle of operation.</p> <div data-bbox="646 1409 1175 1667" style="text-align: center;"> </div> <p data-bbox="643 1877 1138 1927">① Only operative when 1901 pattern operation is selected.</p> <p data-bbox="667 1944 1192 1974">With 1900 , normal 2 wire operation results (same as</p> <p data-bbox="667 1990 808 2020">6400).</p>	

Function Code	Display	Function Explanation	Function Data																																
<div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>651</p> <p>X1-X2-X3 HOLD FUNC <input checked="" type="checkbox"/> LV-OL-FAR</p> </div> <p>LV, OL and FAR Terminal Output Code</p>	<p>6500</p> <p>6501</p>	<p>The signal data output from LV, OL, FAR terminals can be changed.</p> <p>LV terminal outputs the signal selected by 66</p> <p>OL terminal outputs the signal selected by 67</p> <p>FAR terminal outputs the signal selected by 68</p> <p>When 1901 pattern operation is selected, a binary signal equivalent to 1st speed → 7th speed is output from LV, OL, FAR terminals.</p> <table border="1" data-bbox="565 594 1110 779"> <thead> <tr> <th></th> <th>1st Speed</th> <th>2</th> <th>3</th> <th>4</th> <th>5</th> <th>6</th> <th>7</th> </tr> </thead> <tbody> <tr> <td>FAR</td> <td>1</td> <td>0</td> <td>1</td> <td>0</td> <td>1</td> <td>0</td> <td>1</td> </tr> <tr> <td>OL</td> <td>0</td> <td>1</td> <td>1</td> <td>0</td> <td>0</td> <td>1</td> <td>1</td> </tr> <tr> <td>LV</td> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>1</td> <td>1</td> <td>1</td> </tr> </tbody> </table> <p>1 : ON 0 : OFF</p>  <p>With 1900, there is no output.</p>		1st Speed	2	3	4	5	6	7	FAR	1	0	1	0	1	0	1	OL	0	1	1	0	0	1	1	LV	0	0	0	1	1	1	1	<p>65:00</p>
	1st Speed	2	3	4	5	6	7																												
FAR	1	0	1	0	1	0	1																												
OL	0	1	1	0	0	1	1																												
LV	0	0	0	1	1	1	1																												

Function Code	Display	Function Explanation	Function Data
	<div style="border: 1px solid black; padding: 2px; display: inline-block;">6702</div>	<p>The under voltage signal (IP signal) is output from the OL terminal.</p> <p>Signal output when in <div style="border: 1px solid black; padding: 2px; display: inline-block;">2000</div> instantaneous restart nonoperate.</p>  <p>Signal output when in <div style="border: 1px solid black; padding: 2px; display: inline-block;">2001</div> restarting operate.</p> 	








<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <div style="border: 1px solid black; padding: 2px; display: inline-block;">68</div> <div style="font-size: 8px; margin-left: 5px;">Hz rpm V Min</div> </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> LV FUNC OL FUNC <input checked="" type="checkbox"/> FAR FUNC </div> <p>FAR Terminal Function</p>	<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 10px;">6800</div> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 10px;">6801</div> <div style="border: 1px solid black; padding: 2px; display: inline-block;">6802</div>	<p>The signal output from the FAR terminal can be selected from the following 3 types.</p> <p>The frequency equivalence detection signal (FAR signal) is output from the FAR terminal.</p> <p>The hysteresis width is set by <div style="border: 1px solid black; padding: 2px; display: inline-block;">50</div></p>  <p>The setting frequency detection signal (FDT signal) is output at the FAR terminal.</p> <p>See <div style="border: 1px solid black; padding: 2px; display: inline-block;">59</div> for signal details.</p> <p>During inverter operation, reverse signal (STOP signal) is output as the FAR terminal. The signal ON/OFF level is set by <div style="border: 1px solid black; padding: 2px; display: inline-block;">51</div></p> <p>The RUN signal's reverse signal is output.</p> 	<div style="border: 1px solid black; padding: 2px; display: inline-block; font-size: 24px;">68:00</div>
---	---	---	---

Function Code	Display	Function Explanation	Function Data
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> 69: </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <input checked="" type="checkbox"/> RUN FUNC <input type="checkbox"/> FM FUNC </div> <p>Run Terminal Function</p>	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px; width: 60px; text-align: center;">6900</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px; width: 60px; text-align: center;">6901</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px; width: 60px; text-align: center;">6902</div>	<p>The following 3 types of signal output at the RUN terminal can be selected.</p> <p>The inverter operation signal (RUN signal) is output at the RUN terminal. The signal ON/OFF level is set by 61</p>  <p>For 1901 pattern operation, the time-up signal (TP signal) is output by the RUN terminal. (outputs at time-up point of each timer)</p>  <p>No signal output when 1900</p> <p>For pattern operation 1901, the cycle completed signal (TO signal) is output at the RUN terminal. (outputs at 7 step end point)</p>  <p>Also for the continuation of timer operation by the TO signal is output at 7 step end point. 6402</p>	<div style="border: 1px solid black; padding: 5px; width: 100px; text-align: center; font-size: 24px; font-family: monospace;">69:00</div>

Function Code	Display	Function Explanation	Function Data
 <p>70:</p> <p>RUN FUNC FM FUNC</p> <p>FM Terminal Function</p>	 <p>7000</p> <p>7001</p>	<p>The following 2 types of monitor signals output by the FM terminal can be selected.</p> <p>Hz meter use voltage is output by the FM terminal.</p> <p>Voltage adjustment is performed by </p> <p>Output current monitor use voltage is output by the FM terminal.</p> <p>Voltage adjustment is performed by </p> <p>(A current which is 1.5 times of the inverter rated current can be adjusted between 6.5 and 10.5V.)</p>	 <p>70:00</p>


Function Code	Display	Function Explanation	Function Data
<p>71</p> <p><input checked="" type="checkbox"/> NO. ENTRY TL UNITS</p> <p>Inverter Unit No. Entry For Link Operation (All Inverters)</p>	<p>7100</p> <p>7101</p> <p>7102</p> <p>7103</p> <p>7104</p> <p>}</p> <p>7115</p>	<p>Determines the function of the various inverters when performing link operation.</p> <p>Err4 will result when 2 identical numbers are recorded within the same group.</p> <p>for Master record</p> <p>Slave No.1 (Auxiliary No.1 for input terminal link)</p> <p>Slave No.2 (Auxiliary No.2 for input terminal link)</p> <p>Slave No.3 (Auxiliary No.3 for input terminal link)</p> <p>Slave No.4</p> <p>}</p> <p>Slave No.15 Always record the inverter numbers consecutively from lowest to highest.</p>	<p>71:15</p>
<p>72</p> <p><input checked="" type="checkbox"/> NO. ENTRY TL UNITS</p> <p>Number of Units Linked (Central Inverter)</p>	<p>7200</p> <p>}</p> <p>7215</p>	<p>Needed only for Master setting Record the total number of units connected (Master and Slave).</p> <p>When the total number connected is greater than the recorded number of inverters. → The number of not inked inverter will appear.</p> <p>When the total number connected is less than the recorded number of inverters. → Err 4</p>	<p>72:00</p>
<p>73</p> <p><input checked="" type="checkbox"/> LINK MODE INPUT SEL NO. SELECT</p> <p>Link Mode (All Inverters)</p>	<p>7300</p> <p>7301</p> <p>7302</p> <p>7303</p>	<p>Link Mode Selection</p> <p>Link Nonoperate (After Err4 reset, automatically returns to 7300) → (for Mater)</p> <p>Frequency Setting → SET → 80XX</p> <p>Monitoring Signal → SET → 81XX</p> <p>Link Operation → SET → 82XX</p>	<p>73:00</p>

Function Code	Display	Function Explanation	Function Data
<p>74:</p> <p>LINK MODE <input checked="" type="checkbox"/> INPUT SEL NO. SELECT</p> <p>Run Command Input In Link Operation (Central Inverter)</p>	<p>7400</p> <p>7401</p>	<p>Setting for Master (required for link operation)</p> <p>Selects interface for Master 1502 (link) operation Control.</p> <p>RUN/STOP via operation panel</p> <p>RUN/STOP via terminal block</p>	<p>74:00</p>
<p>75:</p> <p>LINK MODE <input checked="" type="checkbox"/> NO. SELECT</p> <p>Inverter Unit No. (Central Inverter Only)</p>	<p>7500</p> <p>7515</p> <p>7516</p>	<p>Setting for Master (required for link operation)</p> <p>Record command inverter No.</p> <p>(Individual command)</p> <p>(Total number command)</p>	<p>75:00</p>
<p>80:</p> <p>FREQ BITS CODE <input checked="" type="checkbox"/> OPR MODE</p> <p>Number Of Bits For Frequency Setting In Link Operation (Central Inverter)</p>	<p>8000</p> <p>8001</p> <p>8002</p>	<p>Selects number of bits for frequency input</p> <p>4 Bit binary input</p> <p>Aux. 1 RT1 X3 X2 X1</p> <p>MSB LSB Setting resolution = Max. frequency/15</p> <p>8 Bit binary input</p> <p>AUX.2 AUX.1</p> <p>MSB LSB Setting resolution = Max. frequency/255</p> <p>12 Bit binary input</p> <p>AUX.3 AUX.2 AUX.1</p> <p>MSB LSB Setting resolution = Max. frequency/4095</p> <p>Inverter No. designation is set via the master terminal block.</p> <p>RT1 X3 X2 X1</p> <p>MSB LSB</p>	<p>00:08</p>

Function Code	Display	Function Explanation	Function Data
 <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> FREQ BITS <input checked="" type="checkbox"/> CODE <input type="checkbox"/> OPR MODE </div> <p>Monitoring Signal Output Code In Link Operation</p>		<p>The slave terminal data is monitored via the master terminal block.</p> <p>Set the output terminal data via the function code for each inverter.</p> <p>Terminal output LV OL FAR RUN</p> <p>The inverter No. determination is set via the Master terminal block.</p> <div style="border: 1px solid black; display: inline-block; padding: 2px;"> RT1 X3 X2 X1 </div> <p style="text-align: center;">MSB LSB</p>	
 <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> FREQ BITS <input checked="" type="checkbox"/> CODE <input type="checkbox"/> OPR MODE </div> <p>Monitoring Mode In Link Operaton</p>	 	<p>Selects link operation mode</p> <p>Operation command</p> <p>The master terminal data (input) and key input is transmitted to the slave (s). The slave performs RUN/STOP operation according to the master frequency setting.operate command.</p> <p>The inverter No. determination is performed by function 75.</p> <p>Parameter initial command</p> <p>Function setting for the Slave is performed at the Master operation panel.</p> <p>The inverter No. determination is performed by function 75.</p>	

(3) Trip Record Verification Method

Possible during operation or stop




Change to program mode




<table border="1" style="border-collapse: collapse; width: 100%;"> <tr> <td style="text-align: center;">RESET</td> <td style="text-align: center;">SHIFT</td> </tr> <tr> <td style="text-align: center;">ON</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td style="text-align: center;">↓</td> <td style="text-align: center;">ON</td> </tr> <tr> <td style="text-align: center;">OFF</td> <td style="text-align: center;">↓</td> </tr> <tr> <td style="text-align: center;">↓</td> <td style="text-align: center;">OFF</td> </tr> </table>	RESET	SHIFT	ON	OFF	↓	ON	OFF	↓	↓	OFF	<p>DIGITAL MONITOR</p> <p style="font-size: 1.2em;">OH2</p> <p>GRAPHIC DISPLAY *</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p>F = 60.00Hz I = 1.0A V = 600V Temp. = 70°C</p> </div> <p>Changes when SHIFT key is pressed</p>	<p>DIGITAL MONITOR</p> <p style="font-size: 1.2em;">OH2</p> <p>GRAPHIC DISPLAY</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p>0 = OH2 (current) -1 = OC3 (time before) -2 = Err4 (2 times before) -3 = 0V (3 times before)</p> </div>
RESET	SHIFT											
ON	OFF											
↓	ON											
OFF	↓											
↓	OFF											

(Note 1) For * display, the values shown for F, I, V are present operation values. When trip occurs, the values shown are the values at the time of the trip.
 (Note 2) For * display, the value for V indicates the operation output voltage. For trip, the value indicates the DC intermediate voltage.
 (Note 3) For * display, when trip record is displayed during operation, present values are displayed with the SHIFT key. Also, when trip occurs and the values at the time of the trip are displayed, the trip record is displayed with the SHIFT key.



Returns to function mode



Returns to RUN/STOP when function mode is ended.

(4) Function Setting For Frequency Setting In Link Operation

Function Code	Setting Data					Remarks
	Master	Auxiliary 1	Auxiliary 2	Auxiliary 3	Slave	
15	00 or 01	←	←	←	←	Panel Operation / Terminal Operation Selection
16	01 or 02	←	←	←	←	Link Set Frequency Monitor
71	00	01 * ₁	02 * ₁	03 * ₁	04 ~ 15 * ₁	Setting for Inverter Number
73* ₂	01	←	←	←	←	Frequency Setting Selection
80	00 ~ 02	←	←	←	←	Bit Length Setting

(5) Function Setting For Monitoring Signal In Link Operation

Function Code	Setting Data		Remarks
	Master	Slave	
15	00 or 01	←	Panel Operation / Terminal Operation Selection
71	00	01 ~ 15 * ₁	Setting for Inverter Number
72	00 ~ 15	-	Setting for Number of Connected Inverters
73* ₂	02	←	Monitoring Signal Selection

(6) Function Setting For Link Operation

Function Code	Setting Data		Remarks
	Master	Slave	
15	02	←	Link Operation Selection
16	00 or 01 or 02	-	Link Set Frequency Monitor
47	0 ~ 200%	0 ~ 200%	Percentage Setting
71	00	01 ~ 15 * ₁	Setting for Inverter Number
72	00 ~ 15	-	Setting for Number of Connected Inverters
73* ₂	03	←	Link Operation Select
74	00 or 01	-	Panel Operation / Terminal Operation Select
75	16	-	All inverter Selection
82	00	-	Operation Command Selection In Link Operation

(Note 1) After setting the slave and the auxiliary inverters, set the master.

*₁ Set the slave inverter numbers in sequence from 01 without skipping.

*₂ Set function code 73 after setting other codes.

9. Maintenance & Inspection

In order that the inverter may give long periods of trouble free operation, and to prevent future problems from occurring, the following items should be inspected.


<Caution Notes>

Conduct inspection after disconnecting the power supply and after the "CRG" lamp has gone out.

Megger Test

- ① When conducting an external circuit megger test, disconnect all inverter terminals and never apply test voltage to the inverter.
- ② When conducting a megger test on the inverter itself, perform the test only on the main circuit as shown in the diagram below. Do not conduct a megger test on the control circuits.
- ③ When conducting a continuity test on the control circuits, use a tester (high resistance range type) and not a megger or a buzzer.

Megger Test Outline



(1) Inspection Items

Inspection Point	Inspection Item	Object of Inspection	Correction
Condition	Power Source Voltage	Within permissible range (170V to 253V)	Ajust the power supply voltage.
	Ambient Temperature	Within permissible range (-10°C to 50°C)	After investigating the cause, bring into line with specification limits
	Ambient Humidity	Permissible range (20 to 90% RH)	
		Dew condensation / Freezing	
Vibration	Within permissible limit (0.6G or less)		
Other	Noise	Noise from cooling fan, etc.	Contact the distributor where the unit was purchased.
	Smell	Smell of burning	
	Dust	Dust accumulation on cooling fins, cooling fan Dust accumulation on control board	Cleaning Blow out with compressed air
	Connectors	Loose connectors	Tighten connectors
	Screws	Loose screws	Tighten screws

(2) Periodic Part Replacement

The life of the inverter will vary according to the installation environment and the amount of running time. However, if continuous operation is within the allowable limits, the life of the ordinary electrolytic condenser is approx. 5 years with the life of the cooling fan being approx. 3 years. It is recommended, however, that these parts be replaced before failure occurs.


(3) Measurement Points & Meters

Since the inverter input/output voltage and current contains high frequencies, selection of the wrong measuring device can lead to gross miscalculations. When using a CT (current-detection transformer) to measure the current, if the frequency is low the amount of error will be great. For this reason always use a CT with as large a capacity as possible.

Measurement Items and Types of Devices

Item		Simple Measurement	Precision Measurement
Input	Voltage	Tester.	Moving-iron type voltmeter
	Current	Clamp meter	Moving-iron type ammeter
	Power	---	Electrodynamometer type wattmeter
Output	Voltage	Tester.	Rectifier type voltmeter
	Current	Clamp meter	Moving-iron type voltmeter
	Power	—	Electrodynamometer type wattmeter

Example of Measurement (Locations & Devices)



10 . Troubleshooting

(1) Protective Function

Protective Function	Function Explanation	Display	Protective Operation
Over-current protection	Protects the inverter when the over-current flow momentarily reaches the specified protection level. OC1: During acceleration OC2: During deceleration OC3: During constant speed operation	OC1 OC2 OC3	<ul style="list-style-type: none"> Stops inverter output Motor coast-to-stop Batch alarm (1c) output Alarm signal is internally held until the alarm command is reset. (※)
Protection against momentary Power Failure Under-voltage Protection	For momentary power failure or under-voltage less than 15msec., operation is intermittent. For a period exceeding 15msec., the inverter is stopped. If the restart after instantaneous power failure mode is selected, operation will resume automatically after the power is restored.	LU	Stops inverter output
Over-voltage Protection	This function protects the inverter when the over-voltage (regenerative over-voltage) reaches the momentary over-voltage protection level.	OU	<ul style="list-style-type: none"> Stops inverter output Motor coast-to-stop Batch alarm (1c) output Alarm signal is internally held until the alarm command is reset. (※)
Inverter Overheating	Detects inverter overheating caused by overload operation, cooling fan failure, abnormally high ambient temperature, etc.	OH1	
External Thermal	As an external alarm, it stops output when the DB braking resistor thermal relay, etc. connected to the THR-CM terminals goes from ON to OFF.	OH2	
Electronic Thermal Overload	Performs motor overload protection when connected to the 4 poles of this company's commonly used motor, even if there is no external thermal overload.	OL1	
Setting Error	Displays when incompatible function codes are selected.	Err1	
Communication Error	Displays when there is continuous keypad panel abnormal communication.	Err2	
DSP Error	Displays when there is any malfunction of the internal DSP by external noises or abnormally high ambient temperatures.	Err3	
Link Error	Displays when there is a mismatch between the set function and the actual wiring during link operation.	Err4	

(Note 1) (※) Alarm signal hold

After the protective function has been activated and the alarm signal has been output, if the auto-breaker installed on the power supply side is switched OFF, there will be no inverter control power and the signal cannot be internally held.

(Note 2) Reset command

Use the keypad panel RESET key or turn on the control terminals RST-CM to reset from the abnormal stop condition.

(Note 3) The past 3 protective operations are stored in the memory. This protective operation information is displayed on the GRAPHIC DISPLAY and is changed each time the SHIFT key is pressed (time before → 2 times before → 3 times before).

Failure information as well as failure condition (frequency, voltage, current, inverter internal temperature) is displayed on the GRAPHIC MONITOR.


(2) Troubleshooting

① Protective Operation Display


Display	Check Point	Corrective Measure
OC1	① Power supply voltage within permissible limits..... ② Output line short-circuited ③ Proper torque boost ④ Proper acceleration time..... ⑤ Other than ① thru ④	Adjust power voltage Output line insulation Motor megger measurement Adjust to proper value Lengthen acceleration time Increase inverter capacity
OC2	① Power supply voltage within permissible limits..... ② Output line short-circuited ③ Proper deceleration time ④ Other than ① thru ③	Adjust power voltage Output line insulation Motor megger measurement Lengthen deceleration time Connect DB braking resistor (option) Increase inverter capacity
OC3	① Power supply current within permissible limits..... ② Output line short-circuited ③ Sudden change in load..... ④ Other than ① thru ③	Adjust power current Output line insulation Motor megger measurement Eliminate sudden load change Increase inverter capacity Investigate for noise intrusion
OV	① Power supply current within permissible limits..... ② Proper deceleration time ③ Other than ① or ②	Adjust power current Lengthen deceleration time Connect DB resistor (option)
OH1	① Inverter ambient temp. within permissible limits ② Cooling fan operating (Over 1.5 kw) ③ Load is over permissible limits	Correct to proper temperature Replace cooling fan Reduce load Increase inverter capacity
OH2	① Proper wiring between THR-CM ② Thermal overload relay activated ③ Continuity check between external DB braking unit terminal 1-2..... ④ Inverter ambient temp. within permissible limits	Rewire Reduce load Correct ambient temp./Lower braking frequency Correct to proper temperature
LV	① Power supply voltage within permissible limits..... ② MC, FAB is closed ③ Open phase ④ Other than ① thru ③	Adjust power voltage Close MC, FAB Correct wiring Investigate power supply capacity
OL1	① Electronic thermal overload set correctly ② Load is over permissible limits	Change thermal relay Reduce load
Err1	① Correct function code selection.....	Verify function code
Err2	① Noise source close to inverter.....	Noise prevention measures
Err3	② Abnormal ambient temperature.....	Correct temperature
Err4	① Wiring correct.....	Conform wiring and function code setting for link operation mode

(Note 1) Motor coast-to-stop when protective operation is displayed. According to the chart above, after correcting the cause of the problem, reset with the **RESET** key on the operation panel. (Press the **RESET** key after the motor has stopped.) To reset the alarm, turn ON between the RST-CM control circuit terminals.


(Note 2) "LV" is displayed when the power supply is switched on or off, and does not indicate any abnormality.




ii) Motor runs but speed does not change



iii) Motor rotation is not smooth



iv) Motor overheats



Digital time setting

11. Appendix

(1) Standard Specifications

Item		Specification			
Inverter Type		FVR002B7S-2	FVR004B7S-2	FVR008B7S-2	
Standard Applicable Motors [kW]		0.2	0.4	0.75	
Control	Rated Capacity [kVA] (Note 1)	0.57	1.1	1.9	
	Rated Output Voltage [V](Note 2)	3-phase 3-wire type 200 to 230			
	Rated Output Frequency [Hz]	0.2 - 400			
	Rated Output Current [A]	1.5	3	5	
	Overload Current Rating	150% for 1 min. (inverse time characteristic)			
Power Supply	Rated Input AC Voltage	3-phase 3-wire type 200 to 230V , 50/60Hz			
	Allowable fluctuation	Voltage: + 10% Voltage unbalance %: within 3% Voltage: - 15% Frequency: ± 5%			
Output	Control System	Vector Dispersion PWM control			
	Output Frequency Range	0.2 to 400Hz (start frequency 0.2 to 60Hz, maximum frequency 0.2 to 400Hz setting possible)			
	Frequency Temperature Fluctuation	Analog Setting: max. frequency ± 0.2% (at 25 ± 10°C)			
		Digital Setting max. frequency ± 0.01% (at -10°C to +50°C)			
	Frequency Setting Resolution	Analog Setting: 0.02Hz (at max. frequency 60Hz)			
		Digital Setting: 0.002Hz (at max. frequency 60Hz)			
	Frequency Setting Resolution	0.002Hz (both analog & digital setting)(Note 3)			
	Voltage / Frequency Characteristics (V/F)	Voltage: 200 to 230V Frequency: 0.2 to 400Hz (When in fee selection, voltage or frequency) can be arbitrarily adjusted			
	Torque Boost	320 patterns (squared decrease, including 10 step minute adjustment), automatic torque boost selection possible			
	Acceleration/Deceleration Characteristics	0.01 to 3600 sec. (independent acceleration/deceleration), linear, S characteristic (Strong & weak), automatic and multi-step acceleration/deceleration (independent 4-step) selection possible. (Both terminal & program selection possible.)			
	Internal Functions	Operating sound selection	The sound quality of the sound produced by the motor can be changed to prevent resonance.		
		Frequency meter adjustment	Scale calibration of externally connected analog frequency meter (DC 6.5 to 10.5)		
		Parameter protection	Data lock is possible to ensure that the data codes are not changed.		
		Terminal link	Operation frequency setting for multiple inverters, multi-step operation, interlocking operation, and ratio operation are all possible at the same time.		
		Brake switch	Normal or strong brake selection possible		
		Pattern operation	7 independent step settings possible (frequency up to 400Hz, timer up to 3,600 sec.)		
		Program operation	Based on the pattern operation: 1 cycle, repeat cycle, continuous operation at least step speed, etc. selection possible		
Momentary power failure restart		After momentary power failure, automatic restart possible			
High/Low limiter		Output frequency upper and lower range limit 0 to 100% (1% step) setting possible			
Bias		The magnitude of the bias which contains the frequency setting signal, can be set from 0 to 100% (1% step)			
Gain		The output frequency gain corresponding to the frequency setting signal can be set from 0 to 200% (1% step)			
Frequency jump		A 3 point jump in width of sympathetic vibrations, and resonance is possible during 0 to 5Hz (1Hz step)			
Slip compensation control		Even with load fluctuations, maintains motor at constant speed			
Current limit control		Output current can be controlled within a range of between 30% and 150% (1% step)			
8 step speed switch (operation panel included)		8 step speed operation possible			
2-wire, 3-wire changeover	Selection between the hold constant of operation stop command (2-wire operation) or the momentary contact (3-wire operation) is possible.				
Terminal function change	The function of the same terminal can be changed via the setting (for 10 terminals)				

(Note 1) Indicates rated capacity when rated output voltage is 230V

(Note 2) Output of voltage exceeding the power supply voltage is not possible.

(Note 3) The output frequency is changed at 0.002Hz intervals during acceleration/deceleration. (when at max. frequency 60Hz)


Item		Specification		
Inverter Type		FVR002B7S-2	FVR004B7S-2	FVR008B7S-2
Control Torque	Standard Equipment	Regenerative braking	Condenser regenerative	
		DC braking	Braking frequency 0.2 to 60Hz, braking time 0.01 to 30 sec., braking voltage 0 to 15%	
	With optional equipment	Type	Braking resistor	
		Torque	150% or more	
Operation	Frequency setting signal		Frequency setting device or voltage input: DC 0 to 10V (DC 0 to 5V)	
	Input signal (contact input)		※ By changing the terminal function, the input command or modes can be changed as follows: cycle operation command, frequency adder-subtractor setting, DC brake command, link input, Forward command, reverse command, self-holding selection (when operating 3-wire), multi-step speed (8-step) setting, multi-step accel/decel time setting (4-step), coast-to-stop command, external alarm, reset. (Sampling time span 1 msec or less)	
	External output signal	Contact output	Batch alarm output (1c contact, contact point capacity is AC 250V, 0.3A, COSφ = 0.3)	
		Open collector output	During inverter operation, rated frequency attainment, over-load prediction, under-voltage. ※ These can be changed to the following outputs through the terminal change function. Finish signal of each stage/cycle in pattern operation, frequency level detection, inverter stop, current-limiting monitoring, undervoltage or restarting detection, over-voltage detection.	
Protection Function		Stall prevention, over-current, momentary power failure, under-voltage, over-voltage, inverter over-heating, external problems (external thermal activation, etc.), motor overload (electronic thermal), setting error, communication error, DSP error, link error, output terminal short-circuit.		
Display	Frequency meter output signal		Analog: DC 0 to +10V (adjustment range DC 6.5V to 10.3V) ※ With the terminal change function, this terminal can be changed to load meter equivalent output signal.	
	Keypad panel	Frequency meter output signal	Digital display	4 digit LED, unit is LED
			Graphic display	LCD, with brightness control
		Operation display	Output frequency, set frequency, output current, output voltage, synchronous rpm, line speed	
		Setting display	Function code and setting data displayed (see operation panel explanation)	
		Protection display	OC1: acceleration over-current, OC2: deceleration over-current, OC3: constant speed over-current, LU: under-voltage, OU: over-voltage, OH1: inverter over-heat, OH2: external alarm (external thermal), OL1: electronic thermal (motor overload), Err1: setting error, Err2: communication error, Err3: DSP error, Err4: link error, operating conditions at time of protective operation (4 times including output frequency, etc.), record of protective operations (display of past 3 protective operations)	
		Input signal display	Display of signal existence at FWD, REV, HLD, X1, X2, X3, RT1, RT2 terminals	
Charge lamp (LED)		Lights when DC capacitor voltage is charged		
Condition	Installation location		Indoor, less than 1,000m elevation, not in contact with corrosive gas, oil mist or dust, out of direct sunlight	
	Ambient temperature		-10 to +50 °C (remove ventilation cover if temperature is over +40°C)	
	Temperature		Below 90%RH (without dew condensation)	
	Vibration		0.6G or less (conforms to JIS C0011)	
	Shipping temperature		-25 - + 65°C	
Installation		Install on a panel, install as an external cooling system		
Protection/Cooling Types		Selfcooling type (IP00)		
Approx. weight (kg)		1.5	1.6	1.9
Options		Relay output unit, copy unit, remote operation extension cable, inverter terminal link cable, link adaptor, remote operation panel, remote display panel, T link card, radio noise reduction zero phase reactor, noise reduction AC reactor, power supply coordinating AC reactor, power factor improvement AC reactor, power filter, spark killer, surge killer, arrester, frequency meter, frequency setting device, braking unit, braking resistor, MCA series, ground short detection unit		

(4) Terminal Function

		Code	Terminal Name	Terminal Function
Main circuit part		E(G)	Ground terminal	Connection for ground
		R,S,T	Commercial power input terminals	Connection for commercial power Ac 200 to 230V
		30A(30B),30C	Alarm output	1a(1b) contact AC 250V, 0.3A (cos $\theta = 0.3$)
		P,DB	External braking resistor terminals	Connection for external braking resistor
		U,V,W	Inverter output terminals	Connection for 3-phase induction motor
Control circuit part	Frequency setting	13	Frequency setting voltage output terminal	Internal power supply (DC +10V)
		12	Frequency setting voltage input	Frequency setting signal input (DC 0 to +10V)
		11	Frequency setting common terminal	Internal power supply (0 V)
	Option connection	P12	Ground short detection voltage output	Internal power supply (DC +12 to 15V)
		SHT	Ground short detection signal input	Connection for ground short detection unit(MCAIII-GFD)
		CM	Common	Internal power supply (0 V)
		FM	Frequency meter connection	FM-CM : Regulation (DC +6.5 to 10.5V)
	Input signal	FWD	Forward input	FWD-CM : Forward via short-circuit
		REV	Reverse input	REV-CM : Reverse via short-circuit
		BX	Motor coast-to-stop command	BX-CM : Motor coast-to-stop via short-circuit
		THR	External alarm input	THR-CM : Alarm function via open
		RST	Alarm reset	RST-CM : Reset function via short-circuit
		X1,X2,X3	Multi-step speed selection input	X1,X2,X3-CM : Operation speed switching (8 types)
		RT1,RT2	Acceleration/deceleration time selection input	RT1,RT2-CM : Acceleration/deceleration time switching (4 types)
		HLD	3-wire operation - Stop command	HLD-CM : 3-wire operation function via short-circuit, the pulse signal input from FWD, REV terminals is self-held
		CM	Common	Internal power supply (0 V)
	Output signal	RUN	Inverter running signal	RUN-CM : Open corrector output (27V MAX)
		FAR	Frequency equivalence detection signal	FAR-CM : Open corrector output (27V MAX)
		LV	Under-voltage signal	LV-CM : Open corrector output (27V MAX)
		OL	Overload early warning signal	OL-CM : Open corrector output (27V MAX)
CM		Common	Internal power supply (0 V)	

* CM and CM1, CM2 are short-circuited inside.

(5) FVR-B/S Control Block Diagram



Function Code Table

Function Code	Function	Display, Setting, Range	Factor Setting	For customer use
00	LED digital monitor selection	00 : output frequency [Hz] 01 : output current [A] 02 : output voltage [V] 03 : synchronous rpm [rpm] 04 : line speed [m/min]	00	
01	Graphics monitor selection	00 : Hz AMP monitor 01 : terminal signal 1 02 : terminal signal 2	00	
02	Motor noise reduction	00 to 05 (code)	03	
03	FM terminal output level calibration	00 to 99 (code)	85	
04	Automatic torque boost control	00 : nonoperate 01 : operate	00	
05	Torque boost	00 to 31 (code)	13	
06	Fine adjustment of torque boost	00 to 09 (code)	00	
07	Automatic accel/ decel control	00 : nonoperate 01 : operate	00	
08	Acceleration time 1	(LCD) 0.01 to 3,600 sec.	6.00 12.00	
09	Deceleration time 1	(LCD) 0.01 to 3,600 sec.	6.00 12.00	
10	Data protection	00 : change possible 01 : protect	00	
11	Maximum frequency	00 : 50Hz 00 : 60Hz 00 : 100Hz 00 : 1200Hz 04 : free (Hz)	01	
12	Base frequency	00 : 50 Hz 01 : 60 Hz 02 : free (Hz)	01	
13	Rated output voltage	00 : 200V 00 : 220V 00 : 230V 03 : free (V)	03 (OV)	
14	Number of motor poles	02, 04, 06, 08, 10, 12.	04	
15	Operation command	00 : keypad panel operation 01 : terminal block operation 02 : link operation	01	
16	Frequency command	00 : digital 01 : analog (voltage) 02 : analog (voltage)	01	
17	Accel/Decel pattern	00 : linear 01 : weak "S" shape curve 02 : strong "S" shape curve	00	
18	Normal/High torque dynamic brake	00 : normal brake 01 : hard brake	00	
19	Pattern operation	00 : nonoperate 01 : operate	00	
20	Restart after instantaneous power failure	00 : nonoperate 01 : operate	00	
21	Coefficient for line speed	(LCD) 0.00 - 200	0.01	
22	Function blocks used	00 : up to basic function 01 : up to standard function 02 : up to high level function	00	
23	Acceleration time 2	(LCD) 0.01 - 3000Sec	10.0	
24	Acceleration time 3	(LCD) 0.01 - 3600Sec	15.0	
25	Acceleration time 4	(LCD) 0.01 - 3600Sec	3.00	

Function Code	Function	Display, Setting, Range	Factor Setting	For customer use
26	Deceleration time 2	(LCD) 0.01 - 3600Sec	10.0	
27	Deceleration time 3	(LCD) 0.01 - 3600Sec	15.0	
28	Deceleration time 4	(LCD) 0.01 - 3600Sec	3.00	
29	Multistep speed setting 1	(LCD) 0.00 - 400Hz	10.0	
30	Timer 1	(LCD) 0.01 - 3600Sec	5.00	
31	Multistep speed setting 2	(LCD) 0.01 - 400Hz	20.0	
32	Timer 2	(LCD) 0.01 - 3600Sec	5.00	
33	Multistep speed setting 3	(LCD) 0.01 - 400Hz	30.0	
34	Timer 3	(LCD) 0.01 - 3600Sec	5.00	
35	Multistep speed setting 4	(LCD) 0.01 - 400Hz	40.0	
36	Timer 4	(LCD) 0.01 - 3600Sec	5.00	
37	Multistep speed setting 5	(LCD) 0.01 - 400Hz	50.0	
38	Timer 5	(LCD) 0.01 - 3600Sec	5.00	
39	Multistep speed setting 6	(LCD) 0.01 - 400Hz	60.0	
40	Timer 6	(LCD) 0.01 - 3600Sec	5.00	
41	Multistep speed setting 7	(LCD) 0.01 - 400Hz	60.0	
42	Timer 7	(LCD) 0.01 - 3600Sec	5.00	
43	Electronic thermal overload relay	00 : nonoperate 01 : operate (%)	00	
44	High limiter	(LCD) 0- 100%	100	
45	Low limiter	(LCD) 0- 100%	0	
46	Bias frequency	(LCD) 0- 100%	0	
47	Gain for frequency setting signal	(LCD) 0- 200%	100	
48	Jump frequency 1	(LCD) 0- 400Hz	0	
49	Jump frequency 2	(LCD) 0- 400Hz	0	
50	Jump frequency 3	(LCD) 0- 400Hz	0	
51	Jump frequency range	(LCD) 0- 5Hz	0	
52	DC brake	00 : nonoperate 01 : DC brake	00	
53	DC brake starting frequency	(LCD) 0- 60Hz	0	
54	DC brake voltage	0 to 15 (code)	00	
55	DC braking time	(LCD) 0.01 - 30Sec	0.10	
56	Starting frequency	(LCD) 0.2 - 60Hz	1	
57	Current limiter	00 : nonoperate 01 : operate (%)	00	
58	Slip compensation control	00 : nonoperate 01 : operate	00	
59	Frequency level detection	(LCD) 0- 400Hz	60	
60	FDT and FAR signal hysteresis	(LCD) 0- 30Hz	10	
61	Run signal finishing frequency	(LCD) 0- 400Hz	0	
62	Overload early warning signal	(LCD) 70- 150%	100	

(NOTE) During operation, function code data 00 to 10, 73 to 75, 80 to 82 setting is possible. Also all function codes and data verification is possible.