


LPF 100W_4M is a Low Pass Filter for use in 4M Ham radio equipment.


As an extra feature, there is a small VSWR bridge attached with a simple shutdown pad that can be connected to your amplifier.

This filter is optimised for use with our 25W en 80W pallet amplifiers and can be mounted on the same heat sink as the pallet.



ELECTRICAL SPECIFICATIONS	min	typ	max	
Power handling	100	150	150	W
Input impedance		50		ohm
Output impedance		50		ohm
Harmonic supression @ 140MHz	-40	-45		dB
Harmonic supression @ 210MHz	-55	-60		dB
Internal loss		0.2	0.3	dB

Connections LPF




IN, connect inner conductor of 50 Ohm Teflon coax to this point. For best result use 18CM Coax length between your amplifier and LPF

GND, connect outer conductor of 50 Ohm Teflon coax to this point.

Out, connect inner conductor of 50 Ohm Teflon coax to this point. Connect an 18 CM Coax length from the output to the output connector of the enclosure. Without this coax, the VSWR Bridge will not function!

GND, connect the outer conductor of 50 Ohm Teflon coax to this point.

Connections VWSR PCB



How to adjust the VSWR point

To adjust the shutdown function of the VSWR Bridge, you have to switch the input and output of the LPF. Then power on the AMP to 12-15W output (about 10-15% of the amps max output power). Then set the variable resistor that it will start to lower the DC of the bias of your Amplifier. (A voltmeter is required)

If the variable resistor is set, power off your amplifier and switch the in en out of the filter again. Now your VSWR protection is active.

NOTE: THIS IS ONLY A SIMPLE SHUTDOWN, WE CANNOT GIVE ANY WARRENTY THAT YOUR AMP WILL BE PROTECTED IN ALL CASES!

IMPORTANT NOTICE

FMBROADCASTPARTS RESERVE THE RIGHT TO MAKE CHANGES TO THE PRODUCT(S) OR INFORMATION CONTAINED HEREIN WITHOUT NOTICE. FMBROADCASTPARTS ASSUMES NO RESPONSIBILITY FOR ANY ERRORS WHICH MAY APPEAR IN THIS DOCUMENT. WARRANTY INFORMATION APPLICABLE TO THE PRODUCT IDENTIFIED HEREIN IS AVAILABLE UPON REQUEST. NOTHING CONTAINED HEREIN SHALL CONSTITUTE A WARRANTY, REPRESENTATION OR GUARANTEE OF ANY KIND. FMBROADCASTPARTS EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES, EXPRESS AND/OR IMPLIED INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, AND OF FITNESS FOR A PARTICULAR PURPOSE, USE OR APPLICATION.

WARNING

FMBROADCASTPARTS PRODUCTS ARE NOT INTENDED FOR USE IN LIFE SUPPORT APPLIANCES, DEVICES OR SYSTEMS. USE OF A FMBROADCASTPARTS PRODUCT IN ANY SUCH APPLICATION WITHOUT WRITTEN CONSENT IS PROHIBITED.

No part of this document may be copied or reproduced in any form or by any means without the prior written consent of FMbroadcastparts.