

CENTURION™ - C4 Series Configurable Controller

Installation and Operations Manual

In order to consistently bring you the highest quality, full-featured products, we reserve the right to change our specifications and designs at any time. The latest version of this manual can be found at www.fwmurphy.com.

Warranty - A limited warranty on materials and workmanship is given with this Murphy product. A copy of the warranty may be viewed or printed by going to <http://www.fwmurphy.com/warranty>.



Enovation Controls, LLC. has made efforts to ensure the reliability of the Centurion controller and to recommend safe usage practices in system applications. Please note that in any application, operation and controller failures can occur. These failures may result in full control outputs or other outputs which may cause damage to or unsafe conditions in the equipment or process connected to the Centurion controller. Good engineering practices, electrical codes, and insurance regulations require that you use independent external protective devices to prevent potentially dangerous or unsafe conditions. Assume that the Centurion controller can fail with outputs full on, outputs full off, or that other unexpected conditions can occur.

BEFORE BEGINNING INSTALLATION OF THIS MURPHY PRODUCT:

- Please read the following information before installing the Centurion controller. This installation information is intended for Centurion controller only. Before installing, visually inspect the product for any damage during shipping.
- Disconnect all power and be sure machine is inoperative before beginning installation.
- Installation is to be done only by qualified technician.
- Observe all Warnings and Cautions at each section in these instructions.
- Device shall be wired in accordance with Class I, Division 2 wiring methods.
- This equipment is suitable for use in Class I, Division 2, Groups B, C, and D hazardous Areas.
- **WARNING**–Explosion Hazard–Substitution of components may impair suitability for Class I, Division 2.
- Please contact Enovation Controls immediately if you have any questions.

Table of Contents

Overview	1
Basic Components and Key Features of the C4 Series	2
Optional Components	3
Input/Output Types	4
Power Supply Wiring.....	4
Input/Output Types and Specifications for the Main I/O Module	5
Hardware Installation and Wiring	10
Mounting the Controller	10
Mounting the Display.....	10
Wiring the Display	11
Wiring the Controller	12
Using the MV-3-C Display	14
Features.....	15
Operational Screens	19
Setup Screens and Menus	26
Additional Navigational Aids.....	46
Communications	47
C4-1 Controller Communication Ports.....	47
MV-3-C Display Communication Ports.....	48
Downloading Configurations and Firmware Updates	49
Modbus™ RTU Protocol	50
Replacement Parts and Assemblies	51
Accessories	51
Centurion Configuration Tool Software	51
Glossary	51
Appendices	53
C4-1 Controller LED Description	53
MV-3-C Display LED Description	54
Modbus RTU Register Map.....	54

(THIS PAGE INTENTIONALLY LEFT BLANK)

Overview

The Centurion configurable controller is a display and controller combination expressly designed to meet the requirements of three specific kinds of applications:

- Screw Compressors
- Reciprocating Compressors
- Pumps

The heart of the Centurion system is the main input/output (I/O) module or controller, which can be mounted on a standard DIN rail. While it is designed to work with any Modbus (Master) compliant HMI (Human Machine Interface) or with no operator interface at all, it is optimally configured and field-configurable through Murphynet Software Suite (Centurion Configuration Tool), powerful software developed to configure the controller. Parameters can be modified in the field without special need for laptop or software by utilizing Murphy's specially programmed controller display.

The controller is designed to monitor, control, protect, and optimize small to medium sized gas operated compressors and pumps in the field. Proper operation is maintained by monitoring set points and digital, analog, and thermocouple input points and providing the logic to take corrective and/or proactive steps.

The controller also allows for controlled shut down and no-flow monitoring as well as auto start up, and engine control capabilities.

The controller provides real-time data via communications ports to a connected display and/or supervisory system. This advanced system offers multiple options for remote communications and operation. The industry standard RTU Modbus protocol means greater support for a wide variety of communication equipment including radio and satellite communications systems.

Basic Components and Key Features of the C4 Series

The C4 series consists of a display module, a main I/O module, and optional expansion I/O module. No special cables are required. The Centurion system is designed for use within a weatherproof enclosure only.

Display module (MV-3-C) 320 x 240 LCD graphic display, -40 to 85°C (185°F)

- Power

Powered by 12 or 24 VDC battery systems. 11W (max)

Storage power able to withstand 12V crank

NOTE: Maximum power ratings based on display heater operating at maximum with 10V supply. Heater is only operational below 0 C. Typical based on 24V supply. Heater consumes 5.6W typical.

- Package and design
Same 5" x 5" design as annunciators
12 key keypad
- Communications
LED active indication for each port
RS232/RS485-1 (Modbus Master)
RS485-2 (Reserved)
USB 1.1 compliant ports
 -Type A (Reserved)
 -Type B (Firmware Updates)
CAN 1/2 (Reserved)
- Approvals
CSA, CLASS 1, DIVISION 2, Groups B, C and D certifications are approved.

Main I/O module (C4-1)

- 32 digital inputs (DI)
- 10 digital outputs (DO)
- 2 analog outputs (AO)
- Direct input for analog and thermocouple inputs:
 - 12 analog input (AI)
 - 8 thermocouples (TC)
- 1 magnetic pickup (MPU)

Optional Components

The C4-1 hardware may be configured with 1 of 2 expansion I/O modules (MX4 or MX5-A) which provides additional thermocouple inputs or analog inputs/outputs and digital outputs.

Interchange™ Comm Control Module

MX4

- 18 thermocouple (TC)
- 1 magnetic pickup (MPU)

MX5-A

- 8 analog inputs (AI)
- 6 digital outputs (DO)
- 4 analog outputs (AO)
- 1 magnetic pickup (MPU)

Input/Output Types


Power Supply Wiring

NOTE: Maximum power ratings based on all I/O operating in the ON position with 10V supply. Typical based on 24V supply.

1.1.1 Centurion I/O Module

Requirements: Powered by 12 or 24 VDC battery system: 30W (max)

There are two screw terminal connectors for power hookup at terminals 62 and 63, labeled B+ and B- respectively.



NOTE: Run power directly from battery posts to controller power terminals when battery is the power supply.

Digital Inputs (DI)


Number of devices: 32

Device types: discrete input, normally open (N/O) or normally closed (N/C), active high/active low, non-incendive.

There is one screw terminal connector for each digital input.

Terminals 30 to 61 are DI terminals.

Green LEDs give visual indication of active input signal.




1.1.2 Analog Inputs (AI)

Number of devices: 12

Device types: analog input, (4 to 20) mA or (0 to 5) VDC, 10 bit hardware.

There is one screw terminal connector for each analog input.

Terminals 18 to 29 are AI terminals.



Thermocouple Inputs (TC)

Number of devices: 8

Device types: thermocouple input, type J or K, 12 bit hardware.


Use ungrounded thermocouples only. Grounded thermocouples are not supported. Errors in readings with grounded thermocouples can be the result of differences in grounding between devices.

Open thermocouple detection: drives terminal reading high (max of scale).

Automatic cold junction compensation is built-in.

There are two screw terminal connectors for each thermocouple.

Terminals 1 to 16 are TC terminals where white or yellow indicate positive inputs and red indicates negative inputs.



NOTE: An additional terminal connector is provided, identified as SHD, which isolates thermocouple shields. This connection, at terminal 17, is intended to be wired to an isolated bus bar for thermocouple shield wires. If shields are grounded, do not connect shields to SHD terminal. Connect all shields to SHD or to ground but never both.


Magnetic Pickup (MPU)

Number of devices: 1

Device types: magnetic pickup (MPU), (5 to 120) Vrms, (30 to 10k) Hz.

There are two screw terminal connectors for the magnetic pickup.

Terminals 64 and 65 are MPU terminals.



Digital Outputs (DO)

Number of devices: 10

Device types: discrete output, normally open (N/O) or normally closed (N/C)


- four (4) relay outputs, form C, dry contacts
- four (4) FETs, source B+ (high speed)
- two (2) FETs, sink B- (high speed)

There are three screw terminal connectors for each relay output and two screw terminal connectors for each FET output.

Terminals 70 to 81 are for the four relay terminals.

Terminals 82 to 93 are for the six FET terminals.

Green LEDs give a visual indication of active output signal.




Analog Outputs (AO)

Number of devices: 2

Device types: analog output, 4/20 mA or 0/20 mA, 16 bit hardware

There are two screw terminal connectors for each analog output.

Terminals 66 to 69 are AO terminals.



Hazardous Area Operation

The Centurion certifications:


CSA, CLASS 1, DIVISION 2, Groups B, C and D are approved.

Warning: Explosion hazard – Do not disconnect the equipment unless the power has been switched off, or the area is known to be non-hazardous.

Hardware Installation and Wiring


Mounting the Controller

The Centurion controller can be mounted vertically or horizontally on a standard DIN rail. Three clamp-type feet along the bottom of the controller attach to the DIN rail, however, rail stops are recommended to prevent sliding.




Mounting the Display


The Centurion display can be mounted in the same hole cutout of other Murphy display modules. Four screws attach the display bezel to the mounting surface.






Wiring the Display




Wiring the Controller



Wiring the Controller (continued)




WARNING • EXPLOSION HAZARD • DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NONHAZARDOUS. AVERTISSEMENT • RISQUE D'EXPLOSION • AVANT DE DECONNECTER L'EQUIPEMENT, COUPER LE COURANT OU S'ASSURER QUE L'EMPLACEMENT EST DESIGNIE NON DANGEREUX.



DRAWING NO. SHEET 3 OF 3
50-08-0047
SIZE REV
C E

Using the MV-3-C Display




The display module is a highly integrated operator interface specially programmed to complement and support the Centurion controller. The primary purpose of the display is to:

- view controller operational information
- view/edit controller operational parameters
- send commands to controller, such as stop, edit, and reset

Features

Keypad Description and Navigation



The keypad for the display has 12 keys. The following table describes the keys and their function for each of the three screen types:

- Operating status screens
- Setup screens (password required)
- Edit screens (password required)

Many of the keys have a modified action relative to the current location of the cursor and the current page being displayed.


Key	ID	Description
	HOME	<p>Operating Status Screen Allows the user to get to the first line of the current screen, if pressed again, to get to the default operating status screen.</p> <p>Set Up Screen Allows the user to get to the first line of the current screen, if pressed again, to get to the first setup screen.</p> <p>Edit Screen No associated action.</p>
	ESC/ACK	<p>Operating Status Screen Acknowledges all active messages and alarms displayed in the active alarm screen.</p> <p>Set Up Screen Exit Setup mode.</p> <p>Edit Screen Exit without saving changes to the current configuration.</p>

Key	ID	Description
	Fn (Function Key)	<p>Operating Status Screen Enter "Function mode" and display a dialog box with additional available functions. Automatically cancels upon moving to the next mode, or if no subsequent function is chosen within five seconds.</p> <p>Set Up Screen No associated action.</p> <p>Edit Screen No associated action.</p>
	SETUP/ENTER	<p>Operating Status Screen Enter Setup Mode.</p> <p>Set Up Screen Enter Edit mode or Sub-menu.</p> <p>Edit Screen Accept and save changes made to a current parameter before exiting edit mode.</p>
	RESET	<p>Operating Status Screen Reset any active timers and alarms/faults.</p> <p>Set Up Screen No associated action.</p> <p>Edit Screen No associated action.</p>
	RUN/STOP	<p>Operating Status Screen Initiate or cancel a start sequence.</p> <p>Set Up Screen Cancel a start sequence.</p> <p>Edit Screen Cancel a start sequence.</p>
	ARROW UP	<p>Operating Status Screen Scroll up one line. Automatically repeats if held down continuously until reaching the first line. For history screens, scrolls up one history (for example: shutdown or event).</p> <p>Set Up Screen Scroll up one line. Automatically repeats if held down continuously until reaching the first line.</p> <p>Edit Screen Increase the digit selected by the cursor (from 0 to 9). The user will not be allowed to increase the selected digit if it would result in exceeding range limits. Toggle the value in a list of options if editing a non-numeric value.</p>

Key	ID	Description
	ARROW DOWN	<p>Operating Status Screen Scroll down one line. Automatically repeats if held down continuously until reaching the final line. For history screens, scrolls down one history (i.e. shutdown or event).</p> <p>Set Up Screen Scroll down one line. Automatically repeats if held down continuously until reaching the final line.</p> <p>Edit Screen Decrease the digit selected by the cursor (from 0 to 9). The user will not be allowed to decrease the selected digit if it would result in exceeding range limits. Toggle the value in a list of options if editing a non-numeric value.</p>
	ARROW LEFT	<p>Operating Status Screen Display previous screen. Automatically repeats if held down continuously until reaching the first screen.</p> <p>Set Up Screen Display previous screen. This key has no action when in a sub-menu.</p> <p>Edit Screen Move the cursor left one position when a numeric value is displayed.</p>
	ARROW RIGHT	<p>Operating Status Screen Display next screen. Automatically repeats if held down continuously until reaching the final screen.</p> <p>Set Up Screen Display next screen. This key has no action when in a sub-menu.</p> <p>Edit Screen Move the cursor right one position when a numeric value is displayed.</p>
	TEST	<p>Operating Status Screen Enter test mode and start test timer. This is not applicable in shutdown mode.</p> <p>Set Up Screen No associated action.</p> <p>Edit Screen No associated action.</p>
	TIMER "0"	<p>Operating Status Screen Zero displayed timer (global timers, state timers, etc.)</p> <p>Set Up Screen No associated action.</p> <p>Edit Screen No associated action.</p>

Display Context


The graphic LCD displays are organized around operating status screens and setup screens. The actual number of status screens will be related to the number configured for the controller. Operating status screens of the Line By Line type have seven (7) lines visible at a time. Setup screens have five (5) lines visible at a time. Up and down navigation arrows indicate that more lines are available on the page. Navigation between screens is accomplished by pressing the left or right arrow keys.



NOTE: LEDs on the keypad overlay are used to indicate status also. The AMBER LED (left corner) indicates active alarms. The RED LED (right corner) indicates a shutdown.

Numeric Data Entry

The Centurion display allows individual editing of each position of the desired number. This is accomplished by entering the edit mode and using the UP/DOWN arrow keys **(1)** to adjust the number above the blinking cursor between 0 and 9. To edit another position, simply use the LEFT/RIGHT **(2)** arrow keys to move the cursor to that position and repeat the edit process until the desired number is displayed.



In this way, values are “built” rather than “scrolled” through. Some digits may not be allowed to increase if it would result in exceeding range limits. Values which can be positive or negative will have a sign (\pm) to the left of the number. To change the sign value simply move the cursor to the sign using the LEFT arrow key and “toggle” between + and – using the UP and DOWN arrow keys. If the range of the value will exceed range limits the sign may not be allowed to change. In this case, try reducing the number by decreasing the left most digit by one or more and attempt to change the sign again.

Non-numeric Data Entry

In some instances, a word rather than a value is represented in the Edit Mode. This works like the sign value as an ON/OFF or YES/NO prompt where the value is “toggled” between choices using the UP/DOWN arrow keys. The value is not active in the controller until the ENTER key has been pressed to send the value to the controller. Pressing the ESC key will discard any changes and keep the original value prior to entering the Edit Mode.

NOTE: A select few menu parameters change in real-time when the value is changed. These will be noted in this document.

Operational Screens

The display offers a number of operational displays used to for indication of the current values for the signals monitored by the system. On the Operating Status screens, the two bottom lines display the state, hours, mode and active timer status. This information is key to understanding the “status” of the controller.

Mode refers to the Operating Mode of the controller and can be LOCAL or REMOTE. Depending on the configuration active in the controller, the operation may differ depending on what Mode the controller is currently displaying.

NOTE: The Mode can be changed by pressing certain keys, if the configuration allows for REMOTE mode.

Pressing RESET or RUN/STOP is a Local function and will change the Mode to Local if it is in REMOTE.

Pressing Fn before pressing RESET or RUN/STOP is a REMOTE function and will change the Mode to REMOTE if it is in LOCAL.

Default Operating Screen

After turning on the power, the user will view the Murphy logo screen for two seconds then switch to the default operating screen configured for the system. The Centurion Configuration Tool software allows users to configure up to nine (9) screens with controller input signal groupings. Possible custom screen types that may have been configured as a default operating screen, or which may be also displayed, include:

- a) "Custom Line by Line" allows process data to be displayed in a list format with description and value.
- b) "Custom Gage" allows user to display four (4) most important pieces of data on a 2 x 2 table in larger font.
- c) "Custom PID" up to 6 PID screens.

For more information on configuring the optional screens through the Centurion Configuration Tool, please refer to the Configuration Tool Quick Start Guide.

Murphy Logo Screen



The Murphy logo is the first screen in the sequence of display screens and can be viewed by holding down the left arrow until scrolling left ceases.

Corporate and Configuration Information Screen

```
MURPHY - Mview
WWW.FWMURPHY.COM
(918) 317-4100

JOB# 50331234
CHECKSUM:                3407H
29 MAY 13  15:02:39
```

Following the Murphy Logo screen is the Enovation Controls corporate contact information which also lists configuration name, checksum, and date/timestamp for the configuration loaded in the controller. Any configuration changes subsequent to the factory shipment will be indicated by a unique checksum and new date/timestamp.

Bootloader and Firmware Information Screen

```
C4-1-A
BOOTLOADER:                00.00.00
FIRMWARE:                  00.00.00
Mview - PROGRAM: 50331234
BOOTLOADER:                00.00.00
FIRMWARE:                  00.00.00
MX4
BOOTLOADER:                00.00.00
FIRMWARE:                  00.00.00
```

This screen provides information to Enovation Control's Technical Support staff which lists the bootloader and firmware versions for the core module, the MView display, and the expansion module (if used).

Digital Input Status

DIGITAL INPUT STATUS									
X= CLOSED/ON					O=OPEN/OFF				
1	X	0	0	0	0	0	0	0	8
9	0	0	0	0	0	0	0	0	16
17	X	0	0	0	0	0	0	0	24
25	0	0	0	0	0	0	0	0	32
DIGITAL OUTPUT STATUS									
1	X	0	0	0	0	0	0	0	8
9	0	0	0	0	0	0	0	0	16
NO ALARMS									

The user can see the state of each digital input/output in a table—whether it is open or closed.

O = Open

X = Closed

Shutdown History Screen

SHUTDOWN HISTORY		20
MX4 COM FAILURE	15:31:22	1
LOST C OIL PRS XMTR	12:18:39	2
COMPRESSOR OIL LVL LOLO	12:17:24	3
HI COMPRESS OIL TMP	10:12:00	4
NO ALARMS		

The history of the last 20 shutdowns is displayed on this screen, with the most recent at the top of the list and the oldest at the bottom.

Each event is displayed with the shutdown label on one line and the hour meter reading on the following line. Pressing the up/down arrows will scroll up/down one shutdown at a time rather than one line at a time.

The number displayed in the top right corner indicates how many entries are in the list.. The newest shutdown will always be number one and it will push the older shutdowns further down the list.

Shutdown Snapshot

SHUTDOWN SNAPSHOT	
ENGINE SPEED	500 RPM
SUCTION PRESS.	35.3 PSI
DISCHARGE PRESS.	265 PSI
COMP. OIL PRESS.	74 PSI
ENG. OIL TEMP.	125 F
COMP. OIL TEMP	105 F
DISC. TEMPERATURE	35.3 PSI
COOLER TEMPERATURE	35.3 PSI
NO ALARMS	

The shutdown snapshot screen is a capture of the values displayed on the Line-by-Line custom screen at the time of a Fault SD or ESD event. These values will be retained and display on the shutdown snapshot screen until the next Fault SD or ESD event occurs. An asterisk displayed instead of a value indicates the shutdown snapshot has not captured any data.

NOTE: Only the first two Line-by-Line screens configured will be captured. If no Line-by-Line custom screens are configured, the shutdown snapshot will not function.

Event History Screen

EVENT HISTORY		32
MX4 COM FAILURE	15:31:22	1
LOST C OIL PRS XMTR	12:18:39	2
RESET	12:18:24	3
COMPRESSOR OIL LVL LOLO	12:17:24	4
NO ALARMS		


The history of the last 32 events is displayed on this screen, with the most recent at the top of the list and the oldest at the bottom.

The number displayed in the top right corner indicates how many entries are in the list.

Events include shutdowns, starts, stops, resets, etc.

The user easily can view the events (alarms, etc.) logged before and after a shutdown.

Active Alarms Screen




All active alarms and warnings will be displayed on this screen.

Unacknowledged alarms will be preceded by an asterisk and acknowledged alarms will clear the asterisk.

Pressing ACK on this screen will acknowledge all active alarms.

The top right corner will indicate the number of alarms and which line the cursor is currently on (Example: 3/10 indicates 10 alarms and the cursor is on line 3 of the list). A maximum of twenty (20) active alarms will be displayed.

NOTE: Alarms are warnings based on setpoints and/or digital inputs which are separate from shutdowns.



Alarm / Shutdown Banner

This screen shows the alarm / shutdown annunciation as it will appear on most Operating Status screens.

The message(s) will be visible at the bottom line of the status screen area and then briefly clear once a second.

This will continue until alarms are acknowledged and/or shutdowns are cleared.

If there is more than one unacknowledged alarm active, each alarm will be displayed for one second each until acknowledged.

Pressing the Fn key followed by the ACK key will switch to the active alarms screen.

Gage Display

SUCTION PRS -0.1 PSI	STG1 DISC P 60 PSI
STG2 DISC P 130 PSI	STG3 DISC P 270 PSI
LOCAL ▲	1.9H
RUN LOADED ▼	TIMER = 9
NO ALARMS	

This is an example of a custom gage display.

This display provides larger characters for easier viewing as well as a means to prominently display items of interest.

Line-By-Line

ENGINE SPEED	500 RPM
SUCTION PRESS.	35.3 PSI
DISCHARGE PRESS.	265 PSI
COMP. OIL PRESS.	74 PSI
ENG. OIL TEMP.	125 F
COMP. OIL TEMP	105 F
DISC. TEMPERATURE	35.3 PSI
LOCAL ▲	1.9H
RUN LOADED ▼	TIMER = 9
NO ALARMS	

This is an example of a custom line-by-line status screen.

If the parameters do not fit in the viewable area of the screen, up/down arrow icons at the bottom of the screen indicate the ability to scroll up or down to see additional parameters.


Custom PID Screen

SETPOINT	3.0 PSI
<input type="text"/>	10 %
LINE PRESSURE	2.8 PSI
<input type="text"/>	9 %
CONTROL OUTPUT	
<input type="text"/>	80 %
SUCTION PID	
LOCAL	1.9H
RUN LOADED	TIMER = 9
NO ALARMS	

The user may choose to display any configured PID functions in this convenient format. The control output will be displayed as a percentage of the range.

Setup Screens and Menus

The setup screens provide access to system parameters. These settings can be modified with appropriate password access. The two bottom lines in the setup screens display navigation and command options available such as READ ONLY, ENTER – EDIT, ENTER – ACCEPT, ESC – CANCEL, MORE MENUS, and ENTER - SUBMENU.



Password Screen

Some settings are password protected, including the setup screens.

This is the first screen seen when the SETUP/ENTER key is pressed.

The password need only be entered once during any editing session. The password is timed-out automatically three minutes after the editing session is exited..


The cursor begins at the last digit on the right. The user can adjust the value of each digit with the up/down arrows while the left/right arrows are used to select the digit to edit.

Passwords are assigned using the Centurion Configuration Tool software. Each digit can range from zero to nine (except the first digit on the left).

The user will not be allowed to increase the selected digit if it would result in exceeding range limits.

NOTE: If the Standard password is not zero and a password of all zeroes is entered, the user will have “view only” access.

NOTE: After 3 minutes without activity, the keypad returns the default operational screen and a password must be re-entered to return to the setup and edit menus.



ENTER PASSWORD FOR SETUP MENUS	
00000	▶
	ENTER - ACCEPT ESC - CANCEL

There are two separate levels of passwords to accommodate several security needs:

“Standard” password – Allows access to every feature except the super user menu. Valid standard passwords can be zero or any number between 100 and 65535. If the standard password is set to zero, the result is that anyone can have read/write access to setup menus.

SUPER USER SETUP	L1
RESET FAULT HISTORY	◀
RESET EVENT HISTORY	
USER CODE :	
SUPER USER CODE :	
DISPLAY FACTORY SETUP	
	NO ◀
2 CHOICES	
◀▶	ENTER - EDIT
	MORE MENUS

“Super User” password – Adds the super user menu to the standard menus. Valid super user passwords can be in the range of 100 to 65535. The super user password cannot be the same as the standard password and cannot be set to zero.

Setpoints Setup

Up to 128 setpoints may be configured in the system by the Centurion Configuration Tool software. The values for the setpoints are user editable.

Setpoints are data entries used in greater than or less than comparisons of signals based on variable input types such as MPU, analog, or thermocouples. The setpoint is a threshold, exception or any other out-of-limit event that can be configured to take a required action. Multiple setpoints are often applied to a process and they may be configured as often as needed to meet changing conditions.

Common alarm and shutdown setpoints a user might have configured include:

- High shutdown (High-High)
- High warning (High)
- Open warning (Open or Fail)
- Low warning (Low)
- Low shutdown (Low-Low)

SETPOINTS SETUP	L1
SETPOINTS 1-16	◀
DEBOUNCE TIMERS 1-16	
SETPOINTS 17-32	
DEBOUNCE TIMERS 17-32	
SETPOINTS 33-48	
	◀
ENTER - SUBMENU	
MORE MENUS	

To edit a configured setpoint:

a) Select the setpoint group submenu that requires editing. The configuration listing provided will include a listing of all setpoints and their respective number.

b) Assign numeric threshold that if crossed, triggers the setpoint.

b) Adjust the sign of the threshold value as plus (+) or minus (-) by moving the cursor to the sign symbol position and use the up and down keys to toggle the sign.

NOTE: Setpoints 1-16 and 17-32 can also have debounce timing applied as a signal filter. The setpoint comparison must be sustained through this time delay to see the setpoint as “true”. This time filter can be used to “ignore” transients of short duration.

SETPOINTS 1-16	L1
LO SUCTION PRS	◀
HI SUCTION PRS	
LO STG1 DISC P	
HI STG1 DISC P	
LO STG2 DISC P	
	0.0 ◀
MIN -3276.7	MAX 3276.7
ENTER - EDIT	
MORE MENUS	

General Timer Setup

GENERAL TIMER SETUP	L1
B1 TIMER	◀
B2 TIMER	
C2 TIMER	
S1 TIMER	
S2 TIMER	
SECONDS	30 ◀
MIN 0	MAX 999
ENTER - SUBMENU	
MORE MENUS	

User may edit all general purpose timers. Generally, global timers affect driver operation. They also help define an event arming condition.

B1: All event types can be associated with, and locked out by, a Bx timer. B1 is the first global timer used for delaying an event condition detection. The timer starts and runs in the running States of the controller operation. B1 is also known as the “Lockout Timer”, start bypass or start/run timer.

B2: The second global timer used for delaying event condition detection. B2 is also known as a secondary “Lockout Timer.”

C2: The delay after reaching the “Run Loaded State” that allows Class C2 events to arm. Class C events require a clear reading sustained for 2 seconds to arm. This time used as stabilization time for any manual loading to be operated and the load to stabilize on the machine.

S1-4: Users have up to four (4) options to assign additional special global timers to signals. The Sx timers begin concurrently with the Bx timers.

No Flow: The global delay used for delaying the triggering of a no flow event. This global no flow timer is enabled after B1 expires, and begins timing after any of the pulse transition times configured in the digital input dialog expires.

Test: Time given to allow for maintenance testing of end devices without triggering a fault or shutdown condition. The timer initiates when switched to test mode.

Ignition On Delay: Time delay before the assigned ignition output turns on. This is typically used to delay ignition until engine has started cranking (also known as a purge delay).

Fuel On Delay: Time delay before the assigned fuel valve output is turned on. This is typically used to delay fuel until ignition has been turned on.

Ignition Off Delay: Time delay before the assigned ignition output turns off. This is typically used to burn remaining fuel vapors after the fuel valve is turned off.

State Timer Setup

STATE TIMER SETUP	L1
PANEL RDY	◀
START DLY	
PREHEAT	
PRELUBE	
ESM START	
SECONDS	0 ▶
MIN 0	MAX 65535
◀▶	READ ONLY
	MORE MENUS

User may edit all state timers if marked in use. State 1 – Panel Ready and 23 – Shutdown are Read Only and cannot be edited. The states used for a given application are configured by the Centurion Configuration Tool software.

When the state timeout value is reached, the state logic proceeds to the next "In Use" state. A state timeout may also be configured to trigger a fault event, for example a prelube permissive failure, however the operation depends on the configuration.

Maintenance Timer Setup

MAINTENANCE TIMER SETUP	L1
Oil Change	◀
MT_2	
MT_3	
MT_4	
MT_5	
	◀
 	ENTER - SUBMENU MORE MENUS

The user may access and edit the ten (10) maintenance duration presets, and time remaining settings, if used by the configuration. All maintenance timer units are in hours.

NOTE: These are configured by the Centurion configuration tool software, however must be manually initialized in Centurion display.

Oil Change	L1
TIMER DURATION	◀
TIME REMAINING	
HOURS	120 ◀
MIN 0	MAX 9999
	ENTER - EDIT MORE MENUS

When the timer time remaining reaches 0 hours, an event may be configured to alarm, or generate a message event that maintenance is required.

Start / Restart Maintenance Timers

To initialize or restart the timers, position cursor on TIME REMAINING and press the reset key.

Control Loop Setup

Users may view and edit up to six (6) configured control loops. The settings on this page will differ depending on the type of control configured for the system. The control loops all operate on the principle of a 0-100% calculated output, with special considerations for the Digital loop types. Four control loop types are possible.

- a) Analog and Digital types use a closed loop PID calculation to calculate the output value, in which a process variable is maintained at a desired setpoint with the PID generating a 0-100% corrective action to the process. The ultimate goal of the PID is to reduce the error to zero effectively maintaining the control setpoint (e.g. speed, load, pressure). PID calculations attempt to model the process being controlled by allowing tuning for the dynamics of the process based on the present (Proportional), past (Integral), and future (Derivative) error of the loop. The controller uses the ISA PID control calculation method (dependent PID) as follows:

$$\text{Out} = K_p(\text{Error} + K_i \int (\text{error})dt + K_d \times \frac{d\text{Error}}{dt})$$

- b) 2 Pulsed Digital type uses a closed loop pulse equation that calculates the “On” time for either the increase or decrease digital output based on the control error.

$$\text{Out} = (\text{error} \times \text{Proportional}) + 50\%$$

The ultimate goal of the loop is to reduce the error to zero effectively maintaining the control setpoint (e.g. speed, load, pressure). The control algorithm is centered at 50% output. At 50% output, neither digital output is on. The control loop will either add to 50% or subtract from 50% to pulse the increase or the decrease outputs. Larger deviation from 50% will result in longer output pulses.

- c) 4 Step Load turns on 4 digital outputs in a 4 step staggered loading scheme with time delays in between the loading steps. The ultimate goal of the loop is to reduce the error to zero while maintaining the control setpoint (e.g. speed, load, pressure). The control loop will turn on the outputs in succession and the 0-100% control value will step up from 0 to 20%, 40%, 60% and 80% as the time delays expire. If the deadband is reached, the time delays will reset and no change in control will occur.
- d) Open Loop calculates an analog output value using a linear scaling based on a feedback input. In this case there is no closed feedback, and no setpoint to maintain. There are 2 coordinates specified in engineering units for the process being controlled, one for minimum % output, and one for maximum % output. A linear scaling function will be applied using these 2 values to range the output between the specified minimum and maximum % settings.
- e) Common setpoints to Analog/Digital, 2 Pulsed Digital, and 4 Step Load loop types. Open Loop Ramp loop type shares only those setpoints marked with (*).

1. Auto/Manual Mode*: Set the loop to Auto to enable the control. Set to Manual to allow user entry for the control output as a 0.00-100.00% value.

2. Setpoint: Assign the desired value that is to be maintained by the loop. Depending on configuration this may be a variable setpoint based on analog input, not user editable from the display.
3. Deadband: Assign a value around the setpoint during which the loop will not take any corrective action.
4. Minimum Output*: Set the minimum limit on the calculated value during auto control
5. Maximum Output*: Set the maximum limit on the calculated value during auto control.
6. Loop Update time: Loop calculation frequency. This time should be set no shorter than the update rate for the feedback reading.
7. Max Rate Of Decrease/Increase: This is a maximum slew rate setting for the output change per loop update time.
8. Set Output % (Manual) *: This is the control output value data entry for manual mode.
9. Override 1-3 Ramp time*: Set the interval used to modify the calculated output when a configured override signal is active.
10. Override 1-3 Change %: Set the amount of change either positive or negative, required to the calculated output while a configured override signal is active.

NOTE: Override settings are only used when there is a configuration for overriding the control loop with another process variable. Each control loop may have up to 3 control loop override settings based on setpoint or digital inputs signals going true and false.

11. Display Loop Bar Graph*: Set to yes to show a bar graph page for the control loop as it operates.
12. Ref Line Select*: Setting to select any value to be shown on the Display Loop Bar Graph in addition to the setpoint, feedback, and control output values. This setting is useful for showing the process value of a different analog, thermocouple, or speed input that may be affected by changes to the PID output. Select from available analog, thermocouple, or speed inputs or None to disable the Reference Line Select feature.

CONTROL LOOP SETUP	L1
RECYCLE VALVE	◀
ESM REM SPEED	
CTL_3	
CTL_4	
CTL_5	
	◀
 ENTER - SUBMENU MORE MENUS	

RECYCLE VALVE	L1
AUTO/MANUAL MODE	◀
SETPOINT	
DEADBAND	
PROPORTIONAL	
INTEGRAL %/SECONDS	
	AUTO ◀
2 CHOICES	
 ENTER - EDIT MORE MENUS	

a) Analog/Digital PID loop specific setpoints:

1. Proportional: Proportional gain tuning for the control process.

2. Integral: Integral time constant (%/sec) tuning for the control process. Integration adjusts the output value on the accumulated of the error over time.

3. Derivative: Derivative time (% seconds) tuning for the control process. Derivative is adjusts the output value based on the rate of change of the error over time.

b) 2 Pulse Digital loop specific setpoints:

1. Proportional: Proportional number multiplied by the error, to result in the on time for the pulse. Larger numbers here will result in longer on times for the pulse at a given error.

2. Inc/Dec Max On Time 1/20s: Set the maximum on times for the calculated on time of the pulse. This is a clipping value applied to the calculated result.

3. Inc/Dec Sample Time 1/20s: Set the fixed off time between pulses. This should be set long enough to allow the results of the previous pulse to have effect on the process before a new pulse is generated.

4. Inc/Dec Xover On Time 1/20s: Set the fixed on pulse that is generated when the control changes from increasing to decreasing or vice versa. This is optional, and typically used to prime hydraulic controls to reverse direction.

5 Inc/Dec Xover Off Time 1/20s: Set the fixed off pulse that is generated when the control changes from increasing to decreasing or vice versa. This is optional, and typically used to prime hydraulic controls to reverse direction.

c) 4 Step Load loop specific setpoints:

1. Inc/Dec Step Time Sec: These is the time delay between loading steps turning on or off as the loop attempts to reach the setpoint.

d) Open Loop Ramp specific setpoints:

1. Input For Min % Out: This is the engineering unit value for the loop input that will cause the Minimum % output to be calculated. This value will be a pressure, temperature, RPM or other variable signal that controls the output directly.

2. Input For Max % Out: This is the engineering unit value for the loop input that will cause the Maximum % output to be calculated. This value will be a pressure, temperature, RPM or other variable signal that controls the output directly.

Miscellaneous

MISCELLANEOUS SETUP	L1
CORE FLYWHEEL TEETH	◀
EXP FLYWHEEL TEETH	
HOUR METER	
CRANK ATTEMPTS	
CTLR PORT 2 MODE	
	0 ▶
MIN 0	MAX 32767
 ENTER - EDIT MORE MENUS	

a) Core/Expansion Flywheel Teeth:

Engine: Define a value for flywheel teeth (Pulses Per Revolution) used to calculate RPM.

Motor: When setpoint set to zero "0", crank attempts becomes # of starts per hour for electric motor applications.

b) Hour Meter (0.0-999999.9): Reset or preset the internal hour meter.

c) Crank Attempts (1-16):

Engine: Define a value for number of crank attempts after which an over-crank sequence signal will be triggered in the system. If the configuration includes an Overcrank event, it will be triggered by this signal.

Motor: Define a value for number of motor start attempts per hour after which an excess start attempts will be triggered in the system. If the configuration includes an Overcrank/Excess starts event, it will be triggered by this signal.

d) Controller RTU Address (1-247): Provide the value for the Modbus address for port 1 on the C4-1 board. The factory default is 1.

NOTE: "Ctrl Port 1 (on the C4-1) settings are reserved by the configuration for the connected display."

e) Ctrl Port 2 Mode: Select communication port 2 as RS232, or RS485.

f) Ctrl Port 2 Reply Delay (0-65535): Optional time delay for the Modbus response.

g) Ctrl Port 2 Baud Rate: Select appropriate transmission baud rate (9600; 19200; 38400; 57600; 115200)

NOTE: All ports use no parity, 8 data bits, 1 stop bit:

WARNING: The following cold temperature offset values should only be adjusted by personnel with a full working knowledge of the Centurion in conjunction with calibrated reference equipment.

h) Core CJ#1/2 Temp Offset: Enter a non-zero value for temperature adjustment in tenths of a degree to offset the temperature readings. CJ#1 sensor is used for thermocouple inputs 1-4. CJ#2 sensor is used for thermocouple inputs 5-8.

i) Exp CJ#1/2 Temp Offset: Enter a non-zero value for temperature adjustment in tenths of a degree to offset the temperature

readings. CJ#1 sensor is used for MX4 thermocouple inputs 1-9. CJ#2 sensor is used for thermocouple inputs 10-19.

Digital Input Setup

DIGITAL INPUT SETUP	L1
PANEL ESD	◀
ESM SHUTDOWN	
SPARE DI03	
LB LUBE NOFLOW	
RB LUBE NOFLOW	
	▶
ENTER - SUBMENU	
MORE MENUS	

PANEL ESD	L1
SIGNAL TYPE	◀
SIGNAL FILTER	
FILTER TIMING	
RAW STATUS	
	N/O ▶
2 CHOICES	
ENTER - EDIT	
MORE MENUS	

For all configured digital inputs, the user may edit:

a) Signal Type - Select normally open (N/O) or normally closed (N/C).

b) Signal Filter - Select None to disable filter function for the digital input. This will not disable the digital input for normal operation.

Select Pulse for lubricator divider blocks with a proximity switch output.

Select DB to debounce or delay input detection for unstable inputs such as surge tank level.

c) Filter Timing - Delay time in seconds for the selected filter type.

For Pulse, this delay is the transition time for the lubricator divider block to cycle.

For DB, this is the duration the digital input must remain either ON or OFF before the input will be recognized and accepted as ON or OFF by the sequence. If the input does not remain ON or OFF for the duration of the delay, the timer will reset.

d) Total Pulsed - Total number of pulses counted when the filter type is set to Pulse. The value is expressed in hundreds of pulses; a displayed reading of 1 is equal to 100 pulses. (*only visible on pulse filter types)

Pulse Input Status

PULSE INPUT STATUS	L1
CYCLE TIME - INPUT #1	◀
CYCLE TIME - INPUT #2	
CYCLE TIME - INPUT #3	
CYCLE TIME - INPUT #4	
CYCLE TIME - INPUT #5	
PREV 0	CURR 0 ▶
CYCLE TIME (SEC)	
◀▶ READ ONLY MORE MENUS	

Pulsed inputs are designed to accept a cycling digital output from a lubricator divider block; typically from a general purpose proximity switch.

The user may view information about the pulsed inputs. If a digital input is designated for use as a pulsed input, it will display how much time elapsed before the last transition, and how much time has elapsed since that transition. If the input is not designated as a pulsed input, there will be zeros displayed. Both have a maximum value of 999.

Digital Output Setup

DIGITAL OUTPUT SETUP	L1
RUN STATUS	◀
FAULT SD INDIC	
CORE_DO_3	
CORE_DO_4	
ESM REM SPD EN	
◀	
◀▶ ENTER - SUBMENU MORE MENUS	
RUN STATUS	L1
ACTION	◀
RAW STATUS	
N/O ▶	
2 CHOICES	
▼ ENTER - EDIT MORE MENUS	

Digital output: For all configured digital outputs, the user may edit:

a) Action - Select normally open (N/O) or normally closed (N/C). Normally closed inverts the logic associated with the output if desired.

To force the output, toggling the NO to NC will cause it to invert state.

Analog Inputs Setup

ANALOG INPUTS SETUP	L1
SUCTION PRS	◀
STG1 DISC P	
STG2 DISC P	
STG3 DISC P	
CORE_AI_5	
	◀
  ENTER - SUBMENU MORE MENUS	

SUCTION PRS	L1
SCALED MINIMUM	◀
SCALED MAXIMUM	
MOVING AVERAGE SAMPLES	
RAW COUNT OFFSET	
RAW COUNT MAX	
	0.0 ◀
MIN -3276.7	MAX 3276.7
 ENTER - EDIT MORE MENUS	

For all configured analog input devices, the user may edit:

a) Scaled Minimum - Minimum engineering scale for the input when the raw counts are at the raw count offset reading.
Example: 0 PSI for a 0-100 PSI transmitter.

b) Scaled Maximum - Maximum engineering scale for the input when the raw counts are at the raw count offset + raw count max (total raw counts).
Example: 100 PSI for a 0-100 PSI transmitter.

NOTE: To calibrate an analog input, change the raw offset and max settings, the scaled minimum and maximum settings should match the engineering unit range for the device:

c) Moving Average Samples. (1, 2, 4).
Apply averaging filter to the input.

d) Raw Count Offset. Set the lowest raw analog input counts seen from the device.

e) Raw Count Max. Set the highest raw analog input counts span seen from the device. This number is added to the raw count offset to equal the actual raw count reading.

The user can view the raw counts of the analog inputs to calibrate the input by adjusting the offset and max raw count readings.

NOTE: Typical approximate raw readings for 4-20mA input:

4mA = 147 counts

20mA = 733 counts (147+586)

Analog Outputs Setup

ANALOG OUTPUTS SETUP	L1
RECYCLE VALVE	◀
ESM REM SPEED	
EXP_A0_1	
EXP_A0_2	
EXP_A0_3	
	◀
 ENTER - SUBMENU MORE MENUS	

RECYCLE VALVE	L1
ANALOG OUTPUT	◀
SCALED MINIMUM	
SCALED MAXIMUM	
	0.00 ◀
MIN -327.67	MAX 327.67
 ENTER - EDIT MORE MENUS	

Centurion analog output hardware is ranged to 4-20mA. The actual analog output % will be shown for each channel.


For all configured analog output devices, the user may edit:

a) Minimum - Minimum % output. In most cases, 0% addresses a typical application (4mA).

b) Maximum – Maximum % output. In most cases, 100% (100.00) addresses a typical application (20mA).

To force the output, enter a value from 0.00% = 4mA to 100.00%. = 20mA in the minimum setting.

Temperature Inputs Setup

TEMPERATURE INPUTS SETUP	L1
DISC CYL1 T	◀
DISC CYL2 T	
DISC CYL3 T	
DISC CYL4 T	
COMP OIL TMP	
	◀
  ENTER - SUBMENU MORE MENUS	


The actual thermocouple reading in degrees will be shown per channel.

For all configured thermocouple devices, the user may edit:

- Thermocouple Type.** Identify whether the input type should be set to J or K.
- Thermocouple Offset.** Assign an optional thermocouple reading offset value.

DISC CYL1 T	L1
THERMOCOUPLE TYPE	◀
OFFSET	
	4095 ◀
MIN -32767	MAX 32767
 READ ONLY MORE MENUS	

Display Board Status

DISPLAY BOARD STATUS	L1
BACKLIGHT	◀
DSP CONTRAST	
BATTERY VOLTS	
TEMPERATURE	
HEATER PWM %	
	70 ◀
MIN 0	MAX 100
  ENTER - EDIT MORE MENUS	

The user may view diagnostic information that reflects the operating conditions of the display only.

- Backlight** - Adjust the value from 0 (OFF) to 100 (Full ON) percent to modify the intensity of the backlight. NOTE: This value changes in real-time as adjustment are being made. Pressing ESC will NOT discard the changes made to this value. A password is not required to change this setting.

- DSP Contrast** - Adjust the value from 150 to 180 to modify the LCD contrast. As the

number is increased the active pixels of the display will become darker. Increasing the contrast too much may also increase the darkness of the background. NOTE: This value changes in real-time as adjustment are being made. Pressing ESC will NOT discard the changes made to this value. A password is not required to change this setting.

c) Battery Volts - Indicates internal voltage measurement of display VDC input.

d) Temperature - Indicates internal temperature measurement of display. This is used primarily to monitor ambient temperature to operate LCD heater.

e) Heater PWM % - Refers to the LCD heater which only operates in cold temperature conditions.

f) Reset Source - Indicates the cause of the last reset. Possible causes include external reset, power-up, brown-out and watch dog.

Communication Status

COMMUNICATION STATUS	L1
485-1 RECEIVE COUNT	◀
485-1 TRANSMIT COUNT	
485-1 FRAME ERRORS	
485-1 HW OVERRUNS	
485-1 MB EXCEPTIONS	
	0 ◀
 READ ONLY MORE MENUS	

Users may view the statistics for both of the display unit serial ports, including Modbus requests and responses.

Note: **a), b), c), d)** and **e)** settings are all common to the 485-1, 232 and 485-2 ports.

a) Receive Count – counter for the number of received bytes on the port.

b) Transmit Count - counter for the number of transmitted bytes on the port.

c) Frame Errors – counter for the number of detected packet framing errors

d) Overruns – internal diagnostic counter for factory use.

e) Modbus Exceptions/No Response – internal diagnostic counters for the Modbus traffic.

f) Clear Statistics – Press ENTER key to reset all counters.

g) Modbus Register –Modbus register viewer that allows access to any Modbus register from the controller.

Super User Menu

SUPER USER SETUP	L1
RESET FAULT HISTORY	◀
RESET EVENT HISTORY	
USER CODE :	
SUPER USER CODE :	
DISPLAY FACTORY SETUP	
	NO ◀
2 CHOICES	
◀▶	ENTER - EDIT MORE MENUS

The super user menu will only be visible if the super user password has been entered.

a) Reset Fault History: Set to Yes to clear the Shutdown History screen.

b) Reset Event History: Set to Yes to clear the Event History screen.

NOTE: The Reset History commands do not permanently switch to Yes when entered, but instead toggle back to No after sending the command to the controller.

c) User Code: Press ENTER key to change the Standard User Password. The current password is displayed and can be changed.

d) Superuser Code: Press the ENTER key to change the Superuser Password. The current password is displayed and can be changed.

e) Display – Factory Setups: Set to Yes to overwrite all settings changed through the display to the original configuration settings from the last downloaded configuration file.

NOTE: The Restore Defaults command does not permanently switch to Yes when entered, but instead toggles back to No after sending the command to the controller.

f) Centurion Factory Setup

- g) 485 – 1 / 2: FS BIAS
- 485 – 1 / 2: Term RES
- 485 – 1 / 2: Modbus Address
- 485 – 1 / 2: Baud Rate
- 485 – 1 / 2: Mode

h) 232 – Modbus Address
232 – Baud Rate
232 – Mode

i) CAN0 / 1: Address
CAN0 / 1: Arbitrary
CAN0 / 1: Term Res
Lost CAN0 DLY

j) Backlight - Adjust the value from 0 (OFF) to 100 (Full ON) percent to modify the intensity of the backlight. NOTE: This value changes in real-time as adjustments are being made. Pressing ESC will NOT discard the changes made to this value.

k) DSP Contrast - Adjust the value from 150 to 180 to modify the LCD contrast. As the number is increased the active pixels of the display will become darker. Increasing the contrast too much may also increase the darkness of the background. NOTE: This value changes in real-time as adjustment are being made. Pressing ESC will NOT discard the changes made to this value.

l) Key Press Counter

m) Outputs: 1 – 2
LED: 1 – 2
Outputs: 01 – 10
Outputs: 11 - 20
Outputs: 21 – 30
(Force menus for display outputs including LED's located on the front of the display).

Additional Navigational Aids

Function Key Menu

FUNCTION MENU (FN-EXIT)	L1
SHUTDOWN HISTORY	◀
EVENT HISTORY	
INPUT-OUTPUT STATUS	
VERSION INFORMATION	
SHUTDOWN HISTORY	◀
REMOTE: RUN - STOP - RESET	
ALARMS SCREENS - ACK	
▼ MORE MENUS	

Pressing the Function (Fn) key from any Operational screen will display the Function Menu screen momentarily to gain “quick” access to other pages.

All available function key commands will be displayed there. The user can then press a single key for the available commands.

Remote mode commands are available only while the Fn key is pressed.

If the Fn key is not followed by another key press in five seconds, function mode will time out and the screen will return to the previous screen.

Communications

C4-1 Controller Communication Ports

Port 1 (Serial) – Used for Display.

Port 1 is intended as the primary port for the local device, the display, and should be utilized for display in order for the controller and display synchronization to properly execute.

Interface: RS485/RS232 configurable. Refer to the sequence of operation to determine the actual configuration. Baud rates configurable 9600, 19200, 38400, 57600, 115200. No parity, 8 data bits, 1 stop bit.

Protocol: Modbus RTU slave

Connection: Three (3) screw terminal connectors for RS485. These are identified as A, B, and SHD. Four (4) screw terminal connectors for RS232. These are identified as RX, TX, DTR and SHD.

Port 2 (Serial) – Used for customer connection.

Interface: RS485/RS232 configurable. Refer to the sequence of operation to determine the actual configuration. Baud rates configurable 9600, 19200, 38400, 57600, 115200.

Protocol: Modbus RTU slave, Proprietary (for firmware/configuration transfer)

Connection: Three (3) screw terminal connectors for RS485. These are identified as A, B, and SHD. Three (4) screw terminal connectors for RS232. These are identified as RX, TX, DTR and SHD.

Modbus RTU Slave Address Configuration: The operator may assign a unique Modbus address to each controller (slave) unit that may be in the system. This allows the master controller to differentiate between the modules. For example, to name the controller address 21, place the shunts on LK1, LK4, and LK16 ($1 + 4 + 16 = 21$). Typically, this configuration is set to (1) by the factory. Jumper selectable to address 63.

User can gain additional addresses on Port 2 with the following process.

- If, and only if, Digital Input 30 is **NOT** “in use”, jumper DI 30 to DC-. This will provide address 64. User can then add jumpers to LK4 to continue addresses up to 127.
- If, and only if, Digital Input 31 is **NOT** “in use”, jumper DI 31 to DC-. This will provide address 128. User can then add jumper to LK4 to continue addresses up to 255. To utilize DI 31, user **MUST** have DI 30 jumper to DC- installed.

Port 2 (USB) – Used for configuration file transfers/Firmware updates

Interface: USB 1.1 compliant port capable of emulating RS232 communications via royalty-free pc driver.

Protocol/Services: Modbus RTU slave, Proprietary (for firmware/configuration transfer)

Connection: There is a USB type B connector.

Automatic selection of USB is provided when a signal is detected on the USB type B connector. Connections for RS485 and RS232 will not be enabled on port 2 when USB is connected.

Port 3 (CAN) – Used for Expansion board communication

Protocol/Services: Proprietary (binary).

Connection: There are three (3) screw terminal connectors for CAN. These are identified as HI, LOW, and SHD.

MV-3-C Display Communication Ports

RS232 – Used for Controller communication.

RS232 is intended as the primary port for the controller.

Interface: RS232. Alternately, RS485-1 may be used if the controller is configured for RS485 on Port 1.

Protocol: Modbus RTU master/ Proprietary (binary) synchronization to the C4-1 controller

Connection: Five (5) screw terminal connectors for RS232. These are identified as RX, TX, RTS, CTS, and GND.

RS485-1

RS485 is intended as the secondary port for the controller.

Protocol: Modbus RTU master/ Proprietary (binary) synchronization to the C4-1 controller

Connection: RS485-1/RS485-2 shared terminal block. RS485-1 uses A-1, B-1 and common SHD (shield).

NOTE: Shields should only be terminated on one side of the communication cable connection.

RS485-2 – (Reserved)

USB – Used for firmware updates

Interface: USB 1.1 compliant port.

Protocol/Services: Proprietary (for firmware transfer)

Connection: USB type B connector.

USB-A (Not Used)

CAN 1/2 (Not Used)

Downloading Configurations and Firmware Updates

The Centurion controller and display are configured and upgradeable through software transfers using a PC or laptop computer.

Configuration files are generated by the Centurion Configuration Tool software and provide the application specific personality to the controller and display.

Firmware defines the available set of features that can be configured in the controller and display that the configuration file uses to operate.

Enovation Controls can provide future enhancements and support changes to process requirement for customers using simple email, and obtaining the required transfer utilities from www.fwmurphy.com.

Boot Loader Power Up Mode

Boot Loader power up mode is required for configuration file transfers and firmware updates to the controller. To enter boot loader mode, connect the USB cable to the controller and a PC, and apply power to the controller. The display and third party HMI devices will not receive a response to Modbus requests while the boot loader is active. The controller application will not run, and all outputs will remain off.

An alternate way to enter Boot Loader mode is to apply power to the controller with ALL address selection jumpers for port 2 removed.

Power on the Centurion C4-1 must be cycled with the USB cable removed and at least one address selection jumper installed to resume normal operation, or run mode.

Refer to the Centurion Transfer Guide to obtain step by step instruction on file transfer operations.

There is also a bootloader mode for the display to allow for firmware changes. To enter bootloader on the MV-3-C, press and hold the RIGHT ARROW key and SETUP ENTER keys at the same time while applying power to the display. The display may be blank. Simply hit ENTER to see the bootloader screen. The RED LED on the front of the display will be blinking to indicate bootloader mode.

Modbus™ RTU Protocol

General

The Centurion configurable controller was programmed with the Modbus RTU protocol which is a system based on a “master” and “slave” relationship. The master initiates the queries or commands, and the slave responds to the query with a message or takes action based on the query.

In this case, the master is either the MV-3-C display or another Modbus client, but never both simultaneously as there can only ever be a single Modbus RTU master on a network.

As with all numeric data defined within the Modbus RTU specification, the data is limited to accepting integers (whole numbers only, no decimals). This is important whenever a decimal point is defined for analog inputs.

For example, for the controller to properly read “100.0” with an implied decimal point of 1, the user would need to enter “1000” and 1000 would be stored in the appropriate Modbus register.

The Centurion Controller has all data mapped into Modbus Holding Registers, formatted as signed 16 bit integer data*. The controller responds to Modbus Function Codes 03, 06, and 16. These represent Read Holding Registers, Preset Single Register, and Preset Multiple Register Modbus functions. (*certain data points may be bitmapped data or unsigned data and will be specified on the Modbus RTU map)

Display to Controller Data Transfer

Parameter changes made in the display are actually communicated to the Centurion controller where the logic resides. No changes made through the display affect the display configuration as the display merely reads from, and writes to the Centurion main I/O module. As such, the display can write numeric parameters to the controller.

Replacement Parts and Assemblies

C4-1 Plug Kit	(00000504)	Printed replacement terminal plugs for Centurion Main I/O module
MV-3-C Plug Kit	()	Printed replacement terminal plugs for Centurion display module.
Choke	(50000774)	Ignition noise (choke) filter

Accessories

Centurion Configuration Tool Software

The Centurion Configuration Tool software generates and modifies the properties of the system specific to the hardware connected to the controller, the sequence of operation, defined set points, timers, faults, and displays* for the Centurion system. The software includes file transfer utilities for configuration and firmware upgrades.

CD, Centurion Configuration Tool software. (50-70-2313)

*Display configuration and other settings for display are only for use with the MV-3-C Display Module.

Glossary

Analog Input	Terminals 18 to 29 are analog inputs on the Centurion Main I/O module. Accepts voltage signals within the range of (0 to 5) VDC or (0 to 24) mA and are compared to controller set points and/or displayed.
Boot Loader	Means by which the Centurion controller communicates with Centurion Configuration Tool to transfer new or updated configurations and firmware; and ensure data and configuration synchronization.
Controller Setpoints	User defines normal operating range for the controller to optimize the equipment. Setpoints can also define some other threshold, exception or event that may require action. Multiple setpoints are often applied to a process and they may be manipulated as needed to meet changing conditions.
DeadBand	The user set range at which input may fluctuate without the controller taking any action. The range may be fixed or variable.
Digital Input	Terminals 30 to 61 are the digital input channels, activated by either a ground or supply voltage level. User selects whether digital input is normally open (N/O), or normally closed (N/C). Users may also associate these inputs with transition times for indicating no-flow conditions on divider blocks.

Event	Defines the action required by the controller in response to any number of parameters. Event actions range from simple alarm message to emergency shutdown (ESD).
No-flow	Designed to protect against compressor or engine failures, the controller monitors the cycle time of lubrication system cycles and if that cycle time falls under a user assigned value, the controller will activate a defined associated action such as an alarm or shutdown.
Offset	User defined value to correct for known variance in the raw data.
Panel Ready	In states, the first logical step in start up.
Permissive	A process condition, (digital input or analog setpoint), that must be met in order for the sequence to proceed to the next state.
Signal	An electrical quantity of voltage or current that is used to represent or signify some other physical quantity such as the state of a switch (ON/OFF) or the status of a device (SHUTDOWN/OK)
Span	The difference between the full scale output and the offset as raw data.
Start Delay	A time delay function to prevent premature start up.
State	Predefined step of multiple logical steps (or states) needed to successfully start and operate a compressor.
Thermocouple	<p>A device for measuring temperature consisting of two dissimilar metals of high purity for an accurate temperature/voltage relationship. User defines whether the calibration is J or K. Terminals 1 to 17 are for thermocouple inputs.</p> <p>Type J uses Red (-) and White (+) insulation. Type K uses Red (-) and Yellow (+) insulation.</p>

Appendices

C4-1 Controller LED Description

Power LED – located next to the power connection, the LED illuminates when supply voltage is applied to the controller.

Digital Input/Output Status LEDs – each digital input/output has a status LED that illuminates when the signal is activated. The LED's are located next to the terminals.

Port 1/2 RX/TX LEDs - the serial activity LEDs blink with every transmitted or received message. RX LED is red, and blinks when a packet is received by the controller. TX LED is green, and blinks when a packet is transmitted by the controller. The LED's are located next to the serial port connections.

Port 2 USB Active LED - the LED illuminates steady when a USB cable is detected on the USB port. The LED is located to the immediate right of the USB type B port.

COP LED - Controller Operating Properly LED, the LED will flash on and off every 0.5 seconds when the controller is running the application program. When the controller is in the bootloader mode, the LED will be illuminated steady. If power is applied (Power LED illuminated) and this LED is not illuminated, contact Enovation Controls for technical support.

On the Expansion I/O Module

When the program is running properly the COP LED will flash on and off every 0.5 seconds.

MV-3-C Display Bootloader LEDs

Please be aware of the following conditions and the resulting LED appearances:

- When the unit is powered up and enters the bootloader, the RED and YELLOW LEDs are turned ON.
- If the user held the “right arrow” and “Setup Enter” keys on power up, the RED LED will flash and the YELLOW LED will be OFF.
- If the unit has an invalid application or needs to sync (Mview Replacement only), the RED LED is OFF and the YELLOW LED will flash.
- When the bootloader exits to run the application, the RED and YELLOW LEDs are turned OFF.

MV-3-C Display LED Description

All Ports RX/TX LED's - The serial activity LED's blink with every transmitted or received message. RX LED blinks when a packet is received by the display. TX LED blinks when a packet is transmitted by the display. The LED's are located next to the serial port connections.

Modbus RTU Register Map

All data is signed 16 bit integer unless otherwise noted.

- See www.fwmurphy.com for Centurion C4 Modbus map or contact factory representative.

-NOTES-

In order to consistently bring you the highest quality, full-featured products, we reserve the right to change our specifications and designs at any time. MURPHY products and the Murphy logo are registered and/or common law trademarks of Enovation Controls, LLC. This document, including textual matter and illustrations, is copyright protected by Enovation Controls, LLC, with all rights reserved. (c) 2016 Enovation Controls, LLC. A copy of the warranty may be viewed or printed by going to www.fwmurphy.com/warranty.

ENOVIATION CONTROLS CORPORATE HEADQUARTERS

5311 S 122ND EAST AVENUE
TULSA, OK 74146

ENOVIATION CONTROLS – SAN ANTONIO OFFICE

5757 FARINON DRIVE
SAN ANTONIO, TX 78249

ENOVIATION CONTROLS – HOUSTON OFFICE

105 RANDON DYER RD
ROSENBERG, TX 77471

ENOVIATION CONTROLS LTD. – UNITED KINGDOM

CHURCH ROAD LAVERSTOCK
SALISBURY SP1 1DZ UK

MURPHY ECONTROL TECHNOLOGIES (HANGZHOU) CO, LTD.

77 23RD STREET
HANGZHOU ECONOMIC & TECHNOLOGICAL DEVELOPMENT AREA
HANGZHOU, ZHEJIANG 310018 CHINA

U.S. SALES & SUPPORT

ECONTROL PRODUCTS

PHONE: 210 495 9772
FAX: 210 495 9791
EMAIL: INFO@ENOVIATIONCONTROLS.COM
WWW.ECONTROL.COM

MURPHY PRODUCTS

PHONE: 918 317 4100
FAX: 918 317 4266
EMAIL: SALES@ENOVIATIONCONTROLS.COM
WWW.FWMURPHY.COM

MURPHY CONTROL SYSTEMS & SERVICES

PHONE: 281 633 4500
FAX: 281 633 4588
EMAIL: CSS-SOLUTIONS@ENOVIATIONCONTROLS.COM

MURPHY INDUSTRIAL PANEL DIVISION

PHONE: 918 317 4100
FAX: 918 317 4124
EMAIL: IPDSALES@ENOVIATIONCONTROLS.COM

INTERNATIONAL SALES & SUPPORT

UNITED KINGDOM

PHONE: +44 1722 410055
FAX: +44 1722 450085
EMAIL: SALES@ENOVIATIONCONTROLS.EU
WWW.FWMURPHY.EU

CHINA

PHONE: +86 21 6237 5885
FAX: +86 21 6237 5887
EMAIL: APSALES@ENOVIATIONCONTROLS.COM

LATIN AMERICA & CARIBBEAN

PHONE: 918 317 2500
EMAIL: LASALES@ENOVIATIONCONTROLS.COM

SOUTH KOREA

PHONE: +82 70 7961 4100
EMAIL: SKOREASALES@ENOVIATIONCONTROLS.COM

INDIA

PHONE: +91 91581 37633
EMAIL: INDIASALES@ENOVIATIONCONTROLS.COM



RH 28221 (Tulsa, OK - USA)
RH 620647 (San Antonio, TX - USA)
RH 28221 (Rothsberg, TX - USA)
RH 29432 (UK)



RH 523851 (China) TS 989322 (China)