

Omni-directional 2D barcode scanner Manual



Imaging Bar Code Scanner Technical Specifications

Operational

Light Source	Visible Red LED 625 nm \pm 6.5 nm
Visual Indicators	Blue = ready to scan; White = good read; Yellow = automatic scanning
Host System Interfaces	USB, RS232, Keyboard Wedge, IBM 46xx (RS485)

Mechanical

Dimensions (LxWxH)	(With Stand) 1300MMX98MMX128MM; (Host) 125MMX86MMX85MM
Weight	(With Stand) 510G; (Host) 310G

Electrical

Input Voltage	5VDC
Operating Power (typical)	2W (400mA@5V)
DC Transformers	Class2: 5VDC@2A
LED Class	Class1; IEC60825-1 EN60825-1
EMC	FCC Part15, IEC60825-1, EN55022 Class B

Environmental

Operating Temperature	0°C~45°C
Storage Temperature	-40°C ~ 60°C
Humidity	0% to 95% relative humidity, non-condensing
Drop	Designed to withstand 1.5 m (5') drops
Environmental Sealing	Sealed to resist airborne particulate contaminants
Light Levels	100,000 Lux (9,290 foot-candles)










Scan Performance

Scan Pattern	Area Image (1280 x 512 pixel array)
Motion Tolerance	47 cm/s (18 in/s) for 13 mil UPC at optimal focus
Scan Angle	Horizontal: 50
Print Contrast	20% minimum reflectance difference
Pitch, Skew	75°, 75°
Decode Capability	


1D:Code39, Code93, Code128, UPC/EAN/JAN, Code2 of 5, Code11, Codebar,MSI Plessey, GS1 DataBar, Telepen, Trioptic *PDF: PDF417, MicroPDF417 *2D:QR Code, Micro QR Code, Data Matrix, Aztec Code, Maxicode, Codeblock, Composite Code, POSTNET, PLANET, UPC, Intelligent Mail, Canada Post, Australia Post, Japanese Post, Royal Mail RM4SCC, KIX Code *OCR: OCR-A, OCR-B, E-13B MICR

Features

- **TotalFreedom™:**
Expands scanner functionality by allowing image processing, decoding and formatting plug-ins to be loaded directly to the scanner instead of the host system
- **Omnidirectional Scanning:**
Eliminates need to orientatescanner to bar code
- **Mobile Phone Reading:**
Excels at scanning coupons and tickets directly from the screen of a mobile device
- **CodeSelect™:**
Scans up to 7 bar codes in a single flash and outputs data in any predetermined order
- **Flexible Licensing Solution:**
Meets diverse scanning requirements by offering models with limited decoding capabilities—purchase decoding licenses to enable additional functionality as the need arises
- **Motion Tolerance:**
Offers aggressive scanning of bar codes passing by the window in presentation mode



Mechanical



1	manual switch	4	Scan Window
2	LED Light LED light	5	Speaker
3	10-Pin Female Soket	6	Stand





TABLE OF CONTENTS

Scanner Operation

Presentation and Trigger Modes.....	1
Presentation Mode	1
Multi-Try Trigger Mode	1
Continuous Trigger Mode	1
Single Trigger Mode	2
Omnidirectional and/or Linear Scanner Modes.....	3
Linear Illumination Aiming	4
Data Output.....	4
Same Symbol Timeouts	5

Code Types and Decode Rules

Data Matrix.....	6
QR Code	7
MaxiCode	7
Aztec	8
Postal	8

RS232


Software Handshaking.....	11
---------------------------	----

Interfaces


Additional Interfaces.....	11
----------------------------	----

Presentation and Trigger Modes


Presentation Mode
Out-of-Stand




Presentation Mode
In-Stand




Multi-Try Trigger Mode
Out-of-Stand




Multi-Try Trigger Mode
In-Stand



Continuous Trigger Mode
Out-of-Stand



Continuous Trigger Mode
In-Stand



Presentation and Trigger Modes


Single Trigger Mode
Out-of-Stand



Single Trigger Mode
In-Stand




Set In-Stand Mode to Match
Out-of Stand Mode



Omnidirectional and/or Linear Scanner Modes


Enable Linear Only
in Trigger Operations




Disable Linear Only
in Trigger Operations




Enable 1D Linear Only
in Trigger Operations




Disable 1D Linear Only
in Trigger Operations




Enable Linear Only
in Presentation Operations




Disable Linear Only
in Presentation Operations



Enable 1D Linear Only
in Presentation Operations




Disable 1D Linear Only
in Presentation Operations




Linear Illumination Aiming


Enable Aiming in
Trigger Operations




Disable Aiming in
Trigger Operations



Enable Aiming in
Presentation Operations



Disable Aiming in
Presentation Operations




Data Output

Enable Data Output



Disable Data Output




Same Symbol Timeouts

Retain Same Symbol
Timeout on Trigger



The same-symbol
timeout is not
restarted when the
trigger is pulled.

Reset Same Symbol
Timeout on Trigger



The same-symbol
timeout is restarted
when the trigger is
pulled.

CODE TYPES AND DECODE RULES

Data Matrix


Enable Normal
Color Data Matrix Decoding



Enable Inverse
Color Data Matrix Decoding




Enable Normal **and** Inverse
Color Data Matrix Decoding




Disable
Data Matrix Decoder



Enable Rectangular
Data Matrix Symbol
Decoding




Disable Rectangular
Data Matrix Symbol
Decoding



CODE TYPES AND DECODE RULES

QR Code


Enable Normal
Video QR Code




Enable Inverse
Video QR Code



Enable Normal **and** Inverse
QR Code




Disable QR Code



MaxiCode

Enable MaxiCode




Disable MaxiCode



CODE TYPES AND DECODE RULES

Aztec


Enable Normal
Video Aztec Decoding




Disable Normal
Video Aztec Decoding



Enable Inverse
Video Aztec Decoding




Disable Inverse
Video Aztec Decoding




Postal

Enable
Australia Post




Disable
Australia Post




CODE TYPES AND DECODE RULES

Postal


Enable Japan Post




Disable Japan Post




Enable KIX Code




Disable KIX Code



Enable
PLANET Code




Disable
PLANET Code



Enable
POSTNET Code




Disable
POSTNET Post



CODE TYPES AND DECODE RULES

Postal


Enable B & B'
Fielded POSTNET




Disable B & B'
Fielded POSTNET




Enable
UPU Decoding




Disable
UPU Decoding



Enable
Royal Mail 4 Code



Disable
Royal Mail 4 Code



Software Handshaking

Enable
JV Handshaking




An "JV" response from the host indicates reception of scanner data.

Disable
JV Handshaking




Additional Interfaces

Enable Beeper
ON/OFF Commands




Enables beeper on/off commands with internal USB and IBM interfaces.

Disable Beeper
ON/OFF Commands



3rd Generation
IBM 46xx Defaults



For this feature to function properly, scan IBM Reserved Code #2 after scanning the 3rd Generation IBM 46xx Default bar code.

IBM Reserved Code #2




Scan IBM Reserve bar code above after scanning the 3rd Generation IBM 46xx Default bar code.

Additional Interfaces


IBM 46xx-SIOC RS485 Interface

Send 30H for Last Block
Label Identifier 4680



For PDF
codes only.


Send 00 for Last Block
Label Identifier 4680



For PDF
codes only.


IBM-OEM USB Interface

Send 30H for Last Block
Label Identifier USB




For PDF
codes only.

Send 00 for Last Block
Label Identifier USB



For PDF
codes only.

Full Speed USB
Keyboard Interface





THE POWERLINK CABLE

CONNECTING




Important: If the PowerLink cable is not fully 'latched' the unit can power intermittently.



DISCONNECTING

Before removing the cable from the scanner, Metrologic recommends that the power on the host system is off and the power supply has been disconnected from the PowerLink cable.



1. Locate the small 'pin-hole' on the handle of the unit near the cable.
2. Bend an ordinary paperclip into the shape shown above.
3. Insert the paperclip (or other small metallic pin) into the small 'pin-hole'.
4. You will here a faint 'click'. Pull gently on the strain-relief of the PowerLink cable to remove the cable from the unit.


INSTALLING THE SCANNER TO THE HOST SYSTEM

RS232:

1. Turn off the host device.
2. Plug the male 10-pin RJ45 end of the PowerLink cable into the 10-pin socket on the Focus. You will hear a 'click' when the connection is made.
3. Connect the 9-pin D-type connector of the communication cable to the proper COM port of the host device.
4. Plug the power supply into the power jack on the PowerLink cable.



Check the AC input requirements of the power supply to make sure the voltage matches the AC outlet. The outlet must be located near the equipment and be easily accessible.




5. Connect AC power to the transformer.
6. If will start to initialize. All LE Ds (yellow, white, and blue) will light for approximately 2 seconds then start to alternately flash. When the scanner has finished initializing the LEDs will stop flashing and the unit will beep 3 times indicating that the scanner is ready for use.

INSTALLING THE SCANNER TO THE HOST SYSTEM


Keyboard:

1. Turn off the host device.
2. Plug the 10-pin RJ45 male end of the PowerLink cable into 10-pin socket on the Focus. You will hear a 'click' when the connection is made.
3. Disconnect the keyboard from the host device.
4. Connect the "Y" ends of the communication cable to the keyboard and keyboard port on the host device. If necessary use the male/female adapter cable supplied with the scanner for proper connections.
5. Plug the external power supply (*required*) into the power jack on the PowerLink cable.
6. If will start to initialize. All LEDs (yellow, white, and blue) will light for approximately 2 seconds then start to alternately flash. When the scanner has finished initializing the LEDs will stop flashing and the unit will beep 3 times indicating that the scanner is ready for use.
7. Turn on the host device.



Integrated USB:

1. Turn off the host device.
2. Plug the male 10-pin RJ45 end of the USB cable into the 10-pin socket on the Focus. You will hear a 'click' when the connection is made.
3. Plug the USB type A end of the USB cable into the host's USB port.
4. Turn on the host device.
5. If will start to initialize. All LEDs (yellow, white, and blue) will light for approximately 2 seconds then start to alternately flash. When the scanner has finished initializing the LEDs will stop flashing and the unit will beep 3 times indicating that the scanner is ready for use.



Feb 2013



Printed in China