


Power Analyser UMG 96 RM-E Installation manual


- Installation, Device settings



Janitza electronics GmbH, Vor dem Poststück 6, D-56563 Lahnau, Germany



1



General

Disclaimer

The observation of the information products for the devices is a prerequisite for safe operation...

Further information can be found on our website www.janitza.com at Support > Downloads.

Copyright notice: © 2016 - Janitza electronics GmbH - Lahnau. All rights reserved.

Subject to technical amendments: Make sure that your device agrees with the installation manual.

2



Safety

Safety information

The installation manual does not represent a full listing of all necessary safety measures required for safe operation of the device.

Symbols used: This symbol is used as an addition to the safety instructions and warns of an electrical hazard.

This symbol is used as an addition to the safety instructions and warns of a potential hazard.

This symbol with the word NOTE! describes: Procedures that do not entail any danger of injury.

Measures for safety: When operating electrical devices certain parts of these devices inevitably carry dangerous voltages.

Safety instructions are highlighted with a warning triangle and shown as follows, depending on the degree of hazard:

3




Brief description of device

The UMG 96 RM-E is a multi-functional network analyser, which measures and monitors residual currents (RCM) and currents at the central grounding point (CGRP).

NOTE! If residual currents in electrical systems are monitored, the device (inputs I5/I6) can trigger warning pulses if a response threshold is exceeded.

NOTE! For further information on device functions, data and assembly, see the user manual.

4



Assembly

Install the UMG 96 RM-E in the weather-protected front panel of switch cabinets. Ensure adequate ventilation. Observe clearance to adjacent components!

WARNING! Danger of injury due to electrical energy! Disregard of the installation instructions can damage or destroy your device.


WARNING! Danger of injury due to electrical energy! Serious bodily injury or death can result from: Contact with bare or stripped live wires.

NOTE! For further information on current data and current transformer data can be found in the user manual.

5



Mains systems




The device can be used in 2, 3 and 4 conductor networks (TN, TT and IT networks) and residential and industrial applications.

6




Voltage measurement




Measurement variants for voltage measurement require an N, use a calculated N.

NOTE! If the metering range is exceeded, the measurement device display shows "EEE".

7



Connection variants for current measurement




The measured values for current measurement require an N, use a calculated N.

NOTE! If the measurement range is exceeded, the measurement device display shows "EEE".

8



Current measurement I1, I2, I3



The UMG 96 RM-E is only operated for measuring current with a current transformer.


WARNING! Danger of injury due to electrical energy! Serious bodily injury or death can result from: Contact with bare or stripped live wires.

NOTE! If the measurement range is exceeded, the measurement device display shows "EEE".

9



Connection variants for current measurement I1, I2, I3




The measured values for current measurement require an N, use a calculated N.

NOTE! If the measurement range is exceeded, the measurement device display shows "EEE".

10



Current measuring I4



Current values but not power values can be calculated for current measurement input I4.


NOTE! The measurement input I4 does not require address setting on the device.

NOTE! Further information on current data and current transformer data can be found in the user manual.

11



Analogue inputs



The device has 2 analogue inputs (terminals 32 to 37), each for a temperature measurement or residual current monitoring.


NOTE! Damage to the device / your system due to short circuit! Inadequate insulation of the operating equipment on the analogue inputs relative to the mains supply circuit can lead to your device/system being damaged.

Ensure that there is reinforced or double insulation to the mains supply circuits!

5



Residual current monitoring (RCM) via I5 and I6



The UMG 96RM-E measures residual currents in accordance with IEC/TR 60755 (2008-01), type A and type B.

NOTE! The transformation ratios for the residual current transformer inputs can be individually configured via the software.


* UMG 96 RM-E with residual current monitoring via measurement inputs I5/I6 can be found in the user manual.

Measurement inputs I5 and I6 do not require address setting on the device.

12



Establish connection to PC




More details on device configuration and communication can be found in section 14.

13



Controls and button functions



The device differentiates between display and programming mode.

Measured values are arranged in measured value display profiles and can be conveniently adapted in the GridVis® software.


Display mode: Buttons 1 and 2 can be used to scroll between the measured value indicators.

NOTE! More detailed information on operation, display and button functions for your device can be found in the user manual.

14



Programming mode



The most important programming menus for a quick start: TCP/IP device address, subnet mask, gateway address (4th, 5th, 6th) and dynamic TCP/IP addressing (on/off) (7th) via the Ethernet interface.

Example settings are selected for the device and the PC to implement the following settings:

Device IP address: 192.168.1.116

Subnet mask: 255.255.255.0

PC IP address: 192.168.1.117


Subnet mask: 255.255.255.0

NOTE! Changes are only applied after exiting the programming mode.

15



Programming current transformers




NOTE! Changes are only applied after exiting the programming mode.

16



Manual TCP/IP configuration via the Ethernet interface




NOTE! To ensure that a DHCP server does not overwrite the manual TCP/IP configuration, deactivate the dynamic IP allocation (dYn, rOFF) (step 14 and 17). Then exit programming mode and configure the TCP/IP address manually.

17



Dynamic TCP/IP allocation via the Ethernet interface (DHCP mode)



The dynamic IP allocation can be implemented via the software.

NOTE! The key symbol on the display indicates that dynamic TCP/IP allocation is active (on). When the device starts up, the DHCP server automatically allocates the TCP/IP device address, subnet mask and gateway address.

18



Technical data

Table with general information: Net weight, Packaging weight, Battery, Service life, Ventilation, Protection against ingress of solid foreign bodies, Mounting position, Dimensions, Transport and storage.

Table with ambient conditions during operation: Nominal current, Measurement range, Resolution, Crest factor, Impedance, Power consumption, Measurement range, Sampling rate, Frequency range, Burden, Response time.

Table with current measurement I1-I4: Nominal current, Measurement range, Resolution, Crest factor, Power consumption, Measurement range, Sampling rate, Frequency range, Burden, Response time.

Table with residual current monitoring I5/I6: Nominal current, Measurement range, Resolution, Crest factor, Impedance, Power consumption, Measurement range, Sampling rate, Frequency range, Burden, Response time.

Table with digital outputs: Nominal current, Measurement range, Resolution, Crest factor, Power consumption, Measurement range, Sampling rate, Frequency range, Burden, Response time.

Table with digital inputs: Nominal current, Measurement range, Resolution, Crest factor, Power consumption, Measurement range, Sampling rate, Frequency range, Burden, Response time.

Table with terminal connection capacity (residual current or temperature measurement inputs and digital inputs/outputs).

Table with terminal connection capacity (current measurement).

Table with terminal connection capacity (power supply voltage).

Table with terminal connection capacity (voltage measurement).

19



Procedure in the event of faults

Table with possible faults: No display, No current display, Current displayed is too large or too small, Voltage displayed is too large or too small, Voltage displayed is too small, "EEE" in the display, "EEE" in the display, Device still does not work despite the above measures.

Janitza logo