


www.janitza.com

Power Quality Analyser UMG 605

Operating manual and
technical data



Janitza electronics GmbH
Vor dem Polstück 1
D-35633 Lahnau
Support Tel. 0049 6441 9642-22
Fax 0049 6441 9642-30
e-mail: info@janitza.com
Internet: <http://www.janitza.com>

Janitza®

| | | | |
|-------------------------------|-----------|--|-----------|
| Content | | Operation | 44 |
| General Information | 4 | Key functions | 44 |
| Inspection on receipt | 6 | Concealed key (service) | 44 |
| Scope of supply | 7 | Display mode | 45 |
| Available accessories | 7 | Programming mode | 46 |
| Notes on Use | 8 | Display password | 47 |
| Product Description | 10 | Homepage password | 47 |
| Intended use | 10 | Measurements | 48 |
| UMG605 features | 11 | Voltage transformer ratio | 50 |
| Operating concept | 12 | Current transformer ratio | 51 |
| GridVis programming software | 13 | Interfaces | 52 |
| Methods of measurement | 14 | RS232 | 52 |
| Three-phase 4-wire systems | 15 | RS485 | 52 |
| Three-phase 3-wire systems | 16 | Ethernet | 53 |
| Installation | 18 | Profibus | 54 |
| Installed position | 18 | Recordings | 57 |
| Power supply voltage | 19 | Putting into Service | 58 |
| Voltage measurement | 20 | Applying the power supply voltage | 58 |
| Frequency measurement | 27 | Frequency measurement | 58 |
| Current measurement | 28 | Applying the measuring-circuit voltage | 59 |
| Direct measurement | 31 | Phase sequence | 60 |
| Interfaces | 32 | Applying the measuring-circuit current | 60 |
| RS485 | 34 | Checking the energy measurement | 61 |
| RS485 profibus DP V0 slave | 36 | | |
| Digital inputs and outputs | 38 | | |
| Temperature measurement input | 42 | | |

| | | | |
|-------------------------------------|-----------|-------------------------------------|-----------|
| System information | 62 | Appendix | 82 |
| Overrange | 62 | Parameter list | 82 |
| Serial number | 63 | Measured value displays | 88 |
| Date | 63 | Declaration of conformity | 89 |
| Firmware release | 63 | Dimensioned drawings | 90 |
| Time | 63 | UMG605 connection example | 91 |
| Service and maintenance | 64 | Quick Reference Instructions | 92 |
| Repair and calibration | 64 | | |
| Front film | 64 | | |
| Battery | 64 | | |
| Firmware update | 65 | | |
| Service | 65 | | |
| Trouble shooting | 66 | | |
| Technical specifications | 70 | | |
| General information | 70 | | |
| Ambient conditions during operation | 70 | | |
| Transport and storage | 70 | | |
| Power supply voltage | 71 | | |
| Protection class | 72 | | |
| Inputs and outputs | 73 | | |
| Temperature measurement input | 74 | | |
| Interfaces | 75 | | |
| Function parameters | 76 | | |
| Specifications for | | | |
| IEC 61000-4-30 Class S | 79 | | |
| Measuring inputs | 80 | | |

General Information

Copyright

This manual is subject to the statutory copyright protection provisions and may not be photocopied, reprinted, reproduced as a whole or in parts, by mechanical or electronic means, nor copied or further published in any other way whatsoever without the legally binding, written consent of

Janitza electronics GmbH,
Vor dem Polstück 1,
D 35633 Lahnau,
Germany.

Comments on the manual

We welcome your comments. If anything in this manual seems unclear to you, please let us know by sending an eMail to:

info@janitza.de

Protected trademarks

All trademarks and their resulting rights belong to the respective holders of these rights.

Liability disclaimer

Janitza electronics GmbH does not accept any responsibility whatsoever for errors or deficiencies within this manual and does not undertake any obligation to keep the content of this manual up to date.

Meaning of the symbols used

The following pictograms are used in this manual:



Dangerous voltage!

Danger or risk of severe injury. Disconnect the system and device from the power supply before starting the work.



Important!

Please note and follow the documentation. This symbol is intended to warn you of possible hazards that can occur during installation, starting up and use.



Note.

Inspection on receipt

Fault free and safe use of this device requires appropriate transport, proper storage, erection and assembly as well as careful operation and maintenance. If it can be assumed that safe operation is no longer possible, the device must be immediately taken out of service and secured against being accidentally started up. The device must be unpacked and packed with the usual care, without the use of force and only using suitable tools. The devices must be visually inspected for perfect mechanical condition. Please also note and follow the installation instructions enclosed with the device.

It can be assumed that safe operation is no longer possible if the device, e.g.

- has visible damage,
- no longer works, despite intact mains power supply,
- has been exposed to unfavourable conditions (e.g. storage outside the permissible climatic limits without adjustment to the ambient climate, condensation, or similar) for a lengthy period or was exposed to unfavourable effects or loads during transport (e.g. fall from a large height even if there is no visible external damage, or similar).

Please check the scope of supply for completeness before you start installing the device.



All screw-type terminals belonging to the scope of supply are plugged into the device.



The installation and start-up instructions also describe options which do not belong to the scope of supply.



All supplied options and design versions are described on the delivery note.

Scope of supply

| Number Product No. | | Name |
|--------------------|-------------------------|---|
| 1 | 52 16 xxx ¹⁾ | UMG605 XX ²⁾ |
| 1 | 33 03 085 | Installation and start-up instructions |
| 1 | 33.03.304 | Quick guide (supplement to the operating instructions) |
| 1 | 51 00 116 | CD with the following content: <ul style="list-style-type: none"> - “GridVis” programming software, - Functional descriptions, GridVis, UMG605 - GSD file “u6050c2d.GSD” for profibus DP V0 |
| 1 | 10 01 807 | Screw-type terminal, plug-in, 2 pin |
| 1 | 10 01 808 | Screw-type terminal, plug-in, 3 pin |
| 1 | 10 01 809 | Screw-type terminal, plug-in, 5 pin |
| 1 | 10 01 810 | Screw-type terminal, plug-in, 6 pin |
| 1 | 89 10 051 | Slot-head screwdriver (0.40x2 mm), ESD |
| 1 | 08 01 505 | Patch cable, 2m, twisted, grey (UMG605 - PC/switch connection) |
| 1 | 52 00 008 | RS485, external terminating resistor, 120 ohm |

1) Refer to delivery note for product number.

2) Design version.

Available accessories

| Product No. | Name |
|-------------|---|
| 21 01 058 | Battery, lithium CR2032, 3 V (according to UL1642) |
| 08 02 427 | RS232, Connection cable (UMG 605 – PC), 2m, 5 poles |

Notes on Use

Please read these operating instructions and all other publications which have to be used to work with this product (in particular for installation, operation or maintenance).

Note and follow all safety instructions as well as any warnings. If you do not follow the instructions, personal injuries and/or damage to the product could be the result.

Any unauthorised change or use of this device which extends beyond the given mechanical, electrical or other operating limits can cause personal injuries and/or damage to the product.

Any such unauthorised change is “misuse” and/or “negligence” under the product's warranty and therefore excludes the warranty for cover of possible resulting injuries or damage.

This device may be solely operated and maintained by skilled persons.

Skilled persons are people who, on the basis of their relevant training and experience, are capable of identifying risks and avoiding possible hazards which operation or maintenance of the device can cause.

When using the device, any additional legal and safety regulations required for the respective use must be observed.

**Important!**

If the device is not operated according to the instruction manual, protection is no longer ensured and the device can cause hazards.



Conductors made of individual wires must be fitted with wire end ferrules.



Only pluggable screw terminals with the same number of poles (pins) and of the same type may be plugged together.

Product Description

Intended use

The UMG605 is intended to be used for the measurement and calculation of electrical variables such as voltage, current, energy, work, harmonic components, etc. in building installations, at distribution boards, circuit-breakers and busbar trunking systems.

Measuring-circuit voltages and currents must originate from the same system.

The UMG605 is permanently installed in control cabinets or small distribution boards. It can be installed in any position.

The measurement results can be displayed, stored and read out via serial interfaces and further processed.

The voltage measurement inputs are designed for measurements in low-voltage systems in which rated voltages up to 300 V conductor to earth and surge voltages of overvoltage category III can occur.

The current measurement inputs of the UMG605 are connected via external $\dots/1A$ or $\dots/5A$ current transformers.

Measurement in medium and high-voltage systems takes place with current and voltage transformers. Special safety requirements must be complied, which are not dealt with in any greater detail here.

The UMG605 fulfils the test requirements for use in industrial areas.

Mains failure detection

The mains failure detection takes place via the voltage measurement inputs. The selection of voltage measurement inputs can be configured using the GridVis software.

Mains failure stored energy time

The UMG605 bridges the following mains failures at the auxiliary voltage input:

| | |
|--------------------------|--------------------------------|
| Mains voltage 230V AC | Stored energy time max 80ms |
|--------------------------|--------------------------------|

UMG605 features

- Measurement in IT, TT and TN systems,
- 4 voltage measurement inputs, - 4 current measurement inputs,
- Continuous scanning of the voltage and current measurement inputs,
- Measurement of power quality according to DIN EN61000-4-30:2009 class S,
- Flicker meter according to DIN EN61000-4-15:2011 class F3,
- Analysis and evaluation according to DIN EN50160 with software GridVis, which belongs to the contents of delivery,
- Measurement of harmonics and interharmonics (UIn, UII, I) according to DIN EN61000-4-7,
- Measurement of audio remote frequency (U, I, P, Q),
- Detection of transients $>50\mu\text{s}$ and storage with up to 16000 scanning points
- Detection of more than 2400 measurement values,
- Fourier analysis 1st to 63th harmonic component for U, I, P (cons./supply) and Q (ind./cap.),
- Detection of events such as overvoltage, voltage drop, power failure and overcurrent,
- Datalogger / event memory (128MB Flashdisk),
- Real energy; DIN EN62053-22, accuracy class 0,5S with $\dots/5\text{A}$ converter.
- Reactive energy; DIN EN62053-23, accuracy class 2r.
- 2 digital inputs, 2 digital outputs, temperature measurement input,
- LC display, 2 keys,
- Operating temperature range $-10^{\circ}\text{C} \dots +55^{\circ}\text{C}$,
- Mounting on top hat rails 35 mm. Suitable for installation in distribution systems.
- Serial interfaces
 - Profibus DPV0,
 - RS485; modbus RTU, modbus master, BACnet (option),
 - RS232; modbus slave,
 - Ethernet; web server, EMAIL, BACnet (option),
- Programming own applications in Jasic,

Operating concept

You can program the UMG605 and call up measured values in several ways.

- **Directly** at the device using 2 keys and the display. You can change the values in the parameter list (see Appendix) and call up the measured values from the measured value displays.
- Via the **GridVis** programming software.
- In devices with an ethernet interface, via the **homepage** of the UMG605.
- Via the RS485 with the **modbus** protocol. You can change and call up data with the help of the modbus address list (is filed on the enclosed data carrier).

Operation of the UMG605 via the integrated display and the two keys only is described in these operating instructions.

The GridVis programming software and the homepage have their own “online help”.



Use the **parameter list** in the appendix to these instructions for programming at the UMG605 and the **modbus address list** on the data carrier included in the scope of supply for programming via a serial interface.

GridVis programming software

The UMG605 can be programmed and read out using the GridVis® programming software included in the scope of supply. This requires a PC to be connected to the UMG605 via a serial interface/ethernet.

GridVis features

- Programming the UMG605.
- Configuring recordings.
- Analyse der ausgelesenen Daten nach EN 61000-2-4.
- Reading out recordings.
- Storing data in a database.
- Graphic display of measured values.
- Programming customer-specific applications.




Fig. Connection of a UMG605 to a PC via an RS232 cable.




Fig. Connection of a UMG605 to a PC via an interface converter.




Fig. Connection of a UMG605 to a PC via the ethernet.

Methods of measurement

The UMG605 measures continuously and calculates all effective values over a 200 ms interval.

The UMG605 measures the real effective value (TRMS) of the voltages and currents applied to the measurement inputs.

Three-phase 4-wire systems

The UMG605 can be used in three-phase 4 conductor systems (TN, TT system) (50 Hz, 60 Hz) with earthed PEN conductor. The bodies of the electrical system are earthed.

The conductor to neutral conductor voltage may not exceed 300 V AC.

The UMG605 is only suitable for environments in which the impulse voltage withstand level of 4 kV (overvoltage category III) is not exceeded.

| U_{L-N} / U_{L-L} |
|---------------------|
| 66 V / 115 V |
| 120 V / 208 V |
| 127 V / 220 V |
| 220 V / 380 V |
| 230 V / 400 V |
| 240 V / 415 V |
| 260 V / 440 V |
| 277 V / 480 V |

Maximum rated voltage
of the grid




Fig. Block diagram, UMG605 in TN system.

Fig. Table of rated voltages of the grid suitable for the voltage inputs.

Three-phase 3-wire systems

The UMG605 can be used in unearthed three-phase 3 wire systems (IT system). The conductor to conductor voltage may not exceed 480V AC (50 Hz, 60 Hz).

The UMG605 is only suitable for environments in which the impulse voltage withstand level of 4 kV (overvoltage category III) is not exceeded.

In the IT system the neutral point (star point) of the voltage generator is not earthed. The bodies of the electrical system are earthed. Earthing via high-resistance impedance is allowed.

IT systems are only allowed in certain systems with their own transformer or generator.

| U_{L-L} |
|-----------|
| 66 V |
| 115 V |
| 120 V |
| 127 V |
| 200 V |
| 230 V |
| 240 V |
| 260 V |
| 277 V |
| 347 V |
| 280 V |
| 400 V |
| 415 V |
| 440 V |
| 480 V |

Maximum rated voltage
of the grid

Fig. Table of rated voltages of the grid suitable for the voltage inputs.




Fig. Block diagram, UMG605 in IT system without N.




Fig. Block diagram, UMG605 in IT system with N.

Installation

Installed position

The UMG605 can be installed in control cabinets or in small distribution boards according to DIN 43880. It is mounted on a 35 mm mounting v according to DIN EN 60715. It can be installed in any position.




Fig. UMG605 on mounting rail according to DIN EN 60715.

Power supply voltage

A power supply voltage is required for operation of the UMG605. The type and amount of power supply voltage required is noted on the rating plate.

Before applying the power supply voltage, ensure that the voltage and frequency match the information given on the rating plate!

The connection cables for the power supply voltage must be fused with a UL listed fuse (6A type C).




Fig. Connection example for the power supply voltage U_h.



- A disconnecter or circuit-breaker must be provided for the power supply voltage in the building installation.
- The disconnecter must be installed near the device and must be easy for the user to reach.
- The switch must be labelled as a disconnecting device for this device.
- Voltages which are above the allowable voltage range can destroy the device.



Devices driven with direct current are protected against polarity reversal.



Important!

The inputs for the supply voltage are dangerous to touch!

When connecting the voltage measurement, the following must be observed:

- In order to disconnect the voltage and current, a suitable circuit breaker is to be provided.
- The circuit breaker must be positioned near to the UMG605, identified for the user and easy to reach.
- Only use authorised UL/IEC excess current protection devices and circuit breakers.
- Please use a 6A (UL-listed) cable circuit breaker.
- The excess current protection device must have a nominal value which is measured for the short circuit current at the connection point.
- Measurement voltages and measurement currents must come from the same network.

**Caution!**

Voltages that exceed the permitted nominal network voltages must be connected using a voltage converter.

**Caution!**

The UMG605 is not suitable for measuring DC voltages.

**Caution!**

Contact with the voltage measurement inputs on the UMG605 is dangerous!

**Caution!**

The voltage measurement inputs may not be used for voltage measurement in SELV circuits (low voltage protector).

Main measurement, inputs 1-3 4-conductor connection




Fig. measurement in a three-phase 4 conductor network with asymmetrical load.




Fig. measurement using 3 voltage converters in a three-phase 4 conductor network with asymmetrical load.




Fig. measurement using a three-phase 4 conductor network with symmetrical load.




Fig. measurement using 2 voltage converters in a three-phase 4 conductor network with asymmetrical load.




Fig. measurement using 2 current converters in a three-phase 3 conductor network with symmetrical load.




Fig. measurement in a three-phase 4 conductor network with asymmetrical load.

3-conductor connection




Fig. measurement in a three-phase 3 conductor network with asymmetrical load.




Fig. measurement in a three-phase 3 conductor network with asymmetrical load.




Fig. measurement in a three-phase 3 conductor network with asymmetrical load.




Fig. measurement in a three-phase 3 conductor network with asymmetrical load.




Fig. measurement in a three-phase 3 conductor network with asymmetrical load.




Fig. measurement in a three-phase 3 conductor network with asymmetrical load.




Fig. measurement of a phase in a three-phase 4 conductor network.




Fig. measurement in a single-phase 3 conductor network. I_3 and U_3 are not calculated and set to zero.

Auxiliary measurement, input V4 3-conductor connection




Fig. measurement with one current transformer in a three-phase 4 conductor network with symmetrical load




Fig. measurement with one current transformer in a three-phase 3 conductor network with symmetrical load.




Fig. measurement with one current transformer



Be connected for the measurement of the auxiliary measurement (V4) for frequency estimation needs a voltage to the main measurement.



In case of a three wire main measurement (input V1-V3), the auxiliary measurement (input V4) cannot be used as measuring input.

Frequency measurement

The UMG605 needs the network frequency to measure and calculate measurement values. The network frequency must be in a range between 15Hz and 440Hz.

For automatic ascertainment (wide range) of the frequency, an L1-N voltage larger than 10Veff must be applied to the voltage measurement input V1.

The measurement of power frequency happens only at the measuring inputs of the main measurement (V1, V2, V3).



Measurement voltages and measurement currents must come from the same network.



Be connected for the measurement of the auxiliary measurement (V4) for frequency estimation needs a voltage to the main measurement.




In case of a three wire main measurement (input V1-V3), the auxiliary measurement (input V4) cannot be used as measuring input.

Current measurement

The UMG605 is designed for the connection of current transformers with secondary currents of $.1/1A$ and $.5/5A$. Only alternating currents, not direct currents, can be measured.

Each current measurement input can be permanently loaded with 6A or for 1 second with 100 A.



Attention!

The current inputs are live.



Important!

The UMG605 is not suitable for the measurement of direct voltages.



Earthing current transformers

If a connection is provided for earthing the secondary winding, this must be connected with earth.

Fig. Connection example, current measurement via current transformers.

Ammeter

If you not only want to measure the current with the UMG605 but with an ammeter also, the ammeter must be connected in series to the UMG605.




Fig. Example, current measurement via additional ammeter.



Short-circuit current transformer connections!

The secondary connections of the current transformer must be short-circuited to them first before the current supply leads to the UMG605 are disconnected!

If a testing switch is available, which automatically short circuits the current transformer's secondary leads, it is sufficient to place this in the "test" position, provided the short-circuiters have been tested first.



Open current transformer!

High hazardous live voltage peaks can occur at current transformers which are operated open on the secondary side!

The winding insulation in "safe open current transformers" is dimensioned so that the current transformers can be operated open. But these current transformers are also hazardous live if they are operated open.

Direct measurement

Nominal currents up to 5 A can also be measured directly with the UMG605. In this case it must be noted that each current measurement input may be loaded continuously with 6 A or for 1 second with max 100 A.

As the UMG605 does not have any integrated protection for the current measurement, this protection (e.g. 6A fuse type C) must be provided for during installation.

The direction of the current for each phase can be corrected direct at the UMG or by the provided software.

In case of wrong connections ($k - I / S1 - S2$) there is no changing of the wiring necessary.




Fig. Example, direct current measurement.

Interfaces

RS232

You can use a RS232 connection cable to connect the UMG605 to a PC.

The achievable distance between two devices with RS232 interface depends on the cable used and the baud rate. The maximum connectable cable length is 30 m!

As a guideline value, for a transmission rate of 9600 baud the distance should not exceed 15 m to 30 m.

The permissible ohmic load must be larger than 3 kohm and the capacitive load caused by the transmission cable must be smaller than 2500 pF.

Shielding

A twisted-conductor and shielded cable must be provided for connections via the RS232 interface. The shielding at both ends of the cable must be connected to a large area of the housing or cabinet parts in order to achieve an adequate shielding effect.



Important!

Profibus, RS232, RS485 and temperature measurement input are not metallically separated from each other.



All interfaces can be used simultaneously.




Fig. Example, connecting a UMG605 to a PC via the RS232 interface.





Fig. Connector pin assignment for the PC connection cable (Part number: 08 02 427).

RS485


Bus structure

All devices are connected in a bus structure (line). Up to 32 stations can be connected together in a segment. The cable at the start and end of a segment is terminated with resistors.

If there are more than 32 stations, repeaters must be used to connect the individual segments.



RS485 interface, 2-pole plug contact





RS485 interface, 2-pole plug contact with terminating resistor (Item no. 52.00.008)

Terminating resistors

The cable at the start and end of a segment is terminated with resistors (120 ohm, 1/4 W).

The UMG605 does not contain any terminating resistors.



□ Terminal strip in the control cabinet.

○ Device with RS485 interface.
(Without terminating resistor)

■ Device with RS485 interface.
(With terminating resistor at the device)

Shielding

A twisted-conductor and shielded cable must be provided for connections via the RS485 interface. The shielding at both ends of the cable must be connected to a large area of the mounting plate or cabinet parts in order to achieve an adequate shielding effect.

Cable type

Recommended cable types:

Unitronic Li2YCY(TP) 2x2x0.22 (Lapp cables)

Unitronic BUS L2/FIP 1x2x0.64 (Lapp cables)

Cable length

1200 m for a baud rate of 38.4 k



For the wiring of the Modbus connection, CAT cables are not suitable. Please use the recommended cables.




Important!

Profibus, RS232, RS485 and temperature measurement input are not metallically separated from each other.

RS485 profibus DP V0 slave

The profibus connection in the UMG605 is a 9 pin DSUB socket.

We recommend use of a 9 pin profibus connector for the connection, e.g. as made by Phoenix, type “SUBCON-Plus-ProfiB/AX/SC” with product number 2744380. (Janitza art. no.: 13.120.539)



—Profibus connection

Fig. UMG605 with profibus interface.

Connecting the bus cables

The incoming bus cable is connected to terminals 1A and 1B. The bus cable for the next device in the line is connected to terminals 2A and 2B. If there is not another device in the line the bus cable must be terminated with resistors (switch set to ON).

In the ON switch setting terminals 2A and 2B are switched off for the continuing bus cable.




Fig. Profibus connector with terminating resistors.

Digital inputs and outputs

Digital outputs

The UMG605 has 2 transistor switching outputs. These outputs are metalically separated from the analysis electronics via optocouplers.

- The digital outputs can switch direct or alternating current load.
- The digital outputs can switch loads independant on the polarity of the feeding voltage.
- The digital outputs are not short-circuit-proof.
- Cables, which are longer but 30m must be shielded.




Fig. Connection example.



Attention!
The digital outputs are not short-circuit-proof.




Fig. Connection of alternating voltage relays to the digital outputs.




Fig. Connection of direct current relays to the digital outputs.

Digital inputs

The UMG605 has 2 digital inputs to each of which you can connect one transducer.

An input signal is detected at a digital input if a voltage of at least 10 V and maximum 28 V is applied. In this case a current of at least 1 mA and maximum 6 mA flows. Cables longer than 30 m must be laid with shielding. Please mind the polarity of the feeding voltage.




Fig. Connection example.




Fig. Example for the connection of external switching contacts S1 and S2 to the digital inputs 1 and 2.



Attention!

The polarity of the feeding voltage must be respected for the digital inputs.

S0 pulse input

At each UMG605 with inputs for 24 V you can also connect S0 pulse generators according to DIN EN 62053-31.

You require only one external auxiliary voltage of 20..28 V DC and one external 1.5 kohm resistor each.




Fig. UMG605 with inputs for 24 V. Example with S0 pulse generator.




Fig. UMG605 with inputs for 24 V. Example for connection of an S0 pulse generator at digital input 2.

Temperature measurement input

Temperature sensors with a resistance range of 400 ohm to 4 kohm can be connected to the temperature measurement input.

The total burden (sensor + cable) of 4 kohm may not be exceeded.





Fig. Example, temperature measurement with a KTY83.



Use a shielded cable to connect the temperature sensor.



Important!
Profibus, RS232, RS485 and temperature measurement input are not metallically separated from each other.

Operation

The UMG605 has a display, keys 1 and 2 and the Service key to make it easier to install and start up the UMG605 without a PC.

Important parameters such as current transformers and device address are included in the parameter list (see Appendix) and can be directly programmed at the device.

A differentiation is made between operation with the

- display mode and
- Programming mode.

Key functions

Press the key “briefly”:


- page forwards
- Digit/value +1

Press the key for “long time”:

- page backwards
- Digit/value -1


Simultaneously press both keys for around 1 second and keep them pressed:

- Switch between display mode and programming mode.



Display
Key 1
Key 2
Concealed key

Keys 1 and 2



The UMG605 is operated using keys 1 and 2.

Concealed key (service)

The Service key is intended for use by instructed service employees only.

Display mode

After the power supply is resumed the device is in Display mode.

In Display mode you can use Keys 1 and 2 to page between the measured value displays.



Use Key 1 to select the phase for the measured values.



Press Key 2 to page between the measured values for current, voltage, power output, etc.

The factory default setting for the measured value displays is shown in the “measured value displays” in the Appendix.



Important!

The user can use the GridVis/Jasic to reconfigure the function of the keys and selection of the values to be displayed.




Fig. “Display Mode” display example. Displayed measured value: $U_{L1-N} = 230.0$ V.




Fig. Display example for rotating field and frequency.

Programming mode

The most important settings required for operation of the UMG605 can be displayed and changed in programming mode.

The parameter list in the Appendix contains the addresses for the most important settings. You can make further settings using the GridVis software included in the scope of supply.

If you simultaneously press Keys 1 and 2 for around 1 second, programming mode opens via a password query. If a display password has not been programmed, the first programming menu opens directly.

Programming mode is denoted in the display by the text “PRG”. The digits of the address flash.

If you are in programming mode and have not pressed a key for approximately 60 seconds or simultaneously press Keys 1 and 2 for around 1 second, the device returns to display mode.




Fig. “Programming Mode” display example, address 000 with content 5,000.

Display password

You can program a 4-digit display password to make it difficult to accidentally change the programming data directly at the device. A display password is not set in the factory.

Homepage password

You can protect access to the UMG605's homepage via a password. A homepage password is not set in the factory.

Password mode

The UMG605 differentiates between 3 password modes for the homepage password:

- 0 = The homepage password is not queried.
- 2 = Changes to the configuration and the display of measured values require the password to be entered once.
- 128 = Each change to the configuration requires renewed input of the password.

Forgot password?

After a safe connection between the UMG605 and GridVis please clear the password via software.




Fig. Query window for the display password.

| Addr. | Content |
|-------|---|
| 500 | Display password 0 =the password is not queried. |
| 501 | Homepage, password mode |
| 502 | Homepage password |

Fig. Section of the parameter list for password programming.

Measurements

The UMG605 has four measuring channels for the voltage measurement (V1...V4 against Vref) and four measuring channels for the current measurement (I1...I4). The Voltage and current to be measured have to be come out of the same grid.

Main measurements (channels 1 – 3)

For the main measurement are the channels 1 – 3 available. Use the measuring channels 1 – 3 for measurements in a three phase system.

For the main measurements are 14 different measurement connections available. The appropriated connection diagrams you will find on page 22-24.

The selected connection has to be adjusted at the parameter “110”.




Fig. example of the display; connection for the main measurement, address 110 with the content 0000 (=4w3M).

Selection of connections:

- 0 = 4w3m (default factory setting)
- 1 = 4w2m
- 2 = 4w2u
- 3 = 4w2i
- 4 = 3w3m
- 5 = 3w2m
- 6 = 3w2u
- 7 = 3w2i
- 8 = 2w2m
- 9 = 2w1m
- 10 = 4w3m_hv
- 11 = 4w2u_hv
- 12 = 3w2u_hv
- 13 = 3w2m_hv

Auxiliary measurement (channel 4)

For the auxiliary measurement is only the 4th channel available.

Use the measuring channel 4 only in a single phase system or in three phase systems with symmetrical load.

The settings for the frequency and the relevant voltage are adjusted automatically according the settings of the main measurement.

For the auxiliary measurement are 3 different measurement connections available. The appropriated connection diagrams you will find on page 23.

The selected connection has to be adjusted at the parameter "111".




Fig. example of the display; connection for the auxiliary measurement, address 111 with the content 0000 (=2w1n).

Selection of connections:

- 0 = 2w1n (default factory setting)
- 1 = 3w1m
- 2 = 4w1m

Voltage transformer ratio

The parametrisation of the voltage transformer ratio for the main measurement are under address 002 and 003.

The parametrisation of the voltage transformer ratio for the auxiliary measurement are under address 012 and 013.

A voltage transformer ratio of 400 V/400 V direct measurement is programmed in the factory for all 4 voltage transformer inputs.




Fig. Example; Voltage transformer (primary), address 002, content „400“.

| Address | Voltage transformer values |
|---------|----------------------------|
| 002 | L1 L2 L3 (primary) |
| 003 | L1 L2 L3 (secondary) |
| 012 | L4 (primary) |
| 013 | L4 (secondary) |

Fig. Section of the parameter list for the voltage transformer values.

Current transformer ratio

The parametrisation of the current transformer ratio for the main measurement are under address 000 and 001.

The parametrisation of the current transformer ratio for the auxiliary measurement are under address 010 and 011.

A current transformer ratio of 5 A/5 A is programmed in the factory for all 4 current transformer inputs.




Fig. Example; Current transformer (primary), adress 000, content „0005“.

| Address | Current transformer values |
|---------|----------------------------|
| 000 | Main Input |
| 001 | L1 L2 L3 (primary) |
| | L1 L2 L3 (secondary) |
| 010 | Auxiliary Input |
| 011 | L4 (primary) |
| | L4 (secondary) |

Fig. Section of the parameter list for the current transformer values.

Interfaces

The UMG605 has 4 serial interfaces:

- RS485
- RS232
- Ethernet
- Profibus

All interfaces can be used simultaneously.

RS232

The following data must be programmed for use of the RS232 interface:

- Baud rate,
- Operating mode.

Refer to the parameter list in the Appendix for the default factory setting and the setting ranges.

RS485

The following data must be programmed for use of the RS485 interface:

- Device address,
- Baud rate,
- Operating mode.

Refer to the parameter list in the Appendix for the default factory setting and the setting ranges.

| Addr. | Content |
|-------|---|
| 200 | Device address (1 .. 255) valid for Modbus and Profibus 1 = default factory setting |

Ethernet

Fixed IP address

In simple networks without DHCP servers the network address must be set directly at the device.

BootP

BootP allows fully automatic integration of a UMG605 in an existing network. BootP is an older protocol and does not have the functional scope of DHCP.

DHCP mode

DHCP enables fully automatic integration of a UMG605 in an existing network without any further configuration. On starting the UMG605 automatically imports the IP address, the net mask and the gateway from the DHCP server. The UMG605 is set in the factory to "DHCP".

Zeroconf

Zeroconf allows fully automatic integration (allocation of IP address) of a UMG605 in an existing network without DHCP servers.




Fig. Connection example, the UMG605 and PC require a fixed IP address.




Fig. Connection example, the UMG605 and PC are automatically assigned an IP address by a DHCP server.



The UMG605 may only be connected to the ethernet following consultation with the network administrator!

Profibus

Profibus profiles

The UMG605 can manage 16 profibus profiles. Each profibus profile contains 128 data bytes maximum.

The first data byte of the output area of the PLC (programmable logic controller) always contains the profile number of the profibus profile required by the UMG605.

To request a profibus profile, write the profile number in the first byte of the output area of the PLC.

All system variables and global variables¹⁾ can be individually scaled and converted into one of the following formats:

- 8, 16, 32 bit integer with and without sign.
- 32 or 64 bit float format.
- Big or little Endian²⁾.

¹⁾Global variables are variables which are defined by the user in Jasic and are available to each interface in the UMG605.

²⁾ Big-Endian = High byte before low byte
Little-Endian = Low byte before high byte.

Device master file GSD

The device master file for the UMG605 is called "0B41.GSD" and is included on the CD which belongs to the scope of supply.




Fig. Block diagram for data exchange between PLC and UMG605.

| Addr. | Content |
|-------|---|
| 200 | Device address (1 .. 255) valid for Modbus and Profibus 1 = default factory setting |

Default Profibus profile

Profibus profile number 0

| | Byte Index | Value type | Value format | Scaling |
|----|------------|-----------------------------------|--------------|---------|
| 1 | 1 | Voltage L1-N | float | 1 |
| 2 | 5 | Voltage L2-N | float | 1 |
| 3 | 9 | Voltage L3-N | float | 1 |
| 4 | 13 | Voltage L4-N | float | 1 |
| 5 | 17 | Voltage L2-L1 | float | 1 |
| 6 | 21 | Voltage L3-L2 | float | 1 |
| 7 | 25 | Voltage L1-L3 | float | 1 |
| 8 | 29 | Current L1 | float | 1 |
| 9 | 33 | Current L2 | float | 1 |
| 10 | 37 | Current L3 | float | 1 |
| 11 | 41 | Current L4 | float | 1 |
| 12 | 45 | Effective power L1 | float | 1 |
| 13 | 49 | Effective power L2 | float | 1 |
| 14 | 53 | Effective power L3 | float | 1 |
| 15 | 57 | Effective power L4 | float | 1 |
| 16 | 61 | Cosphi (math.) L1 | float | 1 |
| 17 | 65 | Cosphi (math.) L2 | float | 1 |
| 18 | 69 | Cosphi (math.) L3 | float | 1 |
| 19 | 73 | Cosphi (math.) L4 | float | 1 |
| 20 | 77 | Frequency | float | 1 |
| 21 | 81 | Effective power total L1-L4 | float | 1 |
| 22 | 85 | Reactive power total L1-L4 | float | 1 |
| 23 | 89 | Apparent power total L1-L4 | float | 1 |
| 24 | 93 | Cosphi (math.) total L1-L4 | float | 1 |
| 25 | 97 | Effective current total L1-L4 | float | 1 |
| 26 | 101 | Effective consumption total L1-L4 | float | 1 |
| 27 | 105 | Ind. reactive consum. total L1-L4 | float | 1 |
| 28 | 109 | THD voltage L1 | float | 1 |
| 29 | 113 | THD voltage L2 | float | 1 |
| 30 | 117 | THD voltage L3 | float | 1 |

Profibus profile number 1

| | Byte-Index | Value type | Values format | Scaling |
|----|------------|-----------------------------------|---------------|---------|
| 1 | 1 | Voltage L1-N | Float | 1 |
| 2 | 5 | Voltage L2-N | Float | 1 |
| 3 | 9 | Voltage L3-N | Float | 1 |
| 4 | 13 | Voltage L2-L1 | Float | 1 |
| 5 | 17 | Voltage L3-L2 | Float | 1 |
| 6 | 21 | Voltage L1-L3 | Float | 1 |
| 7 | 25 | Current L1 | Float | 1 |
| 8 | 29 | Current L2 | Float | 1 |
| 9 | 33 | Current L3 | Float | 1 |
| 10 | 37 | Effective power L1 | Float | 1 |
| 11 | 41 | Effective power L2 | Float | 1 |
| 12 | 45 | Effective power L3 | Float | 1 |
| 13 | 49 | Cosphi (math.) L1 | Float | 1 |
| 14 | 53 | Cosphi (math.) L2 | Float | 1 |
| 15 | 57 | Cosphi (math.) L3 | Float | 1 |
| 16 | 61 | Frequency | Float | 1 |
| 17 | 65 | Effective power total L1-L3 | Float | 1 |
| 18 | 69 | Reactive power total L1-L3 | Float | 1 |
| 19 | 73 | Apparent power total L1-L3 | Float | 1 |
| 20 | 77 | Cosphi (math.) total L1-L3 | Float | 1 |
| 21 | 81 | Effective current total L1-L3 | Float | 1 |
| 22 | 85 | Effective consumption total L1-L3 | Float | 1 |
| 23 | 89 | Ind. Reactive consum. total L1-L3 | Float | 1 |
| 24 | 93 | THD voltage L1 | Float | 1 |
| 25 | 97 | THD voltage L2 | Float | 1 |
| 26 | 101 | THD voltage L3 | Float | 1 |
| 27 | 105 | THD current L1 | Float | 1 |
| 28 | 109 | THD current L2 | Float | 1 |
| 29 | 113 | THD current L3 | Float | 1 |

Profibus profile number 2

| | Byte-Index | Value type | Values Format | Scaling |
|----|------------|-----------------------------------|---------------|---------|
| 1 | 1 | Effective consumption total L1-L3 | Float | 1 |
| 2 | 5 | Drawn eff. consum. total L1-L3 | Float | 1 |
| 3 | 9 | Supplied eff. consum. total L1-L3 | Float | 1 |
| 4 | 13 | Reactive consumption total L1-L3 | Float | 1 |
| 5 | 17 | Ind. reactive consum. total L1-L3 | Float | 1 |
| 6 | 21 | Cap. reactive consum. total L1-L3 | Float | 1 |
| 7 | 25 | Apparent consumption total L1-L3 | Float | 1 |
| 8 | 29 | Effective consumption L1 | Float | 1 |
| 9 | 33 | Effective consumption L2 | Float | 1 |
| 10 | 37 | Effective consumption L3 | Float | 1 |
| 11 | 41 | Inductive reactive consumption L1 | Float | 1 |
| 12 | 45 | Inductive reactive consumption L2 | Float | 1 |
| 13 | 49 | Inductive reactive consumption L3 | Float | 1 |

Profibus profile number 3

| | Byte-Index | Value type | Values Format | Scaling |
|----|------------|-----------------------------------|---------------|---------|
| 1 | 1 | Effective power L1 | Float | 1 |
| 2 | 5 | Effective power L2 | Float | 1 |
| 3 | 9 | Effective power L3 | Float | 1 |
| 4 | 13 | Effective power total L1-L3 | Float | 1 |
| 5 | 17 | Current L1 | Float | 1 |
| 6 | 21 | Current L2 | Float | 1 |
| 7 | 25 | Current L3 | Float | 1 |
| 8 | 29 | Current total L1-L3 | Float | 1 |
| 9 | 33 | Effective consumption total L1-L3 | Float | 1 |
| 10 | 37 | CosPhi (math.) L1 | Float | 1 |
| 11 | 41 | CosPhi (math.) L2 | Float | 1 |
| 12 | 45 | CosPhi (math.) L3 | Float | 1 |
| 13 | 49 | CosPhi (math.) total L1-L3 | Float | 1 |
| 14 | 53 | Reactive power L1 | Float | 1 |
| 15 | 53 | Reactive power L2 | Float | 1 |
| 16 | 53 | Reactive power L3 | Float | 1 |
| 17 | 53 | Reactive power total L1-L3 | Float | 1 |
| 18 | 53 | Apparent power L1 | Float | 1 |
| 19 | 53 | Apparent power L2 | Float | 1 |
| 20 | 53 | Apparent power L3 | Float | 1 |
| 21 | 53 | Apparent power total L1-L3 | Float | 1 |

Recordings

2 recordings are preconfigured in the default factory setting of the UMG605. Recordings are adjusted and extended via the software GridVis.

Recording 1

The following measured values are recorded with the time base of 15 minutes:

- Voltage effective L1
- Voltage effective L2
- Voltage effective L3
- Voltage effective L4
- Voltage effective L2-L1
- Voltage effective L3-L2
- Voltage effective L1-L3
- Current effective L1
- Current effective L2
- Current effective L3
- Current effective L4
- Active Power L1
- Active Power L2
- Active Power L3
- Active Power L4
- Active Power Sum L1-L3
- Active Power Sum L1-L4
- Reactive power fundamental L1
- Reactive power fundamental L2
- Reactive power fundamental L3
- Reactive power fundamental L4
- Reactive power fundamental Sum L1-L3

- Reactive power fundamental Sum L1-L4

(The mean value, minimum value and maximum value are also recorded for each measured value.)

Recording 2

The following measured values are recorded with the time base of 1 hour:

- Consumed Active Energy L1
- Consumed Active Energy L2
- Consumed Active Energy L3
- Consumed Active Energy L4
- Consumed Active Energy Sum L1-L3
- Consumed Active Energy Sum L1-L4
- Inductive Reactive Energy L1
- Inductive Reactive Energy L2
- Inductive Reactive Energy L3
- Inductive Reactive Energy L4
- Inductive Reactive Energy Sum L1-L3
- Inductive Reactive Energy Sum L1-L4

Putting into Service

Applying the power supply voltage

The power supply voltage level for the UMG605 is given on the rating plate. Supply voltages which do not correspond to those given on the rating plate can result in malfunctions and destruction of the device.

After applying the power supply voltage the text “Start up” appears in the display. Around two seconds later the UMG605 switches to the first measured value display.

If no display appears, check whether the power supply voltage is within the rated voltage range.

Frequency measurement

For the frequency measurement, the measured voltage must be greater than 10 V in the voltage measuring path L1-N.

Only detected frequencies within the range 15 Hz to 440 Hz are used for measurement at the current and voltage measurement inputs.

Power supply voltage
(see rating plate)



Prior to commissioning potential production dependant contents of the energy counter, min/max values and records have to be deleted.

Applying the measuring-circuit voltage

The UMG605 is suitable for the measurement of voltages of up to 300 V AC to earth and 520 V AC conductor to conductor.


The UMG605 is not suitable for the measurement of direct voltages. Voltages above 300 VAC to earth must be connected via voltage transformers.

After connecting the measurement-current voltages, the measured values displayed by the UMG605 for the L-N and L-L voltages must correspond to those at the voltage measurement input.

If a voltage transformer factor is programmed, this must be taken into account in the comparison.

Minimum voltage

A measuring-circuit voltage greater than $10V_{eff}$ must be applied to the voltage measurement input V1. If an adequately high measuring-circuit voltage is not applied the UMG605 cannot determine the system frequency and can therefore also not take a measurement.



At least one phase (L) and the neutral conductor (N) must be connected to the voltage measurement input for the measurement.

Phase sequence

Check the direction of the voltage rotating field in the measured value display of the UMG605. A “right” rotating field usually exists.

Applying the measuring-circuit current

The UMG605 is designed for the connection of $\dots/1A$ and $\dots/5A$ current transformers. Only alternating currents, not direct currents, can be measured via the current measurement inputs.

Short-circuit all current transformer outputs except one. Compare the currents displayed by the UMG605 with the applied current.

Taking into account the current transformer transformation ratio, the current displayed by the UMG605 must correspond to the input current.

The UMG605 must display approximately zero Amperes in the short-circuited current measurement inputs.

The current transformer ratio is set to $5/5A$ in the factory and if necessary must be adapted to the current transformer used.

Checking the energy measurement

Short-circuit all current transformer outputs except for one and check the displayed power outputs.

The UMG605 may only display one power output in the phase with a non short-circuited current transformer input. If this is not the case, check the connection of the measuring-circuit voltage and the measuring-circuit current.

If the power output amount is correct but the sign of the power output is negative, S1(k) and S2(l) could be inverted at the current transformer or they supply active energy back into the network.

System information

Overrange

Overranges are displayed as long as they exist and cannot be acknowledged. An overrange exists if at least one of the four voltage or current measurement inputs lies outside their specified measuring range.

If an overrange exists it is shown in the display with “EEEE”.

The symbols L1, L2, L3 and L4 are used to indicate at which input the overrange has occurred. The “V” and “A” symbols indicate whether the overrange occurred in the current or in the voltage path.




Fig. Measured value display with overrange.



Important!

Voltages and currents that lie outside the permissible measuring range can destroy the device.

Serial number




Fig. Measured value display with serial number.

Firmware release




Fig. Measured value display for the firmware release.

Date




Fig. Measured value display with date.

Time




Fig. Measured value display with time.

Service and maintenance

The device is subjected to various safety checks before delivery and marked with a seal. If a device is opened, the safety checks must be repeated. A warranty will be provided for unopened devices only.

Repair and calibration

Repair work and calibration can be carried out by the manufacturer only.

Front film

The front film can be cleaned with a soft cloth and standard household cleaning agent. Do not use acids and products containing acid for cleaning.

Battery

The internal clock is provided with power from the power supply voltage. If the power supply voltage fails the clock is supplied by the battery. The clock supplies date and time information, e.g. for recordings, minimum and maximum values and events.

The life expectancy of the battery is at least 5 years, at a storage temperature of +45°C. The typical life expectancy of the battery is 8 to 10 years.

The device must be opened to change the battery. If the device has been opened a renewed safety check is necessary for safe operation. A warranty will be provided for unopened devices only.

Disposal

The UMG605 can be reused or recycled as electronic scrap in accordance with the legal provisions. The permanently installed lithium battery must be disposed of separately.

Firmware update

If a firmware update has to be performed for your UMG605 you can do this with the GridVis software included in the scope of supply.

Service

Should questions arise, which are not described in this manual, please contact the manufacturer directly.

We will need the following information from you to answer any questions:

- Device name (see rating plate),
- Serial name (see rating plate),
- Software release (see measured value display),
- Measuring-circuit voltage and power supply voltage,
- Precise description of the error.

Trouble shooting

| Possible error | Cause | Remedy |
|---|--|---|
| No display . | External fusing for the power supply voltage has tripped. | Replace fuse. |
| | Device is defective. | Send device to the manufacturer for repair. |
| No current display . | Measurement voltage is not connected. | Connect the measuring-circuit voltage. |
| | Measurement current is not connected. | Connect measuring-circuit current. |
| Displayed current is too large or too small. | Current measurement in the wrong phase. Current transformer factor is incorrectly programmed. | Check connection and correct if necessary. Read out and program the current transformer transformation ratio at the current transformer. |
| “EEEE” and “A” in the display. | The current measuring range has been exceeded. | Check the measuring-circuit current and if necessary install a suitable current transformer. |

| Possible error | Cause | Remedy |
|---|---|---|
| Displayed voltage is too small or too large. | Measurement in the wrong phase. Voltage transformer incorrectly programmed. | Check connection and correct if necessary. Read out and program the voltage transformer transformation ratio at the voltage transformer. |
| Displayed voltage is too small. | Overrange. The peak voltage value at the measurement input has been exceeded by harmonic components. | Install voltage transformers. Important! Ensure the measurement inputs are not overloaded. |
| “EEEE” and “V” in the display. | The voltage measuring range has been exceeded. | Check the measuring-circuit voltage and if necessary install a suitable voltage transformer. |
| „Error CF„ in the display | The calibration data could not be read out. | Send device to the manufacturer for checking with a precise description of the error. |

| Possible error | Cause | Remedy |
|---|--|---|
| Active power too small or too large. | <p>The programmed current transformer transformation ratio is incorrect.</p> <p>The current path is assigned to the wrong voltage path.</p> <p>The programmed voltage transformer transformation ratio is incorrect.</p> | <p>Read out and program the current transformer transformation ratio at the current transformer.</p> <p>Check connection and correct if necessary.</p> <p>Read out and program the voltage transformer transformation ratio at the voltage transformer.</p> |
| Active power consumption / supply is reversed. | <p>At least one current transformer connection is mixed up/reversed.</p> <p>A current path is assigned to the wrong voltage path.</p> | <p>Check connection and correct if necessary.</p> <p>Check connection and correct if necessary.</p> |
| No connection with the device. | <p>RS485:</p> <ul style="list-style-type: none"> - Device address is incorrect. - Wrong protocol. - Termination missing. <p>Ethernet:</p> <ul style="list-style-type: none"> - IP address incorrect - The concealed key (service) was used. | <p>Adjust the device address.</p> <p>Select protocol.</p> <p>Close bus with terminating resistor (120 ohm).</p> <p>Adjust IP address at the device.</p> <p>Overwriting the address 204 with 0 and set IP address or select DHCP/Zeroconf (address 205).</p> |

| Possible error | Cause | Remedy |
|--|----------------------|---|
| Despite the measures above the device does not work. | Device is defective. | Send device to the manufacturer for checking with a precise description of the error. |

Technical specifications

General information

| | |
|----------------------------|--|
| Net weight | : 350g |
| Device dimensions | : approx l=107.5 mm, b=90 mm, h=82 mm (according to DIN 43871:1992) |
| Housing flammability class | : UL94V-0 |
| Installed position | : any |
| Fixing/mounting | : 35 mm top hat rail (according to IEC/EN 60999-1, DIN EN 50022) |
| Battery | : Type lithium CR2032, 3 V |

Ambient conditions during operation

The UMG605 is intended for weather-protected, stationary use. The UMG605 fulfils the use conditions according to DIN IEC 60721-3-3.

| | |
|-----------------------------|---|
| Operating temperature range | : -10°C. +55°C |
| Relative humidity | : 5 to 95 %, (at +25 °C) without condensation |
| Degree of pollution | : 2 |
| Operating altitude | : 0 .. 2000 m above sea level |
| Installed position | : any |
| Ventilation | : Forced ventilation is not required. |

Transport and storage

The following information applies to devices which are transported or stored in the original packaging.

| | |
|-------------|------------------|
| Free fall | : 1m |
| Temperature | : -20°C to +70°C |

Power supply voltage

The power supply voltage must be connected to the UMG605
via a UL listed fuse : 6A, type C (approved to UL / IEC)

Option 230V

Nominal range : 95V .. 240V (45-65 Hz) or DC 135V .. 340V
Operating range : +-10% of nominal range
Installation overvoltage category : 300V CATIII
Power consumption : max 3.2W, max 9VA

Option 90V

Nominal range : 50V .. 110V (45-65 Hz) or DC 50V .. 155V
Operating range : +-10% of nominal range
Installation overvoltage category : 300V CATII
Power consumption : max 3.2W, max 9VA

Option 24V

Nominal range : 20V .. 50V (45-65 Hz) or DC 20V .. 70V
Operating range : +-10% of nominal range
Installation overvoltage category : 300V CATII
Power consumption : max 5W, max 8VA

Connectable conductors

Only one conductor may be connected per terminal connection!

Solid core, multi-core, flexible core : 0.08 - 2,5 mm², AWG 28 - 12
Pin-end connector, wire end ferrules : 1.5 mm², AWG 16

Protection class

Class II according to IEC 60536 (VDE 0106, Part 1), i.e. a PE terminal is not required!

Protection against ingress of solid foreign
bodies and water

: IP20 according to EN 60529 September 2000,
IEC 60529:1989

Inputs and outputs

2 digital inputs

Pulse input (S0)

Maximum counting frequency : 20 Hz

Switching input

Response time (Jasic program) : 200 ms

Input signal applied : 18V .. 28 V DC (typically 4 mA)

Input signal not applied : 0 .. 5 V DC, current less than 0.5 mA

2 digital outputs, semi-conductor relay, not short-circuit proof.

Switching voltage : max 60 V DC, 30 V AC

Switching current : max 50 mAeff AC/DC

Response time (Jasic program) : 200 ms

Output of voltage dips : 20 ms

Output of voltage overranges : 20 ms

Pulse output (operating pulses) : max 20 Hz

Cable length : up to 30 m unshielded
: greater than 30m shielded

Connectable conductors

Solid core, multi-core, flexible core : 0.08 - 1.5 mm²

Pin-end connector, wire end ferrules : 1 mm², only one conductor may connected per terminal connection!

Temperature measurement input

| | |
|-------------------------------|-------------------------------|
| Update time | : approx 200 ms |
| Connectable sensors | : PT100, PT1000, KTY83, KTY84 |
| Total burden (sensor + cable) | : max 4 kohm |

| Sensor type | Temperature range | Resistance range | Measurement uncertainty |
|-------------|-------------------|---------------------|-------------------------|
| KTY83 | -55 ° .. +175 °C | 500 ohm .. 2.6 kohm | ± 1.5% rng |
| KTY84 | -40 ° .. +300 °C | 350 ohm .. 2.6 kohm | ± 1.5% rng |
| PT100 | -99 ° .. +500 °C | 60 ohm .. 180 ohm | ± 1.5% rng |
| PT1000 | -99 ° .. +500 °C | 600 ohm .. 1,8 kohm | ± 1.5% rng |

rng = measuring range

| | |
|---------------------------------------|--|
| Cable length | : up to 30 m unshielded : greater than 30 m shielded |
| Connectable conductors | |
| Solid core, multi-core, flexible core | : 0.08 - 1.5 mm ² |
| Pin-end connector, wire end ferrules | : 1 mm ² , only one conductor may be connected per terminal connection! |

Interfaces

| | | |
|------------------------|--|--|
| RS232 | | : 5 pin screw-type terminals. |
| Protocol | | : Modbus RTU/slave |
| Transfer rate | | 9600 bps, 19.2 kbps, 38.4 kbps, 115.2 kbps |
| RS485 | | : 2 pin screw-type terminals. |
| Protocol, modbus RTU | | : Modbus RTU/slave, modbus RTU/master |
| Transfer rate | | : 9.6 kbps, 19.2 kbps, 38.4 kbps, 57.6 kbps, 115.2 kbps, 921.6 kbps |
| RS485 | | : Connector, SUB D 9 pin |
| Protocol, profibus | | : Profibus DP/V0 according to EN 50170 |
| Transfer rate | | : 9.6 kbaud up to 12 Mbaud |
| Ethernet 10/100Base-TX | | |
| Connection | | : RJ-45 |
| Functions | | : Modbus gateway, embedded web server (HTTP) |
| Protocols | | : TCP/IP, EMAIL (SMTP), DHCP-Client (BootP), Modbus/TCP(Port 502), ICMP (Ping), NTP, TFTP, Modbus RTU over Ethernet (Port 8000), FTP, SNMP. |

Function parameters

- Measurement using current converters ../5A
- Measurements at 50/60 Hz

| Function | Symbol | Accuracy class | Measurem. range | Display range |
|-----------------------------------|---------------------------------------|-------------------------------------|---------------------|----------------------|
| Total effective power | P | 0.5 ⁹⁾ (IEC61557-12) | 0 .. 15.3kW | 0 W .. 9999 GW |
| Total reactive power | QA ⁶⁾ , Qv ⁶⁾ | 0.5 ⁹⁾ (IEC61557-12) | 0 .. 15.3 kvar | 0 varh .. 9999 Gvarh |
| Total apparent power | SA, Sv ⁶⁾ | 0.5 ⁹⁾ (IEC61557-12) | 0 .. 15.3 kVA | 0 VA .. 9999 GVA |
| Total effective energy | Ea | 0.5S ^{9) 7)} (IEC61557-12) | 0 .. 15.3 kWh | 0 Wh .. 9999 GWh |
| Total reactive energy | ErA ⁶⁾ , ErV ⁶⁾ | 1 ⁵⁾ (IEC61557-12) | 0 .. 15.3 kvarh | 0 varh .. 9999 Gvarh |
| Total apparent energy | EapA, EapV ⁶⁾ | 0.5 ⁹⁾ (IEC61557-12) | 0 .. 15.3 kVAh | 0 VAh .. 9999 GVAh |
| Frequency | f | 0.05 (IEC61557-12) | 40 .. 70 Hz | 40 Hz .. 70 Hz |
| Phase current | I | 0.25 ⁸⁾ (IEC61557-12) | 0.001 .. 8.5 Arms | 0 A .. 9999 kA |
| Neutral cond. current measured | IN | 0.25 ⁸⁾ (IEC61557-12) | 0.001 .. 8.5 Arms | 0 A .. 9999 kA |
| Neutral cond. current calculated | INc | 1 (IEC61557-12) | 0.001 .. 25.5 A | 0 A .. 9999 kA |
| Voltage | U L-N | 0.2 (IEC61557-12) | 10 .. 600 Vrms | 0 V .. 9999 kV |
| Voltage | U L-L | 0.2 (IEC61557-12) | 18 .. 1000 Vrms | 0 V .. 9999 kV |
| Power factor | PFA, PFV | 0.5 (IEC61557-12) | 0.00 .. 1.00 | 0 .. 1 |
| Short-time flicker, long-time fl. | Pst, Plt | Cl. A (IEC61000-4-15) | 0.4 Pst to 10.0 Pst | 0 .. 10 |
| Voltage drops | Udip | 0.2 (IEC61557-12) | 10 .. 600 Vrms | 0 V .. 9999 kV |
| Voltage rises | Uswl | 0.2 (IEC61557-12) | 10 .. 600 Vrms | 0 V .. 9999 kV |
| Transient overvoltages | Utr | 0.2 (IEC61557-12) | 10 .. 600 Vrms | 0 V .. 9999 kV |
| Voltage interruptions | Uint | Duration +- 1 cycle | - | - |
| Voltage inbalance ¹⁾ | Unba | 0.2 (IEC61557-12) | 10 .. 600 Vrms | 0 V .. 9999 kV |
| Voltage inbalance ²⁾ | Unb | 0.2 (IEC61557-12) | 10 .. 600 Vrms | 0 V .. 9999 kV |
| Voltage harmonics | Uh | Cl. 1 (IEC61000-4-7) | to 25 kHz | 0 V .. 9999 kV |

| Function | Symbol | Accuracy class | Measur. range | Display range |
|--|--------|-----------------------|--------------------------------------|----------------|
| THD of voltage ³⁾ | THDu | 1.0 (IEC61557-12) | to 2.5 kHz | 0 % .. 999 % |
| THD of voltage ⁴⁾ | THD-Ru | 1.0 (IEC61557-12) | to 2.5 kHz | 0 % .. 999 % |
| Current harmonics | Ih | Cl. 1 (IEC61000-4-7) | to 2.5 kHz | 0 A .. 9999 kA |
| THD of current ³⁾ | THDi | 1.0 (IEC61557-12) | to 2.5 kHz | 0 % .. 999 % |
| THD of current ⁴⁾ | THD-Ri | 1.0 (IEC61557-12) | to 2.5 kHz | 0 % .. 999 % |
| Mains signal voltage (voltage inter-harmonics) | MSV | IEC 61000-4-7 Class 1 | 10% – 200% von IEC 61000-2-4 Class 3 | 0 V .. 9999 kV |

- Measurement using current converters .../5A
- Measurements at 15 Hz ...440 Hz

| Function | Symbol | Accuracy class | Measur. range | Display range |
|--------------------------------|---------------------------------------|-------------------------------|-------------------|----------------------|
| Total effective power | P | 1 ⁵⁾ (IEC61557-12) | 0 .. 15.3kW | 0 W .. 9999 GW |
| Total reactive power | QA ⁶⁾ , Qv ⁶⁾ | 1 ⁵⁾ (IEC61557-12) | 0 .. 15.3 kvar | 0 varh .. 9999 Gvarh |
| Total apparent power | SA, Sv ⁶⁾ | 1 ⁵⁾ (IEC61557-12) | 0 .. 15.3 kVA | 0 VA .. 9999 GVA |
| Total effective energy | Ea | 1 ⁵⁾ (IEC61557-12) | 0 .. 15.3 kWh | 0 Wh .. 9999 GWh |
| Total reactive energy | ErA ⁶⁾ , ErV ⁶⁾ | 2 ⁵⁾ (IEC61557-12) | 0 .. 15.3 kvarh | 0 varh .. 9999 Gvarh |
| Total apparent energy | EapA, EapV ⁶⁾ | 1 ⁵⁾ (IEC61557-12) | 0 .. 15.3 kVAh | 0 VAh .. 9999 GVAh |
| Frequency | f | 0.05 (IEC61557-12) | 15 .. 440 Hz | 15 Hz .. 440 Hz |
| Phase current | I | 0.5 (IEC61557-12) | 0.001 .. 8.5 Arms | 0 A .. 9999 kA |
| Neutral cond. current measured | IN | 0.5 (IEC61557-12) | 0.001 .. 8.5 Arms | 0 A .. 9999 kA |

| Function | Symbol | Accuracy class | Measurem. range | Display range |
|-----------------------------------|----------|----------------------|-----------------------------|----------------|
| Neutral cond. current calculated | INc | 1.5 (IEC61557-12) | 0.001 .. 25.5 A | 0 A .. 9999 kA |
| Voltage | U L-N | 0.5 (IEC61557-12) | 10 .. 600 V _{rms} | 0 V .. 9999 kV |
| Voltage | U L-L | 0.5 (IEC61557-12) | 18 .. 1000 V _{rms} | 0 V .. 9999 kV |
| Power factor | PFA, PFV | 2 (IEC61557-12) | 0.00 .. 1.00 | 0 .. 1 |
| Short-time flicker, long-time fl. | Pst, Plt | - | - | - |
| Voltage drops | Udip | 0.5 (IEC61557-12) | 10 .. 600 V _{rms} | 0 V .. 9999 kV |
| Voltage rises | Uswl | 0.5 (IEC61557-12) | 10 .. 600 V _{rms} | 0 V .. 9999 kV |
| Transient overvoltages | Utr | 0.5 (IEC61557-12) | 10 .. 600 V _{rms} | 0 V .. 9999 kV |
| Voltage interruptions | Uint | Duration +- 1 Zyklus | - | - |
| Voltage inbalance ¹⁾ | Unba | 0.5 (IEC61557-12) | 10 .. 600 V _{rms} | 0 V .. 9999 kV |
| Voltage inbalance ²⁾ | Unb | 0.5 (IEC61557-12) | 10 .. 600 V _{rms} | 0 V .. 9999 kV |
| Voltage harmonics | Uh | Cl. 2 (IEC61000-4-7) | bis 2.5 kHz | 0 V .. 9999 kV |
| THD of voltage ³⁾ | THDu | 2.0 (IEC61557-12) | bis 2.5 kHz | 0 % .. 999 % |

Explanations

- 1) Reference to amplitude.
- 2) Reference to phase and amplitude.
- 3) Reference to basic oscillation
- 4) Reference to effective value.
- 5) The accuracy class will degrade by one step when measured with a ..1A-current transformer.
- 6) Calculation from fundamental harmonic oscillation.
- 7) Precision class 0.5S per IEC62053-22
- 8) Based on IEC61557-12

Specifications for IEC 61000-4-30 Class S

| Parameter | Uncertainty | Measuring Range |
|---------------------------------------|--|---|
| 5.1 Frequency | ± 50 mHz | 42.5 Hz – 57.5 Hz, 51 Hz – 69 Hz |
| 5.2 Magnitude of Supply Voltage | $\pm 0.5\%$ of U_{din} | 20% – 120% of U_{din} |
| 5.3 Flicker | $\pm 5\%$ of reading | 0.4 – 4.0 Pst |
| 5.4 Supply Voltage Dips and Swells | Magnitude: $\pm 1\%$ of U_{din} Duration: ± 1 cycle | N/A |
| 5.5 Spannungsunterbrechungen | Duration: ± 1 Periode | N/A |
| 5.7 Unbalance | $\pm 0.3\%$ | 1% – 5% u_2 1% – 5% u_0 |
| 5.8 Harmonics | IEC 61000-4-7 Class 2 | 10% – 100% of Class 3 of IEC 61000-2-4 |
| 5.9 Interharmonics | IEC 61000-4-7 Class 2 | 10% – 200% of Class 3 of IEC 61000-2-4 |
| 5.10 Mains Signaling Voltage | 3% – 15% of U_{din} , $\pm 5\%$ of U_{din} | 3% – 15% of U_{din} |
| 5.12 Underdeviation and Overdeviation | $\pm 0.5\%$ of U_{din} | 10% – 150% of U_{din} |

The UMG605 meets IEC 61000-4-30 Class S requirements for:

- Aggregations, Time Clock Uncertainty, Flagging, Transient Influence Quantities

Measuring inputs

Voltage measurement

| | |
|--------------------------------------|-----------------------------|
| Three-phase 4-wire systems (L-N/L-L) | : max. 277 V/480 V |
| Three-phase 3-wire systems (L-L) | : max. 480 V |
| Resolution | : 0,01 V |
| Crest-faktor | : 2 (referring to 480 Vrms) |
| Measurement category | : 300V CAT III |
| Specified impulse withstand voltage | : 4 kV |
| Impedance | : 4 MOhm/phase |
| Power input | : approx 0.1 VA |
| Scanning frequency | : 20 kHz/phase |
| Transients | : >50 μ s |
| Fundamental oscillation | : 15 Hz .. 440 Hz |
| Resolution | : 0,001 Hz |

Connectable conductors (current measurement and voltage measurement)

Only one conductor may connected per terminal connection.

Solid core, multi-core, flexible core : 0.08 - 4 mm², AWG 28 - 12

Pin-end connector, wire end ferrules : 2.5 mm², AWG 14

Current measurement

| | |
|-------------------------------------|-----------------------------|
| Nominal current | : 5A |
| Rated current | : 6A |
| Resolution in the display | : 10mA |
| Crest-faktor | : 2 (referring to 6 Arms) |
| Measurement category | : 300 V CAT III |
| Specified impulse withstand voltage | : 4 kV |
| Power input | : approx 0.2 VA (Ri=5 mohm) |
| Overload for 1 sec | : 100 A (sinusoidal) |
| Scanning frequency | : 20 kHz |

Appendix

Parameter list

| Add | Format | Name | Setting range | Units | Default setting |
|-----|--------|--|---------------|-------|-----------------|
| 000 | float | Current transformer, primary, L1..L3 | 0 .. 1000000 | A | 5 |
| 001 | float | Current transformer, secondary, L1..L3 | 1 .. 5 | A | 5 |
| 002 | float | Voltage transformer, primary, L1..L3 | 0 .. 1000000 | V | 400 |
| 003 | float | Voltage transformer, secondary, L1..L3 | 1 .. 480 | V | 400 |
| 010 | float | Current transformer, primary, L4 | 0 .. 1000000 | A | 5 |
| 011 | float | Current transformer, secondary, L4 | 1 .. 5 | A | 5 |
| 012 | float | Voltage transformer, primary, L4 | 0 .. 1000000 | V | 400 |
| 013 | float | Voltage transformer, secondary, L4 | 1 .. 480 | V | 400 |

| Add | Format | Name | Setting range | Units | Default setting |
|-----|--------|--|------------------|--------|-----------------|
| 100 | int | Automatically get TFTP configuration file 0 = switched off x = file number | 0 .. 9999 | - | 0 |
| 101 | int | TFTP error handling 0 = In the event of an error the Configuration menu appears in the UMG605. 1 = In the event of an error the does NOT switch to the Configuration menu of the UMG605. | 0 .. 1 | - | 0 |
| 110 | short | Current transformer circuit (L1 .. L3) 0=4w3m, 1=4w2m, 2=4w2u, 3=4w2i, 4=3w3m, 5=3w2m, 6=3w2u, 7=3w2i, 8=2w2m, 9=2w1m, 10=4w3m,11=4w2m, 12=3w2u, 13=3w2m) | 0 .. 1 | - | 0 |
| 111 | short | Voltage measurement system configuration 0=2w1n, 1=3w1m, 2=4w1m | 0 .. 1 | - | 0 |
| 112 | short | Relevant voltage 0 = L-N, 1 = L-L | 0 .. 1 | - | 0 |
| 113 | short | Deletes all real and apparent energy meters and S0-counters (1 = delete) | 0 .. 1 0 .. 1 | - - | 0 0 |
| 114 | short | Deletes all reactive energy meters (1 = delete) | 0 .. 1 | - | 0 |
| 115 | short | Resets all minimum and maximum values (1 = reset) | 0 .. 1 | - | 0 |
| 116 | short | Flickerfilter 0 - 50Hz/230V, 1 - 120V/50Hz 2 - 230V/60Hz, 3 - 120V/60Hz | 0 .. 3 | - | 0 |

| Add | Format | Name | Setting range | Units | Default setting |
|-----|--------|---|---------------|-------|-----------------|
| 200 | int | Device address, modbus/profibus | 1 .. 255 | - | 1 |
| 201 | int | Baud rate, RS232 0 = 9600 bit/s 1 = 19200 bit/s 2 = 38400 bit/s 3 = 57600 bit/s 4 = 115200 bit/s | 0 .. 4 | - | 4 |
| 202 | int | Baud rate, RS485 0 = 9600 bit/s 1 = 19200 bit/s 2 = 38400 bit/s 3 = 57600 bit/s 4 = 115200 bit/s 5 = 921600 bit/s | 0 .. 5 | - | 4 |
| 203 | int | RS485, mode 0 = modbus RTU/slave 1 = modbus RTU/master 2 = gateway transparent | 0 .. 6 | - | 0 |
| 204 | int | RS232, mode 0 = modbus RTU/slave 3 = Debug 6 = SLIP | 0 .. 6 | - | 0 |

| Add | Format | Name | Setting range | Units | Default setting |
|-----|--------|---|---------------|-------|-----------------|
| 205 | int | DHCP mode 0 = fixed IP 1 = BootP 2 = DHCP-Client 3 = Zeroconf | 0, 1, 2, 3 | - | 2 |
| 300 | int | IP address, xxx --- --- --- | 0 .. 255 | - | 000 |
| 301 | int | IP address, --- xxx --- --- | 0 .. 255 | - | 000 |
| 302 | int | IP address, --- --- xxx --- | 0 .. 255 | - | 000 |
| 303 | int | IP address, --- --- --- xxx | 0 .. 255 | - | 000 |
| 304 | int | IP mask, xxx --- --- --- | 0 .. 255 | - | 000 |
| 305 | int | IP mask, --- xxx --- --- | 0 .. 255 | - | 000 |
| 306 | int | IP mask, --- --- xxx --- | 0 .. 255 | - | 000 |
| 307 | int | IP mask, --- --- --- xxx | 0 .. 255 | - | 000 |
| 310 | int | IP gateway, xxx --- --- --- | 0 .. 255 | - | 000 |
| 311 | int | IP gateway, --- xxx --- --- | 0 .. 255 | - | 000 |
| 312 | int | IP gateway, --- --- xxx --- | 0 .. 255 | - | 000 |
| 313 | int | IP gateway, --- --- --- xxx | 0 .. 255 | - | 000 |

| Add | Format | Name | Setting range | Units | Default setting |
|-----|--------|---|---------------|-------|-----------------|
| 400 | short | Day | 1 .. 31 | - | xx |
| 401 | short | Month | 1 .. 12 | - | xx |
| 402 | short | Year | 1 .. 9999 | - | xxxx |
| 403 | short | Hour | 0 .. 23 | - | xx |
| 404 | short | Minute | 0 .. 59 | - | xx |
| 405 | short | Second | 0 .. 59 | - | xx |
| 406 | short | Accept date and time 1 = accept set data | 0, 1 | - | 0 |
| 500 | int | Device password | 0 .. 9999 | - | xxxx |
| 501 | int | Homepage, password mode 0, 2, 128, 130 | 0 .. 9999 | - | 0 |
| 502 | int | Homepage, password | 0 .. 9999 | - | xxxx |
| 510 | pw1 | Activate "EMAX" option, licence part 1 | 0 .. 999 | - | xxx |
| 511 | pw2 | Activate "EMAX" option, licence part 2 | 0 .. 999 | - | xxx |
| 520 | pw1 | Activate "BACnet" option, licence part 1 | 0 .. 999 | - | xxx |
| 521 | pw2 | Activate "BACnet" option, licence part 2 | 0 .. 999 | - | xxx |
| 600 | int | LCD contrast | 0 .. 99 | - | 50 |
| 601 | int | LCD backlight, max. brightness | 0 .. 16 | - | 10 |
| 602 | int | LCD backlight, min. brightness | 0 .. 8 | - | 3 |
| 603 | int | LCD backlight, on-time | 0 .. 9999 | sec | 60 |

Measured value displays

You can have the following measured values shown on the display, with the default factory setting, using keys 1 and 2. The measured value names used are abbreviated and have the following meaning:

- Active power demand = active power demand, imported supply
- Reactive power = reactive power, inductive
- Active power demand = active power demand, imported supply with return block


| | | | | | |
|--------------------------|-------------------------|-------------------------|-------------------------|-----------------------------|-----------------------------|
| Voltage L1-N | Voltage L2-N | Voltage L3-N | Voltage L4-N | | |
| Voltage L1-L2 | Voltage L2-L3 | Voltage L3-L1 | | | |
| Current L1 | Current L2 | Current L3 | Current L4 | | |
| Active Power demand L1 | Active Power demand L2 | Active Power demand L3 | Active Power demand L4 | Active Power demand L1..L3 | Active Power demand L1..L4 |
| Reactive Power L1 | Reactive Power L2 | Reactive Power L3 | Reactive Power L4 | Reactive Power L1..L3 | Reactive Power L1..L4 |
| Active Energy demand L1 | Active Energy demand L2 | Active Energy demand L3 | Active Energy demand L4 | Active Energy demand L1..L3 | Active Energy demand L1..L4 |
| cos(phi) L1 | cos(phi) L2 | cos(phi) L3 | cos(phi) L4 | cos(phi) L1..L3 | |
| Frequency Rotating field | Temperature input | Date | Time | Serial number | Firmware Release |

Declaration of conformity


| | |
|---|---|
| The product fulfils the following EC Directives: | |
| 2004/108/EG | Electromagnetic compatibility of electrical equipment. |
| 2006/95/EG | Electrical equipment for use within certain voltage limits. |
| Considered standards: | |
| Noise immunity IEC/EN 61326-1:2013 IEC/EN 61000-4-2:2009 IEC/EN 61000-4-3:2011 IEC/EN 61000-4-4:2013 IEC/EN 61000-4-5:2007 IEC/EN 61000-4-6:2009 IEC/EN 61000-4-8:2010 IEC/EN 61000-4-11:2005 | Class A: Industrial environment Electrostatic discharge Electromagnetic RF Field 80-2700MHz Burst Surge Conducted disturbances 0.15-80MHz Power frequency magnetic field Voltage dips, short interrupts and voltage variations |
| Noise emission IEC/EN 61326-1:2013 IEC/CISPR11/EN 55011:2011 IEC/CISPR11/EN 55011:2011 | Class B: Residential environment Radio disturbance field strength 30-1000MHz Radio disturbance voltage 0.15-30MHz |
| Equipment safety IEC/EN 61010-1:2011 | Safety requirements for electrical equipment for Measurement, control and laboratory use – Part 1: General requirements |
| IEC/EN 61010-2-030:2011 | Particular requirements for testing and measuring circuits |

Dimensioned drawings


Front view



Side view



UMG605 connection example



Quick Reference Instructions

Adjusting the primary current

You have three current transformers of the same type with a current transformer ratio of 200 A/5 A.

You would like to program the primary current with 200 A.

To do this you must enter the value 200 for the primary current in the address 000.


The secondary current is preset to 5 A in address 001 in the factory.

Switch to Program mode

Simultaneously press keys 1 and 2 for around one second.

The PRG symbol for programming mode appears.

The content of address 000 is displayed.



Change address

As address 000 is already displayed the address does not have to be changed.

Enter the primary current.

Use Key 1 to select the digit to be changed.

Use Key 2 to change the selected digit.

Exit program mode

Simultaneously press both keys for around 1 second.

The current transformer setting is saved and the device returns to display mode.

