



## On-line UPS **Fuji Medium-capacity UPS** UPS5000CF Series

# Three-phase 10 to 160kVA UPS5000CF



## High Performance and Wide Products Line UP

#### **Main features**


- Online double conversion
- IGBT inverter and output isolation transformer
- 3 phases UPS allow 100 % unbalance load
- Fully DSP control, high reliability and performance
- Wide input voltage range
- DC cold start function
- Advanced battery charging management
- Intelligent fan speed control
- ECO mode and EPO function
- Intelligent RS-232/RS-485 communication port
- 12 Pulse rectifier (optional)
- Bypass isolation transformer (optional)

#### Application

Computer room, Data center, Precision instrument, Intelligent equipment



#### Principle diagram



Model No. designation

UPS5000CF -	<u>T4</u> /	
1	2	3
1 Fuji UPS series		

- 2 Three phase, 4 wire
- ③ Output capacity [kVA]

## Fuji Medium-capacity UPS UPS5000CF Series

### Specification

Series		UPS5000CF series										
Model		T4/10	T4/20	T4/30	T4/40	T4/50	T4/60	T4/80	T4/100	T4/120	T4/160	
Input	Voltage(Vac)	380/400±20 %										
	Rectifier Frequency	40 to 65										
	SYNC Frequency Tracking	50/60±5 % (±10 % optional)										
	Phase	3 ¢ 4w+PE										
Output	Capacity[kVA/kW]	10/8	20/16	30/24	40/32	50/40	60/48	80/64	100/80	120/96	160/128	
	Phase	3 ¢ 4w+PE										
	Voltage(Vac)	L-N: 220/230±1 %, L-L:380/400±1 %										
	Frequency[Hz]	50/60±0.5	50/60±0.5 % (battery mode)									
	Waveform	Pure sine	Pure sine wave, THD≤3 % (linear load)									
	3 Phases 100 % Load Unbalance Voltage Stability	≤2 %, allow 100 % unbalance										
	Overload	110 % load for 30 mins, 125 % load for 10 mins, 150 % load for 1 min.										
Battery	Voltage (Vdc)	12 V x 29=348										
	ВАТТ Туре	External										
	Charger Current(A)Max	10 to 40 A setting										
	Battery Self-testing	Automatically alarm and estimate battery status in battery abnormal status										
Other	Maintenance Bypass	Yes										
	Communication Interface	RS-232/RS-485 and dry contactor(MODBUS and SNMP adapter are optional)										
	Display	LCD Display indicates frequency, voltage, load, battery voltage, etc. LED indicates running status										
	Alarm	Overload, abnormal AC input, low battery, UPS failure										
	Protection	Low battery, overload, over temperature, short circuit, output over voltage, output low voltage										
	Noise[dB]	<65										
	Working Temperature	0 to 40 °C										
	Relative Humidity	0 to 95 %, No condensation										
	Dimension(W x D x H)	500 x 800 x 1180 800 x 800 x 1600 1000 x 800 x 1800										
	Mass[kg]	195	240	290	450	470	490	690	725	775	905	

#### Battery run time

Model	Backup	Battery		Rack		Mass
	time		Q'ty	No.	Q'ty	[kg]
UPS5000CF-T4/10	30min	24AH/12V	29	B16	1	303
	60min	38AH/12V	29	B16	1	448
UPS5000CF-T4/20	15min	24AH/12V	29	B16	1	303
	20min	38AH/12V	29	B16	1	448
	40min	65AH/12V	29	B16	2	722
UPS5000CF-T4/30	15min	38AH/12V	29	B16	1	448
	25min	65AH/12V	29	B16	2	722
	45min	100AH/12V	29	B16	2	1041
	60min	65AH/12V	29 x 2	B16	4	1444
UPS5000CF-T4/40	15min	65AH/12V	29	B16	2	722
	30min	100AH/12V	29	B16	2	1041
	40min	65AH/12V	29 x 2	B16	4	1444
UPS5000CF-T4/50	20min	100AH/12V	29	B16	2	1041
	60min	100AH/12V	29 x 2	B16	4	2082
UPS5000CF-T4/60	15min	100AH/12V	29	B16	2	1041
	25min	65AH/12V	29 x 2	B16	4	1444
	45min	100AH/12V	29 x 2	B16	4	2082
UPS5000CF-T4/80	15min	65AH/12V	29 x 2	B32	2	1496
	30min	100AH/12V	29 x 2	B32	2	2134
	50min	100AH/12V	29 x 3	B32	3	3201

ľ	Model Backup		Battery	Rack		Mass	
		time	Capacitor/ voltage	Q'ty	No.	Q'ty	[kg]
ι	JPS5000CF-T4/100	20min 40min 60min	100AH/12V 100AH/12V 100AH/12V	29 x 2 29 x 3 29 x 4	B32 B32 B32	2 3 4	2134 3201 4268
ι	JPS5000CF-T4/120	18min 30min 45min 60min	100AH/12V 100AH/12V 100AH/12V 100AH/12V	29 x 2 29 x 3 29 x 4 29 x 5	B32 B32 B32 B32	2 3 4 5	2134 3201 4268 5335
ι	JPS5000CF-T4/160	12min 20min 30min 40min	100AH/12V 100AH/12V 100AH/12V 100AH/12V	29 x 2 29 x 3 29 x 4 29 x 5	B32 B32 B32 B32	2 3 4 5	2134 3201 4268 5335

#### **Battery rack**

	Dimension(W x D x H)
B16	470 x 800 x 1177 mm
B32	1000 x 800 x 1600 mm

## **Fuji Sales Network**

Fuji Electric Asia Pacific Pte. Ltd. 171, Chin Swee Rd., #12-01, San Centre, SINGAPORE 169877	TEL: +65-6533-0010
<b>PT Fuji Electric Indonesia</b> Wisma Keiai, 17th Floor Jl. Jend. Sudirman Kav. 3, Jakarta 10220, INDONESIA	TEL: +62-21-572-4281
Fuji Electric Co., Ltd. Hanoi Representative office 204 Unit, 2nd Floor, Tung Shing Square, Ngo Quyen Street, Hoan Kiem Dist, Hanoi, VIETNAM	TEL: +84-4-3935-1593
Fuji Electric (Thailand) Co., Ltd. 889 Thai CC Tower, 11F, Room No. 114-6 South Sathorn Rd, Yannawa, Sathorn, Bangkok 10120, THAILAND	TEL: +66-2210-0615
<b>Fuji Electric India Pvt. Ltd.</b> 409 410, Meadows, Sahar Plaza, Andheri Kurla Road, J.B. Nagar, Andheri (E) Mumbai 400 059, INDIA	TEL: +91-22-4010-4870

#### Installation Conditions

#### • This unit is designed to be used indoors.

- Do not install in a place exposed to direct sunlight, wind or rain.
  Avoid a dusty, hot and/or humid place.
- Our UPS is designed to work in a temperature range of 0 to +40°C. However, we recommend that it be used at +25°C or lower to ensure stable operation over the entire life of the UPS.
- System multiplexing, installation of an emergency generator set, and special measures for operation, maintenance and control are required when the system is to be used for the following applications. Contact us in such cases.
  - · Medical equipment that directly affects human life
  - Equipment that may cause personal injury
- Computer systems of social or public importance

Even if a trouble occurs due to use of this product (hardware/software), Fuji Electric will not compensate for any damages whatsoever, including damages caused by an error or trouble of connected equipment and software, and other secondary damages.

\* The product names and company names used in this catalog are trademarks or registered trademarks of the respective companies.

#### Printed on recycled paper

#### For Fuji Electric Co., Ltd.

171, Chin Swee Rd., #12-01, San Centre, SINGAPORE 169877 Phone : 65-6533-0010

FC Fuji Electric Asia Pacific Pte. Ltd.

Gate City Ohsaki, East Tower, 11-2, Osaki 1-chome, Shinagawa-ku, Tokyo 141-0032, Japan

Information in this catalog is subject to change without notice.