# **inter<sub>sil</sub>**

# Evaluation Hardware/Software Manual for ALS and Proximity Sensor

http://www.intersil.com/lightsensor/

# **Ambient Light Sensor Products**

ISL29011 FAMILY					
	ALS	IR	PROXIMITY		
ISL29011	X	X	x		
ISL29018	X	X	x		
ISL29021		X	x		
ISL29023	X	X			
ISL29033	X	X			
ISL29028 FAMILY					
ISL29027			x		
ISL29028/ISL29028A	x	X	x		
ISL29030/ISL29030A	X	X	x		
ISL29040/ISL29042	X	X	x		
STAND ALONE					
ISL29020	X	X			

# **Evaluation Boards**



FIGURE 1. ISL29023 EVALUATION BOARD



FIGURE 2. ISL29020 EVALUATION BOARD



FIGURE 3. ISL29028 EVALUATION BOARD





CAUTION: These devices are sensitive to electrostatic discharge; follow proper IC Handling Procedures. 1-888-INTERSIL or 1-888-468-3774 Copyright Intersil Americas Inc. 2010, 2011. All Rights Reserved Intersil (and design) is a trademark owned by Intersil Corporation or one of its subsidiaries. All other trademarks mentioned are the property of their respective owners.

# **Table of Contents**

Ambient Light Sensor Products	. 1
Evaluation Boards	. 1
Table of Contents.	. 2
Evaluation Package	. 3
System Requirements	. 3
Software Installation.	. 3
Firmware Reference	. 3
Evaluation Kit Contents	. 3
Hardware Setup for ISL29011 Family	. 3
Running Program for ISL29011 Family	. 3
Hardware Setup ISL29028 Family	. 8
Troubleshooting	11
Evaluation Boards Schematics	12

# **Evaluation Package**

- Demo Board
- Evaluation Software (online)
- USB 2.0 Cable

# **System Requirements**

- Windows 98/NT/2000/XP/VISTA/WIN7
- Available USB Port

# **Software Installation**

- Intersil\_ISL29XXX\_HID(V107).exe or:
- intersil\_ISL29011,ISL29018,ISL29021,ISL29023 Installer V107.exe

# **Firmware Reference**

- Intersil\_ISL29xxx\_HID(V107).exe, which has Human Interface Device firmware in the Micro-controller board (ISLUSBCEVAL1Z-HID\_REV1). It can therefore communicate with Intersil Ambient Light Sensor products using a PC operating on Windows 98/NT/2000/XP/VISTA/WIN7.
- ISL29011,ISL29018,ISL29021,ISL29023 Installer V107.exe, which has Jungles firmware in the Micro-controller board (ISLUSBCEVALS12- REVA). It can therefore communicate with Windows 98/NT/2000/XP but not VISTA and WIN7.

Note: If you have trouble with Firmware, please see "Troubleshooting" on page 10.

# **Evaluation Kit Contents**

The evaluation kit consists of the hardware, software, and documentation listed in the following.

- 1. Evaluation PCB
- 2. PDF of board schematic (online)
- 3. PDF of board layout (online)
- 4. Evaluation Software Installer (online)
- 5. Evaluation Board manual (online)
- 6. IC Data sheets (online)

The software and documentation can be found in the following links:

http://www.intersil.com/products/deviceinfo.asp?pn=ISL29028 http://www.intersil.com/products/deviceinfo.asp?pn=ISL29011 http://www.intersil.com/products/deviceinfo.asp?pn=ISL29018 http://www.intersil.com/products/deviceinfo.asp?pn=ISL29021 http://www.intersil.com/products/deviceinfo.asp?pn=ISL29020 http://www.intersil.com/products/deviceinfo.asp?pn=ISL29020 http://www.intersil.com/products/deviceinfo.asp?pn=ISL29027

# **Installing the Software**

From the link supplied in the previous section, download and run *Intersil\_ISL29XXX\_HID\_Installer\_V107.exe*. The user will be greeted by the screen shown in Figure 5. Continue through the installer and read the instructions. The PC and PCB should *not* be

connected via the USB until after the installation has satisfactorily completed.

- Double-click Intersil\_ISL290XXX\_HIDV1.07.Installer.exe



FIGURE 5.

# Hardware Setup for ISL29011 Family

- Connect the USB 2.0 Cable to the PC first, and then to the Evaluation Board
- The computer may ask about installing software for new found hardware; select "Yes, this time only"
- On the following screen, it will ask about how to install hardware. Select the recommended option (Installing from CD) and follow the directions
- The USB is the only connector needed

# Running Program for ISL29011 Family

 To open the program, go to the "Start" menu, as shown in Figure 6 (Start →Intersil →Intersil\_29XXX\_HID→ Intersil\_29XXX\_HID)

🛅 Intersil_ISL29XXX_HID	Intersil_ISL29XXX_HID
m ISL2900X	▶ 🥑 Intersil_ISL29XXX_HID_uninstall

FIGURE 6.

- Once you have double clicked the program, the window displayed in Figure 7 should open.



- Go to "Device Select" tab and select whichever Device you have connected to your computer; for this example we will use "ISL29011", as shown in Figure 8.

	Device Select	•
_	Device Select	
	ISL29011	
	ISL29018	
4	ISL29020	
	ISL29021	
	ISL29023	

#### FIGURE 8.

- The "ISL29011 Multi-Function Sensor Evaluation Software" window should open
- This is the main window in which all demonstrations will be done
- **USB Communication** Check to make sure the light shown in Figure 9 is green. If it is not green, check your connection.



#### FIGURE 9.

• Test Communication with the IC by clicking the button shown in Figure 10; if it shows "good", then the Hardware and Software are properly set up; if it says "fail", then check your connections. If the problem still persists, then you may want to restart the software.

- Device Mode Cor	ntrol
C Test Comm	Good

FIGURE 10.

Note: This is common for all devices

 From the menu on the left, choose the specific "Operation" in which you would like to operate the IC, as shown in Figure 11. A detailed explanation is described in the data sheet (FN6691). Table 1 summarizes the different modes.



#### TARIE 1 **EXPLANATION** MODE Power-down Turn off and keep data in registers. ALS Once Ambient Light Sense for one conversion then Power-down. Infrared Sense for one conversion then Power-down. IR Once Prox. Once Proximity Infrared Sense for one conversion then Internal Calc. Power-down; Flagging is triggered by Interrupt. ALS Cont. Ambient Light Sense continuously and continue to refresh registers. IR Cont Infrared Sense continuously and continue to refresh registers. Prox. Cont Proximity Infrared Sense continuously and continue to Internal refresh registers; Flagging is triggered by Interrupt (Scheme1). Prox. Cont Proximity Infrared Sense continuously and continue to refresh registers; Flagging is triggered by Interrupt External (Scheme0).

• Integration Time in Figure 12, corresponds to the resolution of the internal ADC and the number of bits allocated to representing Count. Higher resolution (more bits) requires a large number of counts and will need longer acquisition (integration) time.



#### FIGURE 12.

• Sensitivity-Range Select (Figure 13) allows us to choose the sensitivity of the sensor based on external conditions/object detection. For example, a really bright object would require a higher range (i.e. 64000), versus a dark object, which would require a low range (i.e. 1000). Higher range reduces photo detector sensitivity.

AD Sensitivity - Range Select—					
O 1000	<ul><li>● 4000</li></ul>				
O 16000	O 64000				

#### FIGURE 13.

The section shown in Figure 14 allows the user to choose either external prox or internal prox calculation.

Scheme0(external prox): Not recommended because subtraction is done by the software.

Scheme1(internal prox): Recommended because subtraction performed by system on chip

Me	easurement	Туре	
$\odot$	Scheme0	0	Scheme1

FIGURE 14.

The section shown in Figure 15 is for proximity mode:

**Source Current** allows you to adjust the IR LED driving current. A greater current allows for the detection of objects at farther distances.

**IR Modulation Frequency** allows you to modulate the IR LED driving current. Increasing the frequency parameter allows for better noise immunity.



FIGURE 15.

This section shown in Figure 16 displays data of Device Registers:

<ul> <li>Device Regist</li> </ul>	ers							
RO	R1	R2	R3	R4	R5	R6	B7	R8
Wr 60 •	45	)		00 0	00 0	FF O	FF O	00 💿
Rd 📉 O	XX c		> 📉 o	× o	× o	× o	× o	× o
Opr	Con	ADLSB	ADMSB	ILLSB	ILMSB	IHLSB	IHMSB	RS¥D
Wr	Wr			Wr	Wr	Wr	Wr	Wr
Rd	Rd	Rd	Rd	Rd	Rd	Rd	Rd	Rd
				Read All				



## **REGISTER 0X00 – CONFIGURE MODEL**

IC register 0x01 controls the modes such as ALS/IR/Prox and Interrupt flag and Interrupt persistence of the part, which are explained in detail in the data sheet.

# **REGISTER 0X01 – CONFIGURE MODES II**

IC register 0x02 controls the ranges and resolutions of the part and also Scheme for Proximity.

## **REGISTER 0X02 AND 0X03**

Data will be stored to these registers.

## **REGISTERS 0X03 TO 0X07 – INTERRUPT THRESHOLDS**

The PROX interrupt and ALS thresholds are stored in registers 0x03 to 0x07. They can be edited by writing values to the "Interrupt Limits" box and clicking "write". See the IC data sheet for more information on interrupt limits.

The section shown in Figure 17 allows the user to set the interrupt trip-point, which acts as an alarm/monitoring function to determine whether the ADC count exceeds the upper/lower limit.

<ul> <li>Interrupt Pers</li> <li>1 C 4</li> </ul>	sistance 4 C 8 C 1	16 🕅 P	oll External Intr.
Interrupt Li	imits Rea	ad / Clear Status	Status
Lower	Sar	nple Ext. errupt Pin	0 Pin 7
Write R	ead ty 12 Bits	4095 M	ax 0 Min

FIGURE 17.

Interrupt Persistence	Sets the number of times the upper limit needs to be exceeded or lower limit needs to be subceeded. Once the allotted number of times is achieved, an alarm/interrupt will flag
Interrupt Limits	Type the upper threshold for the interrupt in the top box (Max = 65535 for Int. Time = 16; Max = 4095 for Int. Time = 12) Type the lower threshold for the interrupt in the bottom box (Min = 0, for either Int. Time)
Write	Stores value to memory in Registers 4-7
Read	Read limit values stored in Registers 4-7
Read/Clear I-Status	Checks the 2 <sup>nd</sup> bit of Register 0 to determine Interrupt status, whether interrupt thresholds have been triggered or not. It then displays the results in the "Status" section. The R0-B2 box displays the status of the interrupt. To clear the interrupt status, click 2 times on "Read/Clear" button. - Green light means the button is on and value from bit 2 from R0 has been read - Square light displays status; if black then interrupt is off/not triggered yet; if red then interrupt has been triggered
Sample Ext. Interrupt Pin	Samples the external Pin 7 on package of the IC - Green light means, button is on and is displaying output of Interrupt pin (7 <sup>th</sup> pin) - Square light displays the status; black means trigger hasn't been triggered yet - Red means interrupt has just been triggered
Poll External Intr.	Allows for checking of External Interrupt Status while sampling data.

To use:

- 1. Choose Interrupt Persistence value (we recommend 8)
- 2. Enter a decimal number for the Upper Limit. Enter a decimal number for the Lower Limit.
- 3. The Upper Limit must be greater than the Lower Limit. The values for the limits depend on the application, the configuration of other options, and the distance at which you choose to flag.
- 4. Click on "Write" and then click on "Read" and verify that the desired limit values are correct (verify that the values entered for intended limits are the same values in the field box after clicking on "Read"). If not, repeat Steps 2 and 3.
- 5. Double click "Read/Clear I-Status" to clear status.
- 6. Now you may choose to manually poll the Interrupt pin (pin 7 on package), or for it to happen automatically. To do it manually, simply click on "Sample Ext. Interrupt Pin" when desired. To do it automatically, ensure that the "Poll External Intr." box is selected.
- 7. Interrupt is set up now and you may begin collecting data. Data is collected within the Upper Limit and Lower Limit. The black box means unflagged status. On the other hand, if the data is collected either above the Upper Limit or the lower of the Lower Limit, then the black block will be red, which means the flag has been triggered.

- **Collect Data Graphical Real Time Data** allows you to sample data (whether ALScont, IRcont, ALS Once or IR Once). Samples are now being taken and are being plotted, and appropriate values are displayed on the right in the corresponding box.
- "Stop Data Acquisition" stops sampling of data.



FIGURE 18.

Here the scale can be adjusted to meet your sampling needs. **"Manual Re-Scale**" allows you to type in the Maximum and Minimum values for the scale (vertical axis) in the appropriate boxes. The **"Automatic Re-Scale**" button is useful if the sampled data is out of the range of the graph or you need to zoom-in on data. It will rescale the vertical axis to an appropriate field of view.

- Exit this button closes the entire program
- The value in the "ADC Reading" and/or "Lux Reading" fields are the appropriate output coming out of the sensor according to which Mode is engaged (Figure 19).
- Max Min Count This is the maximum value that can be measured based on the resolution chosen (Integration Time). Max count increases with more Integration Time.



FIGURE 19.

# **Saving Measurements to File**

To save a series of ALS and PROX measurements to disk, see the "Save Measurements to File" box at the very bottom of the GUI. The user may click "Browse" to select a filename/file path and click "Write to Disk" to write the current graph data to disk.

# **Running the Program for ISL29020**

To open the program, go to the "Start" menu, as shown in Figure 20.

intersil_ISL29XXX_HID	Þ	🧵 Intersil_ISL29XXX_HID
m ISL2900X	•	🥑 Intersil_ISL29XXX_HID_uninstall

### FIGURE 20.

- (Start  $\rightarrow$ Intersil\_29XXX\_HID $\rightarrow$ Intersil\_29XXX\_HID)
- Once you have double clicked the program, the window displayed in Figure 21 should open

🧘 Intersil ALS Evalu	lation Software Mail	n Startup Menu	- 🗆 ×
inte	ersil	SIMPLY SMARTER	
	Device Select	•	
	About		

#### FIGURE 21.

- Go to "Device Select" tab and select whichever Device you have connected to your computer; for this example we will use "ISL29020"
- The "ISL29020 Multi-Function Sensor Evaluation Software USB HID Version" window should open the main window in which all demonstrations will be done

Device Select	•
Device Select	
ISL29011	
ISL29018	
ISL29020	
ISL29021	
ISL29023	_
Adr=0x88 (ISL29027)	
Adr=0x8A (ISL29027)	-

#### FIGURE 22.

• USB Communication- Check to make sure the light shown in Figure 23 is green. If it is not green, check your connection



#### FIGURE 23.

• **Test Communication** with the IC by clicking the button shown in Figure 24; if it shows "good", then the Hardware and Software are properly set up; if it says "fail", then check your connections. If the problem still persists, then you may want to restart the software.



FIGURE 24.

The section shown in Figure 25 allows the ADC-Core to be enabled. The user needs to check "Enable ADC-Core" in order to enable the devices.

Command Reg: Power Down	O Enable ADC-Core
	FIGURE 25.
Measurements One Shot C Continuous	AD Resolution (Clocks 2 <sup>^</sup> N) 16 • 12 • 8 • 4
Measurement Visible Light IR Sensing	C External Timing

#### FIGURE 26.

The section shown in Figure 26 allows the user to choose either one shot or continuous measurement for visible or IR sensing and change our ADC resolution for 16-bit or 12- or 8-bit or even 4-bit ADC. However, Intersil recommends to run 12-bit ADC or 16-bit ADC for better 50/60Hz reject.

The "External Timing" check box is another option to run when using external customer supplied timing.



FIGURE 27.

Once the external timing from Integration Time is selected, Figure 27 will appear. The External timing allows ADC or Timer tests to be read and is able to choose the timing between pulses (~2 pulses). For more information about external timing, refer to the data sheet

E F	Bange - LL	IX Sensitivity	Select		
		- 4000		C 04000	
9	• IUUU	0 4000	0 16000	0 64000	

#### FIGURE 28.

**Range-LUX Sensitivity Select** allows the user to choose the sensitivity of the sensor based on external conditions/object detection. For example, a really bright object would require a higher range (i.e., 64000), versus a dark object, which would require a low range (i.e., 1000). Higher range reduces photo detector sensitivity.



#### FIGURE 29.

The section shown in Figure 29 allows the user to choose REXT to fix its internal oscillator frequency. 500k $\Omega$  is recommended for the devices.

**Collect Data Graphical Real Time Data** allows you to sample data (whether ALScont, IRcont, ALS Once or IR Once). Samples are now being taken and are being plotted, and appropriate values are displayed on the right in the corresponding box.

- Stop Data Acquisition stops sampling of data. Here the scale can be adjusted to meet your sampling needs.
- Manual Re-Scale allows you to type in the Maximum and Minimum values for the scale (vertical axis) in the appropriate boxes.
- Automatic Re-Scale button is useful if the sampled data is out of the range of the graph or you need to zoom-in on data. It will rescale the vertical axis to an appropriate field of view.
- · Exit this button closes the entire program
- The value in the "ADC Reading" and/or "Lux Reading" fields are the appropriate output coming out of the sensor according to which Mode is engaged.





leasurements to File				
gram Files\Intersil\Intersil_ISL29XXX_HID/Data.txt				Browse Write to D
				Append
	FIG	URE 31.		
File Edit View Favorites Tools Help				2
🌏 Back 👻 🕥 🖌 🏂 🔎 Search 😥	Folders 🔯	🏂 🗙 🍤 [	•	
Address C:\Program Files\Intersil\Intersil_ISL	29028-30-40			💌 🄁 Go
Name	Size	Туре 🔺	Date Modified	
🔊 cometl32.oex	595 KB	ActiveX Control	7/28/2005 2:51 PM	
SOMDLG32.OCX	137 KB	ActiveX Control	7/28/2005 2:51 PM	
S DATAFORM.OCX	530 KB	ActiveX Control	7/28/2005 2:51 PM	
🔊 масомма2.осх	102 KB	ActiveX Control	7/28/2005 2:51 PM	
STABCTL32.OCX	205 KB	ActiveX Control	7/28/2005 2:51 PM	
Intersil ISL29028-30-40.exe	412 KB	Application	2/22/2010 4:51 PM	
🔁 unins000.exe	1,1	Application	2/22/2010 4:55 PM	
wdreg16.exe	26 KB	Application	3/21/2005 6:05 AM	
Tudrog, gui ovo	120 VP	Application	2/21/2005 6:05 AM	-

FIGURE 32. LOCATION OF EXECUTABLE ON USER'S HARD DRIVE

# **Saving Measurements to File**

To save a series of ALS and PROX measurements to disk, see the "Save Measurements to File" box at the very bottom of the GUI. (Figure 31). The user may click "Browse" to select a filename/file path and click "Write to Disk" to write the currently graph data to disk.

# Hardware Setup ISL29028 Family

# **Schematic and Layout**

The PCB schematic and Layout are contained on the CD-ROM included with this evaluation kit (also see Figures 38 through 40). If lost, contact the local Intersil sales/FAE team. (http://www.intersil.com/cda/Support/contacts/)

# **Connecting the PCB to PC**

Insert the USB-B plug into the Intersil evaluation PCB, and the USB-A plug into the user's PC. As seen in Figure 34, the status of the PC<->PCB communication link is displayed in the colored box next to "Attached".

# **Jumpers on PCB**

The "rev B" evaluation board has 4 jumpers, which control various aspects of the part. By default, the jumpers *JP\_IC*, *JP\_MISC*, and *JP\_IRLED* need not be connected due to the 0 $\Omega$  resistors *R*6, *R*7, and *R8* which connect to a 3.3V rail. If the user desires to test part performance at voltages other than V<sub>DD</sub> = V<sub>IR-LED</sub> = V<sub>I2C</sub> = 3.3V, unsolder these resistors, use the installed test points, and power any of the 3 rails as desired.

TABLE	2.	JUMPER	OVERVIEW
	_		

DESIGNATOR	FUNCTION
JP_PIN1	ISL29028: Changes I <sup>2</sup> C address ISL29030: Leave open (see below)
JP_IC	Connects 3.3V rail to VDD
JP_MISC	Connects 3.3V rail I <sup>2</sup> C pull-up, INT, PIN1
JP_IRLED	Connects 3.3V rail to the IR-LED D1

## JP\_PIN1

The jumper *JP\_PIN1* is connected to pin 1 of the ODFN and should be **disconnected for ISL29030** usage, and **will work in either state for the ISL29028**. The ISL29030 has a current source on pin 1. The ISL29028 has an I<sup>2</sup>C address select line tied to pin 1.

# **Running the Program for ISL29028 Family**

If the user has selected the default installation path, the software will install in the following folder: C:\Program Files\Intersil\Intersil\_ISL29028-30-40\ as seen in Figure 32.

Double-click the highlighted executable shown in Figure 32 to start the evaluation software. A shortcut to this file is also provided via the Windows Start Menu under All Programs  $\rightarrow$  Intersil  $\rightarrow$  Intersil ISL29028-30-40.

Connect the PC to the evaluation PCB via a USB cable. When this connection is made, the "Attached" box displayed in Figure 33 should turn green.

The ISL29028 has a selectable I<sup>2</sup>C address (see pin ADDR0). By changing the input logic signal (via jumper  $JP_PIN1$ ), the I<sup>2</sup>C address can be set to either 0x88 or 0x8A (see the PCB schematic/IC data sheet for more information). This board is shipped with jumper  $JP_PIN1$  removed, so by default the part will respond to I<sup>2</sup>C address 0x88.



FIGURE 33. SOFTWARE START-UP SCREEN

USB COMM 🗧 88 C Test Comm	Collect / Graph Real Time Data Test Red LED Test ORN LED Scale Max Scale Min 4095 0
Register 1 Configure	04100 04100 Manual Re-Scale
IR Led Sleep Time mSec Range	03690 03690 Exit
● 800 C 75 C 2000 Lux	03280 03280 03280 Graph Timing
C 200 C 125	02870 02870 02870 Loop Time
C 100 C Continuous Measure Mode	
IR Drive	02050 02050 Meas. I me
	01640 01640
Register 2 Interrupt Control	01230 01230000000000
Proximity ALS / IR Intr Pin	00820 00820 00820 00820 00820 Saturated?
Persistence Persistence C And O	00410 00410 00410 00410 No
	00000 400 200 200 200 100 100 00 40 0 0000 ALS / IR
Meas INT bits	AD Cnt Total 400 Samples AD Cnt ICC Samples
Beep on INT state change	Device Registers 0x0 0x1 0x2 0x3 0x4 0x5 0x6 0x7 0x8 0x9 0xA 0xB 0xC 0xD 0xE 0xF
Interrupt Limits     Roll External Intr.     Roll 12C Interrupt	w/ 00 0 00 0 00 0 00 0 FF 0 00 0 FF 0 00 0
Interrupt Limits Dec Hex	
ALS/ IR Upper 4095	(n/a) CONF INTR PLT PHT ATH1 ATH2 ATH3 PROX ALS1 ALS2 (n/a) (n/a) (n/a) TEST1 TEST2
ALS / IR Lower 0	Wr   Wr   Wr   Wr   Wr   Wr   Wr   Wr
Prox Upper 255	Rd R
Write Read	
Save Measurements to File	
C:\Program Files\Intersil\Intersil_ISL29028-30-40\	data.csv Append Browse Write to Disk Captured Readings 0

FIGURE 34. SOFTWARE MAIN SCREEN

# **Main Window**

The main evaluation software window can be seen in Figure 34.

If the user desires to change the  $I^2C$  address the GUI communicates with, see the upper-left box containing "88" in Figure 34. Change the number as desired and click the "Test Comm" box to test for a valid communication link between the PC and Light Sensor at the specified  $I^2C$  address.

# **REGISTER 0X01 - CONFIGURE MODES**

IC register 0x01 controls the range and modes of the part. "Sleep time", "Range" and "Measure Mode" bits are explained in detail in the data sheet. All control bits *not* related to the interrupt function are located in this register.

# **REGISTER 0X02 – INTERRUPT BEHAVIOR**

IC register 0x02 contains the interrupt flags and controls the interrupt modes. Interrupt persistence, and AND/OR (see bit 0) functionality is contained in this register.

# **REGISTERS 0X03 TO 0X07 – INTERRUPT THRESHOLDS**

The PROX interrupt thresholds and ALS thresholds are stored in registers 0x03 to 0x07. They can be edited by writing values to the "Interrupt Limits" box and clicking "write". See the IC data sheet for more information on interrupt limits.

# **EXTERNAL INTERRUPT AND INTERRUPT LEDS**

To poll the status of the hardware *INT* pin, select the "Poll External Intr" check box and the on-PCB microcontroller will continuously check the logic state of the *INT* line. To poll the status of *ALS\_FLAG* and *PROX\_FLAG* interrupt bits (in register 0x02), select the "Poll I<sup>2</sup>C Interrupt" check box - the GUI will perform an I<sup>2</sup>C read and then instruct the microcontroller to turn

D3/D4 on or off depending on the state of ALS\_FLAG and PROX\_FLAG.

## **COMPLETE REGISTER LISTING**

The "Device Registers" box at the bottom of the GUI displays a complete listing of all registers in hex format and should automatically update based on the options selected by the user. Users can individually write to or read from these registers using the "Wr"/"Rd" buttons.

# **REAL-TIME DATA ACQUISITION GRAPH**

To graphically display the results of ALS and proximity conversions, first click the check boxes "ALS /IR Enable" and "Prox Enable" and select the mode of operation by using the radio buttons in the "Register 1 Configure" area. After this register is configured, click the "Collect Data" button shown in the upper-left of Figure 35. Both ALS and Proximity conversions can happen (and are displayed) at once because the ISL29028 architecture has two concurrent ADCs.

# ADC RESOLUTION AND GRAPH RESCALING

Because the ALS conversions are inherently 12-bit  $(2^{12}-1 = 4095)$  count maximum), and the proximity conversions are inherently 8-bit  $(2^{8}-1=255)$  count maximum), the graph may require rescaling to view both results on the same curve at once. To set a new maximum and minimum graphical scale, change the numbers in the "Scale Max" and "Scale Min" boxes, then click "Manual Re-Scale".

## SAVING MEASUREMENTS TO FILE

To save a series of ALS and PROX measurements to disk, see the "Save Measurements to File" box at the very bottom of the GUI. The user may click "Browse" to select a filename/filepath and click "Write to Disk" to write the currently graphed data to disk.

# **Application Note 1591**



FIGURE 35. REAL-TIME DATA ACQUISITION GRAPH

# Troubleshooting

- If suffering from poor USB connection; the USB port may need to change.
- If the Proximity sensor is unable to measure anything within a certain distance, the sensor has saturated and the Selectivity parameter needs to be increased.
- If the program says connection fail and the sensor instantly stops working, then simply unplug it from the computer and plug it back in. If the problem still persists then unplug, close the program, plug it back in, and reopen the program.
- If during a measurement, the program crashes or instantly the Evaluation board is no longer detected as being connected, then unplug and plug back in.
- If too much noise is being picked up, then increase the Frequency parameter.
- If you require better detection of far distances, then increasing the current parameter will help.
- Also recall that since this is an optoelectrical part with a clear package, performance may be sensitive to aggressive scratching or damaging.

 If the message "Please check USB connection" appears right after trying to run the program, you have an older version of the software GUI or the USB is not connected to the PC. Go back and check the micro-controller board to see if it is marked "HID" version or not. If not, you have the "Jungle" version.

	×
Please check USB conr generic ISL29011 Eval	nection. luation Board not found.
Retry	Cancel

#### FIGURE 36.

- If you have WIN7 installed on you PC and you are trying to run an Intersil Program, then you will get the message shown in the following.



FIGURE 37.

The following screen shown may be caused by the PC monitor. The solution is to resize the set custom text size (DPI) by going to Control Panel ->Appearance and Personalization -> Display -> Set custom text size (DPI) and choose "Scale to this percentage of normal size: 100%" (96pixels/inch).

Custom DPI Setting	R	x
For a custom DPI setting, select a perc drag the ruler with your mouse.	entage from the list, or	
Scale to this percentage of normal size	: 100% 🔻	
0 1	2 3	
9 point Segoe UI at 96 pixels per inc	h.	
Use Windows XP style DPI scaling	OK Ca	ncel

# **Evaluation Boards Schematics**

VDD=3V3 Vdd d VDDD IRDR SDA 🔶 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 C4 C3 1uI ĪNT VDDA 0.1ul GND GND SDA +3.3V**⊲** -5V⊲ Rext 🛱 SCL SCL ISL2901 VDD= 3V3 D2 Revi R1 500K USB PO RES1 R

FIGURE 38. ISL29011, ISL29018, ISL29021 EVALUATION BOARD SCHEMATIC

For other questions, comments, and feedback, contact the local Intersil FAE/Sales team.

(http://www.intersil.com/cda/Support/contacts/)

# **Evaluation Boards Schematics** (Continued)



FIGURE 39. ISL29023 EVALUATION BOARD SCHEMATIC





Intersil Corporation reserves the right to make changes in circuit design, software and/or specifications at any time without notice. Accordingly, the reader is cautioned to verify that the Application Note or Technical Brief is current before proceeding.

For information regarding Intersil Corporation and its products, see www.intersil.com