

PowerManager UPS Software

for Windows 98/ME/NT/2000/XP/2003/Vista, Linux, Free BSD

Serial: PN-1AF99-31709-0E2E0-06820

Wichtig! Unbedingt beachten!

- Bei der Installation der Software kann eine Fehlermeldung erscheinen, die ignoriert werden kann
- Es wird empfohlen, die englischsprachige Version zu installieren
- Der serielle Port, an dem die USV angeschlossen ist, muß nach jedem Start neu gewählt werden. AUTO funktioniert nicht.
- Im Konfigurationsdialog **NICHT** den Knopf „Testing“ betätigen, da sonst keine Kommunikation mit der USV zustande kommt. Einfach nur auf OK klicken.

Important! Please note!

- During the installation of the software an error might occur that can be ignored
- The serial port, which the UPS is connected, has to be selected everytime the software is started. The AUTO setting does not work.
- In the configuration dialogue do not use the “Testing” button, else there will be no communication with the UPS. Just exit with the OK button.

PowerManager UPS Software

for Windows 98/ME/NT/2000/XP/2003/Vista, Linux, Free BSD

Serial: PN-1AF99-31709-0E2E0-06820

Wichtig! Unbedingt beachten!

- Bei der Installation der Software kann eine Fehlermeldung erscheinen, die ignoriert werden kann
- Es wird empfohlen, die englischsprachige Version zu installieren
- Der serielle Port, an dem die USV angeschlossen ist, muß nach jedem Start neu gewählt werden. AUTO funktioniert nicht.
- Im Konfigurationsdialog **NICHT** den Knopf „Testing“ betätigen, da sonst keine Kommunikation mit der USV zustande kommt. Einfach nur auf OK klicken.

Important! Please note!

- During the installation of the software an error might occur that can be ignored
- The serial port, which the UPS is connected, has to be selected everytime the software is started. The AUTO setting does not work.
- In the configuration dialogue do not use the “Testing” button, else there will be no communication with the UPS. Just exit with the OK button.