

Tech Note 101014_01

Date: October 10, 2014

Product: Retrofit Kit 2 (RK2)

Subject: Ribbon Cable Connections

Note: A and B indicator labels were added to RIB boards on October 10, 2014. See connection procedure below.

1. Insert plug 1 from the 20-16 pin cable (12") into port labeled RELAY 1-32.
2. Connect plug 2 from both cables together.
3. Insert plug 3 from the middle of the 16 Pin Cable (33") into the RIB-A board.
4. Insert plug 4 from the 16 pin cable (33") into the RIB-B board.
5. Repeat for RELAY 33-64.

