

Tech Note 101014_02

Date: October 10, 2014

Product: Retrofit Kit 3 (RK3)

Subject: Ribbon Cable Connections

Note: A and B indicator labels were added to RIB boards on October 10, 2104. See connection procedure below.

1. Insert plug 1 into port labeled RELAY 1-32.
2. Insert plug 2 into the RIB-A board.
3. Insert plug 3 the RIB-B board.
4. Repeat for RELAY 33-64.

