

Tech Note 100713_02

Date: October 7, 2013

Subject: Relay Voltage Divider (RVD) Installation

Product: Relay Panel (RP)

Note: Recommended Installation Procedure



1. Start



4. Insert Outside Divider. Mate threaded stud and alignment dowels with corresponding holes in Inside Divider. Install and tighten Wing Nut on threaded stud.



2. Remove a Lighting Tough Relay (LTR) from above or below the intended RVD location.



5. Reinstall LTR. DO NOT exceed 5 in-lbs when tightening LTR fastener.



3. Insert Inside Divider and secure with Inside Divider Fastener. DO NOT exceed 5 in-lbs when tightening.