



**H506 Louvered Vent**  
**4 1/4" Diameter**  
**ACU-HEAT TEMPLATE**

1. Cut out template.
2. Position and trace around template.
3. Cut out the hole.
4. Test fit product.
5. Mark the mounting holes (if any).
6. Pre-drill the mounting holes and mount the product.