

# DIESEL PRO 243

# APPLICATIONS -

Any diesel engine with fuel flow rates up to 60 gph

# **ELIMINATE UNNECESSARY CHANGES & MAINTENANCE**

- All-in-one fuel filter, water separator, and fuel heater for medium duty applications
- Clear cover provides instant visual indication of filter life
- "SEEING IS BELIEVING"

  See when NOT to change the filter
- Extended filter change intervals same filter can be used in Fuel Pro®
- Enhanced fuel system troubleshooting procedures
- Biodiesel compatible to B20

## **5 MINUTE FILTER CHANGES** -

- Dry filter changes Drain fuel below collar and replace
- No fuel spills Removing standard filters full of fuel can be messy and hazardous
- Check valve eliminates drain back during filter changes
- High flow drain
- Simple priming for easier starts
- Easy removal collar Use DAVCO wrench or common tool

### **MODELS & OPTIONS**

- Base Model Unheated
- Electric Heat
  - 12VDC, 24VDC Pre-heater or 120VAC Overnight Heater
- Water-In-Fuel (WIF) sensor





**PORTS** 

body for improved fuel hose routing

Both sides of





# "SEEING IS BELIEVING"®



When new, the fuel level in the filter will be very low with minimal restriction. As the filter is used, contaminants collect on the filter from the bottom up. Fuel rises on the filter indicating remaining filter life.



Fuel level increases in clear cover. As contaminants collect on the filter, the fuel rises to a noncontaminated section of the filter, providing optimal filtration while maintaining lowest restriction.




Fuel level at filter wrap level. Even though the fuel level is now more than half of the filter element, the fuel is still flowing through clean media at minimal restriction levels. The filter still has significant life remaining.



The filter element is now completely covered by fuel. At this point, all of the media's surface area is utilized. Restriction is increasing and the filter element should be changed at the next scheduled maintenance interval.

#### TYPICAL INSTALLATION



### **HOW IT WORKS**

- Fuel from the tank enters the fuel processor body.
- Large contaminants and "free" water are separated and remain in the body.
- Fuel rises into the clear cover area.
- Contaminants and emulsified water are captured by the filter media.
- Fuel level rises to maintain a fuel path through clean filter media (path of least resistance).
- Clean, water free, fuel exits the fuel processor to the engine fuel injection system.

#### ORDERING INFORMATION

#### **Models and Options**

Unheated

Unheated with 12VDC Pre-heater

Unheated with 24VDC Pre-heater

Contact DAVCO Customer Service to obtain the part number for the DAVCO Diesel Pro 243 that best fits your application.

#### UNIVERSAL APPLICATIONS

Use Diesel Pro 243 with medium duty diesel engines that have a maximum fuel flow up to 60 gallons per hour.

#### **DISTRIBUTED BY**

DAVCO®, Fuel Pro®, Diesel Pro®, Industrial Pro®, EyeMax®, Sea Pro®, Shop Pro®, Pro-Chek® and "SEEING IS BELIEVING"®

customerservice@davco.com www.davco.com