

Electroswitch Part List

PB Series

[Pages 14-16 in Miniature Switch Catalog](#)

PB-12300CQ

PB-12300ZQ

PB-12311ZQ

PB-12312ZB

PB-12322CQ

PB-12331CG

PB-12331ZQ

PB-12333CB

PB-12333ZG

PB-12333ZQ

PB-12600AB

PB-12600CB

PB-12600CQ

PB-12600Z3Q

PB-12600ZB

PB-12600ZQ

PB-12611ZG

PB-12611ZQ

PB-12612Z3B

PB-12612ZB

PB-12613CQ

PB-12631CB

PB-12631WG

PB-12631ZB

PB-12631ZQ

PB-12632ZQ

PB-12633CQ

PB-12633ZQ

PBS-12332ZQ

PBS-12600CB

PBS-12633ZQ

PBW-12611CB

PBW-12612CQ

PBW-12631ZB

PBW-12631ZQ

Electroswitch Part List

PB Series

[Pages 14-16 in Miniature Switch Catalog](#)

PB SERIES CAPS

W-KN-12 (BLACK)

W-KN-12A (WHITE)

W-KN-12B (RED)

W-KN-14 (BLACK)

W-KN-14A (WHITE)

W-KN-14B (RED)

W-KN-31 (BLACK)

W-KN-31A (WHITE)

W-KN-31B (RED)

W-NU-29A (NUT)

W-NU-30A (NUT)