
## JAEGER CONNECTEURS

## Minex Series — Minex

Technical Data				
RoHS  Panel connector, cable connector	Panel connector  Cable connector  Coupler connector			
and coupler connector	circular housing			
Locking	screw connection			
Protection	IP 65 with flat-gasket for panel connector			
Contacts	3 and 7 contacts ø 1 mm crimp or solder removable contacts			
Max. current	7A ø 1 mm			
Contact resistance between pin and socket	$<$ 0,0020 $\Omega$			
Breakdown voltage (mated connectors)	> 2500 Volts (RMS)			
Insulation resistance	> 5000 MΩ			
Operating temperature	-40 °C to +85 °C (100 hours at +100 °C)			
Materials	Housing and insert made of POM and PBT, gold-plated brass contacts			
Max. conductor cross-section	0,93 mm² (crimped) — 0,60 mm² (soldered)			





## Minex Series — Minex

Part Number		
Housing	Minex 1	Minex 2
Number of Contacts ø 1 mm		7
Male panel connectors – Female cable connectors – Male coupler connectors		
Male panel connector	633 203 006	633 207 006
Female cable connector	633 303 006	633 307 006
Male coupler connector	633 253 006	633 257 006
Protective cap for panel connector	633 043 006	633 047 006
Protective cap for cable connector	633 343 006	633 347 006
Flat-Gasket for panel connector (pack of 10)	633 121 006	633 124 000
Complete crimp tool: 579 316 006 (small crimp: ø 1 mm), 579 481 006 (large crimp: ø 1 mm, ø 1,6 mm, ø 2,4 mm)		
Tool for insertion and removing contacts 597 104 006		
Female panel connectors — Male cable connectors — Female coupler connectors	(00 000 00)	(00.007.00)
Female panel connector	633 003 006	
Male cable connector	633 103 006	
		633 107 000
Female coupler connector	633 353 006	
	633 353 006 633 043 006	633 357 000
Female coupler connector		633 357 00 633 047 00
Female coupler connector Protective cap for panel connector	633 043 006	633 357 000 633 047 000 633 347 000
Female coupler connector Protective cap for panel connector Protective cap for cable connector	633 043 006 633 343 006	633 357 000 633 047 000 633 347 000

- Straight and right-angle panel connectors are also available for printed circuit boards.
- Important: All the contacts must be mounted in the insert using our tool.
- For assembly, wiring, panel connector installation and contact arrangement instructions, see: Technical guides;
- Other accessories, see: Accessories.
- All connectors are delivered with their contacts.
- Thermocouple contacts can be fitted. See: Accessories.