


Installation Information LIPS[®] E100 CYLINDER – LINEAR POSITION SENSOR INTRINSICALLY SAFE FOR HAZARDOUS DUST ATMOSPHERES

For certificate number and safety parameters information for product marked EX04, see next page.



Putting Into Service: The sensor must be used with a galvanic isolation barrier designed to supply the sensor with a nominal 5V and to transmit the sensor output to a safe area. The barrier parameters must not exceed:-

i	=	11.4V
	_	1 26.15

H

Pi = 0.51W

Ci = 1.36µF* Li = 860µH* ('Lxx' option) *Figures for 1km cable where: Ci = 200pF/m & Li = 810nH/m

Ci = 1.16\muF Li = 50\muH ('J' option)

The sensor is certified to be used with up to 1000m of cable, cable characteristics must not exceed:-

Capacitance: \leq 200 pF/m for max. total of: 200 nF

Ii = 0.20A

Inductance: \leq 810 nH/m for max. total of: 810 μ H

Approval only applies to specified ambient temperature range and atmospheric conditions in the range: 0.80 to 1.10 Bar, oxygen \leq 21%.

The performance of the sensor may be affected by voltage drops associated with long cable lengths; For cable lengths exceeding 10 metres a five wire connection is recommended to eliminate errors introduced by cable resistance and associated temperature coefficients.

N.b. sensors supplied with cable, the free end must be appropriately terminated.

Warning - The M12 IEC 60947 connector may be rotated for purposes of convenient orientation of the connector and cable, however rotating the connector more than one complete revolution is not recommended.

Repeated rotation of the connector will damage the internal wiring!


Use: The sensor is designed to measure linear displacement and provide an analogue output signal.

Assembly and Dismantling: The unit is not to be serviced or dismantled and re-assembled by the user.

Maintenance: No maintenance is required. Any cleaning must be done with a damp cloth.

Mechanical Mounting: Via mounting thread, maximum tightening torque: 100Nm. See drawing P100-15, Installation Details Mounting Threads & Seals. An O ring seal is provided, size BS908 for M20 & 3/4 UNF thread or 14.3 x 2.4 for M18 thread. Install the target tube using the flange provided or fix directly into the piston rod using adhesive for instance, the end of the target tube can be proud or flush with the piston end face as required.

Output Characteristic: Target position at start of normal travel is 36.0 mm from seal face. The output increases as the target is moved away from the sensor body, the calibrated stroke is between 5 mm and 800 mm.



Output

Incorrect Connection Protection levels: Not protected – the sensor is **not** protected against either reverse polarity or overvoltage. The risk of damage should be minimal where the supply current is limited to less than 50mA.



For further information please contact: <u>www.positek.com</u> <u>sales@positek.com</u> Tel: +44(0)1242 820027 fax: +44(0)1242 820615 Positek Ltd, Andoversford Industrial Estate, Cheltenham GL54 4LB. U.K.





Installation Information LIPS[®] E100 CYLINDER – LINEAR POSITION SENSOR INTRINSICALLY SAFE FOR HAZARDOUS DUST ATMOSPHERES

For certificate number and safety parameters information for product marked EX07, see previous page.

ATEX Qualified to Intrinsic Safety Standard Certificate numbers SIRA 00ATEX2076X			Ex II 1GD EEx ia IIC T4 (Ta = -40°C to +80°C) Ex ia D 20 T135°C (Ta= -40°C to +80°C)
Electronics Version	Output Description:	Supply Voltage: V _s (tolerance)	Load resistance:
EX04	0.5 - 4.5V (ratiometric with supply) [Output code `A']	+5V (4.5 - 5.5V)	5kΩ min

The barrier parameters must not exceed:-

Ui = 11.4V	Ii = 0.20A	Pi = 0.	51W					
Ci = 1.36µF*	Li = 710µH*	('Lxx' option)	*Figures for 1km cable where: Ci = 200pF/m & Li = 660nH/m					
$Ci = 1.16\mu F$	Li = 50µH	('J' option)						

The sensor is certified to be used with up to 1000m of cable, cable characteristics must not exceed:-

With the exception of the certificate number and safety parameters above, all other notes regarding Putting Into Service, Use, Assembly and Dismantling etc. on previous page apply to sensors marked EX04 or EX07.



