



radian

ISO 9001:2000 Certified

A division of Intracast Co, Inc.

2160 Walsh Ave.

Santa Clara, CA 95050-2512

tel 408-988-6200


fax 408-988-0683

www.radianheatsinks.com


EZ SNAP™ CLIP

MOUNTING GUIDE

MOUNTING



1. Center EZ Snap™ clip alongside BGA




2. Tilt EZ Snap™ and slip one lip under edge of BGA

3. Push down on far side of heatsink


4. Use EZ Touch clip tool to slide remaining lip under BGA and snap down to secure clip onto chip

NOTE: Remove protective sheet from thermal pad before installing EZ Snap clip & heatsink.



Mount & Remove
BGA Heatsinks
Quickly & Easily
with Radian's versatile
EZ Touch Clip Tool

REMOVAL



1. Slip Radian's clip tool or other thinly-edged instrument into the pry holes on EZ Snap™ Clip



2. Slightly tilt tool to dislodge clip
3. Remove loosened EZ Snap™ clip and heatsink

NOTE: Be careful not to break heatsink pins when tilting tool.