


USER DIRECTION OF UN-REELING \_\_\_\_\_



-TR: TAPE & REEL



F:\DWG\MISC\MKTG\USB-A-S-X-X-SM2-X-XX-MKT.SLDDRW