M600 Instrument Software upgrade

- 1. Download the M600 Instrument Software to your PC.
- 2. Using your PC:
 - Insert a floppy disk into the floppy disk drive.
 - Double-click the "M600 V2.4.7.exe" file to unzip files to a floppy disk.
 - Click OK, then choose Unzip.
 - Once the M600 installation files have been copied to the disk, click OK, and choose Close.
 - You should have eight files on your floppy disk.
- 3. Using your M600:
 - Turn on your M600.
 - Connect the M600 keyboard.
 - Insert the disk with the M600 installation files into the floppy drive.
 - On the keyboard, press and hold the [Fn] key and press the [F2/F12] key to enter operating system mode.
 - You will now see a C: prompt.
 - Type A: upgrade, then press Enter.
 - After all the files have been copied to the M600, remove the disk and turn the M600 off.
 - Turn the M600 back on.
 - You may see the message: " Unable to open the parameter file...". This is normal.
 - Press any key to continue.
 - You will see the M600 start screen with new "System Firmware" number.
 - Your M600 is now upgraded and ready to use.