



BLT Circuit Services Ltd  
Brome Ind. Est. Brome, Eye,  
Suffolk, IP23 7HN, England  
Tel: 01379 870870  
Fax: 01379 870970  
e-mail: sales@blt.keme.co.uk  
www.bltcircuitservices.co.uk

## **Control Procedure for AquaStrip 1330P**

### **Method**

- 1) Pipette 25ml of working solution.
- 2) Add 50ml De-min Water.
- 3) Add 5-10 drops Phenolphthalein.
- 4) Titrate V/S N/I HCL to colourless end point.

### **Result**

Standard titration for a 10% working solution should be 19ml.

### **Additions**

Add 1ltr of AquaStrip 1330P for every 2ml drop in titration.