


MICRO BUCKLE


IN



UNLOCK




RATCHET




LOCK

OUT



UNLOCK



RELEASE

TIGHTENING AND LOCKING BUCKLE

1. Insert ladder strap into buckle, pull upward on lever to unlock buckle if needed.
2. Tighten to desired tension.
3. Push ratchet lever down to lock position of buckle. This prevents unwanted movement and size adjustment of strap while boot is out of binding.

RELEASING BUCKLE

1. Pull upward on lever to unlock buckle.
2. Pull on release tab to loosen or release buckle completely.

The Micro Buckle 2 operates like a classic buckle with the additional function of a lock mechanism. The lock mechanism prevents the strap from changing length while the binding is open and the boot is out.

HELPFUL HINT!

Be sure Auto Lever is down when adjusting tension of your ankle strap.