


**Figure 9 : Adjusting tilt with Beam Assembly**

To adjust tilt, loosen top pipe clamp bolts, bolts through tilt beam, and bolts at antenna bracket base (as shown by arrows). Slide arm up or down pipe to achieve tilt. Align mark with indicator angle. Tighten nuts to lock in position.



**Figure 10 : Adjusting tilt with Scissor Assembly**

To adjust tilt, loosen bolts through scissor and tilt beam. Loosen bolt at base of antenna to allow rotation (as shown by arrows). Fold or unfold scissor to achieve tilt angle. Align mark with indicator angle. Tighten nuts to lock position.

**REFERENCE DATA**



**Table 1 : Item numbers for the Mount Kit Hardware**

Item No.	Description
1	Screw Hex M12 x 110
2	Bolt Hex M12 x 130
3	Bolt Hex M12 x 65
4	Nut Hex M12
5	Washer Flat M12
6	Washer Spring M12
7	Screw Hex M6 x 16
8	Washer Spring M6

**Table 2 : Bracket Separation 'S', in millimetres**

Kits	Separation
Direct	S1
Azimuth	
Scissor	S2
Scissor + Azimuth	
Beam	Variable with tilt
Beam + Azimuth	

**S1** = Refer to antenna mount points separation for dimension  
**S2** = (S1 - 255) mm



**Figure 11 : Adjusting Azimuth tilt**

To adjust tilt, loosen bolts through azimuth bracket (top and bottom), and rotate to desired angle. Tighten nuts to lock position.

**TIGHTENING TORQUE VALUES**

Unless stated otherwise, the following general tightening torque values shall be used for metric hexagon bolts and screws, coarse pitch threads, property class 4.6.

Dia	Pitch (mm)	Bolt Tension (kN)	Torque (Nm)
M6	1.00	2.94	3.5
M12	1.75	12.40	30.0

**MAINTENANCE**

Under normal conditions, no maintenance is necessary. However, the antenna should be visually inspected at regular intervals for damage. (eg due to lightning strikes, and falling ice). Periodic checks should be performed to verify correct torque and bracket clearance settings. Accessories provided exclusively by RFS.

**Applications**

The APM40 Kits are mounting hardware options to be used for Base Station antennas up to 2.6 meters length. The same APM40 can be mounting with 2 different Antenna interface : Configuration **A** and **B**

**Features**


- Features include ;
- Basic direct mount kit
  - Beam sliding tilt mount for mechanical tilt
  - Scissor tilt option for fixed at mast (or wall) downtilt
  - Option for azimuth adjustment independent of mast
  - All kits fully upgradable
  - Pipe diameter : 60-120 mm, Wall mount option
  - Mechanical downtilt, depending of antennas
  - Azimuth adjustment up to +/-30 degrees

**Mechanical Specifications**

Weight of kit (kg)	2.8 Max (type of mounting F) 1.8 Min (type of mounting A)
Mounting kit material	Aluminium, Galvanised steel
Packaging material	Plastic sleeve
Dynamometric Tools required	19 and 18mm AF socket 10mm AF spanner or socket

Please contact technical support for more information.

Mount kit installation with antenna configuration **A**




**Mounting Options**

Refer to the following table to identify mount kits supplied. The packages of the mount kits are marked with the APM variation. Refer to the relevant Figure in the Instruction for assembly information. The letter designation is referenced in the antenna model description.


Letter	Type of Mounting	Mounting kit(s)	Figure Reference
A	Direct pipe (no tilt)	APM40-1	3
B	Azimuth upgrade	APM40-1 & APM40-E3	6
C	Beam tilt	APM40-2	4
D	Beam tilt with azimuth upgrade	APM40-2 & APM40-E3	7
E	Beam tilt with scissor upgrade	APM40-2 & APM40-E2	5
F	Beam tilt with scissor and azimuth upgrades	APM40-2, APM40-E2 & APM40-E3	8
-	Direct to beam upgrade	APM40-E1	4
-	Bracket interface for APM40	APM40-E4	2
7	No mount kit	-	-

**Assembly and Installation**



**Figure 1a : Pipe Mount Installation**

For pipe mounting, bolt front and rear pipe brackets to pipe. Tighten from front as rear bracket holds nut captive. Refer to Table 2 for top to bottom mount bracket separation.




**Figure 1b : Wall Mount Installation**

For wall mounting, fix front bracket to wall with appropriate masonry anchors. Pre-drill holes with centres 134mm apart, at top to bottom separation shown in Table 2.

Specifications subject to change without notice.


APM40-E4



**Figure 2 : Interface Bracket Assembly**

Attach interface bracket to antenna with M6 hardware where required. Top and bottom mounting points are identical.


APM40-1



**Figure 3 : Direct Mount Assembly**

Pipe mounting shown . For wall mounting, refer to Figure 1b . Rear pipe bracket is not required. Top and bottom mounting arrangements are identical.


APM40-1 and APM40-E3



**Figure 6 : Azimuth Tilt Extension**

Top and bottom mounting arrangements are identical.


APM40-2



**Figure 4 : Beam Tilt Assembly for downtilt**

This assembly attaches to top of antenna, Bottom mount assembly is the same as direct mount (Figure 3). Ensure tilt indicator has BEAM tilt markings visible. Note: Indicator marked 2.5m to be used with corresponding antenna length or greater.


APM40-2 and APM40-E3



**Figure 7 : Azimuth Tilt with Beam Tilt**

At top, insert azimuth bracket between arms of tilt beam, bolting down onto flat surface of pipe bracket, Bottom arrangement as shown in Figure 6.


APM40-2 and APM40-E2



**Figure 5 : Scissor Tilt Extension**


Insert scissor arm into beam tilt assembly. Bottom mount assembly is the same as direct mount (Figure 3). Reverse tilt indicator to have SCISSOR tilt markings visible.

APM40-2 and APM40-E2 and APM40-E3




**Figure 8 : Scissor Tilt Extension with Azimuth**

Insert scissor arm into tilt beam as shown in Figure 5. Insert azimuth bracket into scissor arm, and bolt down onto flat surface of pipe bracket. Ensure tilt indicator has scissor tilt markings visible. Bottom assembly as shown in Figure 6.



**Figure 9: Adjusting Tilt with Beam Assembly**  
To adjust tilt, loosen top pipe clamp bolts, bolts through tilt beam, and bolts at antenna bracket base (as shown by arrows). Slide arm up or down pipe to achieve tilt. Align Beam mark with indicator angle. Tighten nuts to lock in position. (Refer to tightening torque values)




**Figure 10: Adjusting Tilt with Scissor Assembly**  
To adjust tilt, loosen bolts through scissor and tilt beam. Loosen bolts at base of antenna to allow rotation (as shown by arrows). Fold or unfold scissor to achieve tilt angle. Align Scissor mark with indicator angle. Tighten nuts to lock position. (Refer to tightening torque values)

**REFERENCE DATA**

**Table 1: Item Numbers for the mount Kit Hardware**

Item N°	Description
1	Screw Hex M12x110
2	Bolt Hex M12x130
3	Bolt Hex M12x65
4	Nuts Hex M12
5	Washer Flat M12
6	Washer Spring M12
7	Screw Hex M6x16
8	Washer Spring M6
9	Washer Flat M6
10	Washer Flat M12 diameter 31,5
11	Stub Spacer arm



**Figure 11: Adjusting azimuth tilt**  
To adjust angle, loosen bolts (as show by arrows) through azimuth bracket (top and bottom), and rotate to desired angle. Tighten nuts to lock position.

**TIGHTENING TORQUE VALUES**

Unless stated otherwise, the following general tightening torque values shall be used for metric hexagon bolts and screws. All bolts must be property class 4,8 or over.

Dia	Pitch (mm)	Bolt Tension (kN)	Torque (Nm)
M12	1,75	15,90	40,0

**MAINTENANCE**

Under normal conditions, no maintenance is necessary. However, the antenna should be visually inspected at regular intervals for damage. ( e g due to lightning strikes, and falling ice). Periodic checks should be performed to verify correct torque and bracket clearance settings. Accessories provided exclusively by RFS.

Kits	Separation
Direct	S1
Azimuth	S1
Scissor	S1
Scissor+Azimuth	S2
Beam	variable with tilt
Beam+Azimuth	variable with tilt

S1=Refer to antenna mount bracket separation for distance  
S2=(S1-316) mm

**Applications**

The APM40 Kits are mounting hardware options to be used for Base Station antennas up to 2.6 meters length. The same APM40 can be mounting with 2 differents Antenna interface : Configuration **A** and **B**

**Features**


- Features include ;
- Basic direct mount kit
  - Beam sliding tilt mount for mechanical tilt
  - Scissor tilt option for fixed at mast (or wall) downtilt
  - Option for azimuth adjustment independent of mast
  - All kits fully upgradable
  - Pipe diameter : 60-120 mm, Wall mount option
  - Mechanical downtilt, depending of antennas
  - Azimuth adjustment up to +/-30 degrees

**Mechanical Specifications**

Weight of kit (kg)	2.8 Max (type of mounting F) 1.8 Min (type of mounting A)
Mounting kit material	Aluminium, Galvanised steel
Packaging material	Plastic sleeve
Dynamometric Tools required	19 and 18mm AF socket 10mm AF spanner or socket

Please contact technical support for more information.

**Mount kit installation with antenna configuration **B****




**Mounting Options**


Refer to the following table to identify mount kits supplied. The packages of the mount kits are marked with the APM variation. Refer to the relevent Figure in the Instruction for assembly information. The letter designation is referenced in the antenna model description.

Letter	Type of Mounting	Mounting kit(s)	Figure Reference
A	Direct pipe (no tilt)	APM40-1	3
B	Azimuth upgrade	APM40-1 & APM40-E3	6
C	Beam tilt	APM40-2	4
D	Beam tilt with azimuth upgrade	APM40-2 & APM40-E3	7
E	Beam tilt with scissor upgrade	APM40-2 & APM40-E2	5
F	Beam tilt with scissor and azimuth upgrades	APM40-2, APM40-E2 & APM40-E3	8
-	Direct to beam upgrade	APM40-E1	4
7	No mount kit	-	-

**Assembly and Installation**



**Figure 1a : Pipe Mount Installation**  
For pipe mounting, bolt front and rear pipe brackets to pipe. Tighten from front as rear bracket holds nut captive. Refer to Table 2 for top to bottom mount bracket separation.




**Figure 1b : Wall Mount Installation**  
For wall mounting, fix front bracket to wall with appropriate masonry anchors. Pre-drill holes with centres 134mm apart, at top to bottom separation shown in Table 2.

Specifications subject to change without notice.




**APM40-1 Direct mount assembly**



**Figure 3 : Direct mount assembly**

Pipe mounting shown . For wall mounting, refer to Figure 1b. Rear pipe bracket is not required. Top and bottom mounting arrangements are identical.


**APM40-2**



**Figure 4 : Beam Tilt Assembly (downtilt)**

Bottom mount assembly is the same as direct mount (Figure 3).


**APM40-2 and APM40-E2**



**Figure 5 : Scissor Tilt Extension**

Insert scissor arm into beam tilt assembly. Bottom mount assembly is the same as direct mount (figure 3).


**APM40-1 and APM40-E3**



**Figure 6 : Azimuth Tilt Extension**

Top and bottom mounting arrangements are identical.


**APM40-2 and APM40-E3**



**Figure 7 : Azimuth Tilt with Beam Tilt**

Insert azimuth bracket between arms of tilt beam, bolting down onto flat surface of pipe bracket . Bottom arrangement as shown in Figure 6.

**APM40-2 APM40-E2 and APM40-E3**



**Figure 8 : Scissor Tilt Extension with Azimuth**

Insert scissor arm into tilt beam as shown in Figure 5. Insert azimuth bracket into scissor arm, and bolt down onto flat surface of pipe bracket. Bottom assembly as shown in Figure 6.