


User Manual

MB-73320

Mini-ITX with onboard Intel® 4th generation Core™ i7/i5/i3/Celeron Mobile processor, Intel® QM87 chipset, DDR3 up to 16GB, 2 x Intel® Giga LAN, HDMI, DVI, VGA & LVDS, 4 x SATA, 10 x USB, 6 x COM, GPIO, HD Audio, PCI-Express X16 & X1 slots, 2 x Mini-PCIe, DC 8V ~ 32V input



Ver.	Release Date	Update
1.0V	2013.11.19	Release
1.1V	2014.01.09	
1.2V	2014.04.23	1. Packing Change: CPU cooling Fan change to copper type 2. Update GPIO Pin define

Copyright

The content of this document and software with this product are copyrighted by WIN Enterprises, Inc.

This document contains proprietary information protected by copyright. All rights are reserved; no part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without prior written permission of the manufacturer.

The content of this document is intended to be accurate and reliable; the original manufacturer assumes no responsibility for any inaccuracies that may be contained in this manual. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without prior notice

Trademark

All other product names mentioned herein are used for identification purpose only and may be trademarks and/or registered trademarks of their respective companies.

Limitation of liability

While reasonable efforts have been made to ensure the accuracy of this document, the manufacturer and distributor assume no liability resulting from errors or omissions in this document or from the use of the information contained herein.


For more information or other WIN Enterprises products, please visit our website <http://www.win-ent.com>.

For technical support send inquiries to sales@win-ent.com.

Packing list

Before using this product make sure that the following materials have been shipped.







- ▶ 1 x MB-73320 board
- ▶ 1 x SATA cable, L/ 200mm (p/n: CB-SATA11-00)
- ▶ 1 x 12V/5V SATA power cable , L/ 150mm (p/n: CB-IPOW41-00)
- ▶ 1 x CPU cooling Fan (p/n: CB-F00075-00)
- ▶ 1 x CD Driver Utility



Model Name	Description
MB-7332A	Mini-ITX w/ i7-4700EQ , 2 GLAN,HDMI/DVI/VGA/LVDS, COM, USB, Mini-PCIe socket, 4 SATA, 8V ~ 32V DC input, PCIe X16 slot
MB-7332B	Mini-ITX w/ i5-4400E , 2 GLAN,HDMI/DVI/VGA/LVDS, COM, USB, Mini-PCIe socket, 4 SATA, 8V ~ 32V DC input, PCIe X16 slot
MB-7332C	Mini-ITX w/ i3-4100E , 2 GLAN,HDMI/DVI/VGA/LVDS, COM, USB, Mini-PCIe socket, 4 SATA, 8V ~ 32V DC input, PCIe X16 slot
MB-7332D	Mini-ITX w/ Celeron 2000E , 2 GLAN,HDMI/DVI/VGA/LVDS, COM Mini-PCIe socket, 4 SATA, 8V ~ 32V DC input, PCIe X16 slot
MB-7332E	Same as MB-7332A, but comes with PCIe X16 & PCIe X1 slots
MB-7332F	Same as MB-7332B, but comes with PCIe X16 & PCIe X1 slots
MB-7332G	Same as MB-7332C, but comes with PCIe X16 & PCIe X1 slots
MB-7332H	Same as MB-7332D, but comes with PCIe X16 & PCIe X1 slots

* If any items are missing or damaged contact sales representative or distributor

Optional Accessory

Photo	Model Name	
	P/N:	IP-S01
	PCIe riser card support 1 x PCIe X16 & 1 x PCI slots <u>Note:</u> Works with MB-7332E through H Series only	
	P/N:	IP-S02
	PCIe riser card support 2 x PCI slots <u>Note:</u> Works with MB-7332E though H Series only	
	P/N:	IP-S03
	PCIe riser card support 1 x PCIe X16 & 1 x PCIe X1 slots <u>Note:</u> Works with with MB-7332E though H Series only	
	P/N:	CB-ICOM38-00
	Dual D-Sub 9-pin COM port card, L/ 250mm, with bracket	
	P/N:	CB-IUSB07-AA
	Dual USB cable, L/ 250mm, with bracket	
	P/N:	CB-IPOW102-00
	P4 4-pin to DC Jack lockable power cable, L/ 200mm	

Safety Information

- To prevent electrical shock hazard disconnect the power cable from the electrical outlet before relocating the system.
- When adding or removing devices to or from the system ensure the power cables for the devices are unplugged before the signal cables are connected. If possible, disconnect all power cables from the existing system before you add a device.
- Before connecting or removing signal cables from the motherboard, ensure that all power cables are unplugged.
- Seek professional assistance before using an adapter or extension cord. These devices could interrupt the grounding circuit.
- Make sure that your power supply is set to the correct voltage for your area.
- If you are not sure about the voltage of the electrical outlet you are using contact your local power company.
- If the power supply is broken do not try to fix it by yourself. Contact a qualified service technician or your retailer.

Operational Safety

- Before installing the motherboard and adding devices to it carefully read all the manuals that came with the package.
- Before using the product make sure all cables are correctly connected and the power cables are not damaged. If you detect any damage, contact your dealer immediately.
- To avoid short circuits, keep paper clips, screws, and staples away from connectors, slots, sockets and circuitry.
- Avoid dust, humidity, and temperature extremes. Do not place the product in areas where it may become wet.
- Place the product on a stable surface.
- If you encounter technical problems with the product contact a qualified service technician or your retailer.

Contents

Chapter 1	General Information	5
1.1	Introduction	8
1.2	Specifications	9
1.3	Block Diagram	11
1.4	Board Layout Dimensions	12
1.5	IO / Connector	14
Chapter 2	Hardware installation	16
2.1	Location of onboard connectors	16
2.2	Location of onboard jumpers	18
2.3	Function list of onboard jumper settings	19
2.3.1	JP1 for Clean CMOS jumper	19
2.3.2	JP3 for Power AT/ATX mode selection	20
2.3.3	JP4 for LVDS voltage select	21
2.3.4	JP4 for LVDS brightness control mode.....	22
2.4	Pin definitions of onboard pin header	23
2.4.1	CN1 for Low Pin Count pin-header	23
2.4.2	CN4 for 8-bit GPIO pin header	24
2.4.3	CN5 & CN6 for DC out for HDD power	25
2.4.4	CN7 & CN8 for USB2.0 pin-header	26
2.4.5	CN9 & CN10 for SATA 3.0/2.0 connector	27
2.4.6	CN11 for SPI programmer pin-header	28
2.4.7	CN12 for PCI-Express X1 slot.....	29
2.4.8	CN14 for COM4, RS232 pin-header	30
2.4.9	CN16 for front panel pin-header	31
2.4.10	CN19 for COM3, RS232 pin-header	32
2.4.11	CN21 for COM2, RS232/422/485	33
2.4.12	CN22 for Half-size Mini-PCIe WLAN LED indictor	35
2.4.13	CN23 for Full-size Mini-PCIe WLAN LED indictor.....	36
2.4.14	CN25 for Full-size Mini-PCIe socket	37



2.4.15	CN26 for Half-size Mini-PCIe sockets	38
2.4.16	CN27 for SIM holder	39
2.4.17	CN28 for Internal P4 4-pin power input connector	40
2.4.18	CN29 for 4-channel Audio inputs	41
2.4.19	CN30 for 4-channel Video inputs.....	42
2.4.20	CN39 for 24-bit dual channel LVDS connector	43
2.4.21	CN40 for LVDS backlight pin-header	45
2.4.22	CPU fan connector & System Fan connector	46

Chapter 3 Programming WDT & GPIO47

3.1	GPIO DOS sample code	47
3.2	WatchDog timer DOS sample code	54

1.1 Introduction

MB-73320 is a Mini-ITX board with onboard Intel® Haswell Mobile CPU with integrated Intel® QM87 Express chipset. Onboard display features include HDMI, DVI-D, VGA and 24-bit dual channel LVDS and two DDR3 SO-DIMM supports a maximum of 16GB DDR3 1600 of system memory.

MB-73320 delivers flexible expansion slots allowing customers to install one PCIe X16 card and two Mini-PCIe cards. It is built with a SIM card holder capable of installing a SIM card with a Full-size Mini-PCIe 3G module for wireless connection. For half-size Mini-PCIe socket it also supports mSATA SSD as storage device (Optional). Furthermore, it comes with a PCIe X1 slot that can be paired with WIN's riser card for an additional 1 ~ 3 PCI slots for various applications.

On the I/O ports, the MB-73320 provides plenty of connectivity. 1x Intel® i211AT GbE LAN and 1x Intel® i217LM controller, 1x RS232/422/485 & 5x RS232, 4x USB3.0 + 6x USB2.0, HD Audio, PS/2 Keyboard/Mouse, 4x SATA with RAID 0/1/5/10 and a LPC pin-header supporting WIN's TPM module for the added information protection. The MB-73320 accepts a wide range 8V ~ 32V DC input suitable for a variety of applications in digital signage, industrial systems, Military, POS, kiosks, and factory automation.

About WIN Enterprises

WIN offers reliable and solid products which are produced under Management System Standards: ISO9001-2000 Certificate. The certificate keeps us focused on our quality objectives of management and environmental production. Its willingness to customize standard products for meet unique customer needs makes WIN different. All ODM projects are welcome. Years of experiences enables WIN to fulfill the customer's vision, by delivering products to exact specifications. The WIN R&D team is proud of its strong engineering background. R&D professionals account for 25% of the WIN workforce. We focus on developing new products for both emerging and established markets

For more information about OEM/ODM projects contact us :

Email: sales@win-ent.com TEL: +886-2-8692-6677



1.2 Specifications

System	
Form Factor	Mini-ITX motherboard
CPU	Intel® Core™ i7-4700EQ, 2.4 GHz, Quad-Core / 6M L2, TDP 47W (MB-7332A) Intel® Core™ i5-4400E, 2.7 GHz, Dual-Core / 3M L2, TDP 37W (MB-7332A) Intel® Core™ i3-4100E, 2.4 GHz, Dual-Core / 3M L2, TDP 35W (MB-7332A)
Chipset	Intel QM87 Express chipset
Memory	2 x 204-pin DDR3 1333/1600 MHz / SODIMM up to 16GB, w/o ECC support
BIOS	AMI SPI BIOS
SSD	Half-size Mini-PCIe socket support mSATA SSD
Watchdog timer	255 levels, 1 ~ 255 sec
Expansion	1 x PCIe X16 slot 1 x PCIe X1 (work with riser card for PCIe X1 or PCI 32-bit/33 MHz expansion slots) 1 x Full-size Mini-PCIe socket w/ USB, PCIe signal 1 x Half-size Mini-PCIe socket w/ USB, PCIe or SATA signal
Board Size	170mm x 170mm
Operating Temp.	0°C~60°C (32°F~140°F)
Storage Temp.	-20°C~80°C (-4°F~176°F)
Operating Hum.	10%~90% (non-condensing)

Display Features	
Chipset	Intel® Haswell processor, integrated
Display interface	1x external HDMI 1.4a
	1x external VGA
	1x external DVI-D
	1x internal 24-bit Dual Channel LVDS

I/O	
Series Port	Internal : 1x RS232/422/485 (COM2), 4x RS232 External : 1x RS232
SATA	4x SATA 6Gb/s, w/ RAID 0/1/5/10
USB	External : 4x USB3.0 + 2 x USB2.0 Internal : 4x USB2.0
Ethernet	1x Intel® i211AT PCIe controller 1x Intel® i217LM PHY support Intel® AMT 9.0
Audio	External : Line-in/out , Mic-in Internal : Line-out , Mic-in
Digital I/O	8-bit GPIO interface




Custom Embedded Solutions

LPC	1x LPC 2 x 10-pin header for Optional TPM module
Other	2x cooling Fan header (Smart fan support) , 1 x PS/2 keyboard/Mouse 1x Front Panel header for power on/off, reset, HDD/power LED indicator 1x LVDS Backlight/inverter pin-header


Power	
Power in	Wide range DC 8V ~ 32V input (AT/ATX mode select by jumper)
Connector	1x internal P4 4-pin power connector



Note: Specifications and photos subject to change without notice

1.3 Block Diagram





1.4 Board Layout Dimensions






1.5 IO ports





2.1 The location of onboard connectors






Label	Function
CN1	Low Pin Count
CN2	SATA3
CN3	SATA3
CN4	SATA power
CN5	SATA power
CN6	GPIO
CN7	USB 2.0 Pin header
CN8	USB 2.0 Pin header
CN9	SATA3
CN10	SATA3
CN11	SPI Programmer
CN12	PCI-Express X1 slot
CN13	Power on/off, Reset, HDD/Power LED
CN14	LVDS backlight inverter
CN15	COM4
CN16	COM3
CN17	COM5
CN18	24-bit LVDS
CN19	COM6
CN20	COM2
CN21	PCI-Express X16 slot

Label	Function
CN22	Half-size Mini-PCIe LED
CN23	Full-size Mini-PCIe LED
CN24	Full-size Mini-PCIe socket
CN25	Half-size Mini-PCIe socket
CN26	SIM card holder
CN27	SMBUS pin header
CN28	P4 4-pin power input connector
CN29	RJ45 LAN + Dual USB 3.0
CN30	RJ45 LAN + Dual USB 3.0
CN31	PS2 keyboard/mouse + Dual USB 2.0
CN32	Audio jack
CN33	VGA connector
CN34	COM1
CN35	HDMI connector
CN36	N/C
CN37	DVI-D connector
CN38	Front Audio header
CN39	N/C
CN40	N/C
CN41	N/C
CN42	N/C

2.2 The location of onboard jumpers




Label	Function
JP1	Panel Voltage (VCC) select
JP2	COM3 Pin-9 select mode (RI/5V/12V)
JP3	COM4 Pin-9 select mode (RI/5V/12V)
JP4	LVDS backlight control mode select
JP5	CMOS Clear jumper
JP6	AT/ATX power mode jumper select

2.3 The function list of onboard jumpers setting

- 2.3.1 : JP1 for Panel Voltage select

JP1	
Closed Pin	Result
1-2 *	+3.3V
3-4	+5V
5-6	+12V


* Default setting



- 2.3.2: JP2 for COM3 box header Pin-8 function select

JP2	
Closed Pin	Result
1-2 *	RI
3-4	+5V
5-6	+12V


* Default setting



- 2.3.3: JP3 for COM4 box header Pin-8 function select

JP3	
Closed Pin	Result
1-2 *	RI
3-4	+5V
5-6	+12V


* Default setting



- 2.3.4 : JP4 for LVDS brightness control mode

JP4	
Closed Pin	Result
1-2	PWM mode
2-3 *	DC Level

* Default setting




- 2.3.1 : JP5 for Clear CMOS

If you want to clean the CMOS data, set jumper to 2-3 just for few seconds, Then,
Move the jumper back to 1-2 pin

JP5	
Closed Pin	Result
1-2 *	Normal
2-3	Clear CMOS


* Default setting



- 2.3.2: JP6 for ATX / AT mode

JP6	
Closed Pin	Result
1-2 *	ATX mode
2-3	AT mode


* Default setting



2.4 The pin define of onboard pin header

- 2.4.1 : CN1 for Low Pin Count pin-header

CN1 : 2 x 7 header , pitch 2.0 mm			
Pin	Signal	Pin	Signal
1	+3.3V	2	LAD0
3	LAD1	4	LAD2
5	LAD3	6	LFRAME
7	Reset	8	+5V
9	LCLK	10	LPME
11	GND		Key
13	SERIRQ	14	LDRQ




- 2.4.2 : CN4 & CN5 for 4-pin HDD power

CN4 : 4-pin wafer for SATA power connector			
Pin	Signal	Pin	Signal
1	+12V	2	GND
3	GND	4	+5V

Note: Maximum output current 12V/1A, 5V/1A


CN5 : 4-pin wafer for SATA power connector			
Pin	Signal	Pin	Signal
1	+12V	2	GND
3	GND	4	+5V

Note: Maximum output current 12V/1A, 5V/1A



2.4.3 : CN6 for 8-bit GPIO


CN6 : 2 x 6 header , pitch 2.0 mm			
Pin	Signal	Pin	Signal
1	+3.3V	2	GPI0
3	GPI1	4	GPI2
5	GPI3	6	GPO0
7	GPO1	8	GPO2
9	GPO3	10	Key
11	+5V	12	GND



- 2.4.4 : CN7 & CN8 for USB 6/7 , USB 8/9


CN7: 2 x 5 header , pitch 2.54 mm			
Pin	Signal	Pin	Signal
1	+5V	2	+5V
3	USB6_data-	4	USB7_data-
5	USB6_data+	6	USB7_data+
7	GND	8	GND
9	Key	10	GND

CN8: 2 x 5 header , pitch 2.54 mm			
Pin	Signal	Pin	Signal
1	+5V	2	+5V
3	USB8_data-	4	USB9_data-
5	USB8_data+	6	USB9_data+
7	GND	8	GND
9	Key	10	GND



- 2.4.5 : CN11 for SPI programmer


CN11 : 2 x 4 header , pitch 2.54 mm			
Pin	Signal	Pin	Signal
1	+3.3V	2	GND
3	CS_N (Chip Select)	4	SCLK (Serial Clock)
5	MISO (Master Input, Slave Output)	6	MOSI (Master Output, Slave Input)
7	N/C	8	FLASH_IO




- 2.4.6 : CN12 for PCI-Express X1 slot

Note: This slot could work with WIN's RE-S0X riser card to get PCIe X16 & PCI expansion slots
Regarding the PCIe X16 slot, The maximum power supported is a 35W PCIe add-on card

Pin	Side B	Side A
1	+12V	PRSNT1
2	+12V	+12V
3	+12V	+12V
4	GND	GND
5	SMCLK	TCK
6	SMDAT	TDI
7	GND	TOD
8	+3.3V	TMS
9	RST	+3.3V
10	+3.3V AUX	+3.3V
11	WAKE	PWRGD
Key Notch		
12	Reserved	GND
13	GND	REFCLK+
14	HSOp	REFCLK-
15	HSOn	GND
16	GND	HSIp
17	PRSNT2	HSIn
18	GND	GND




Configuration of MB-7332C with IP-S01 riser card




- 2.4.7 : CN13 for Front panel

CN13 : 2 x 4 header , pitch 2.54 mm			
Pin	Signal	Pin	Signal
1	HDD_LED+	2	Power_LED+
3	HDD_LED-	4	GND
5	GND	6	GND
7	RESET+	8	Power Switch




- 2.4.8 : CN14 for LVDS Backlight pin header

CN14: 1 x 5 wafer , Pitch : Pitch 2.0 mm			
Pin	Signal	Pin	Signal
1	+12V	2	GND
3	Backlight Enable	4	Backlight Control
5	+5V		




- 2.4.9 : CN15 for COM4 box header

CN15 : 2 x 5 header, pitch 2.00 mm			
Pin	Signal	Pin	Signal
1	DCD, Data carrier detect	2	DSR, Data set ready
3	RXD, Receive Data	4	RTS, Request to send
5	TXD, Send Data	6	CTS, Clear to se
7	DTR, Data Terminal Ready	8	RI, Ring indicator
9	GND	10	N/C




- 2.4.10 : CN16 for COM3 box header

CN16 : 2 x 5 header, pitch 2.00 mm			
Pin	Signal	Pin	Signal
1	DCD, Data carrier detect	2	DSR, Data set ready
3	RXD, Receive Data	4	RTS, Request to send
5	TXD, Send Data	6	CTS, Clear to se
7	DTR, Data Terminal Ready	8	RI, Ring indicator
9	GND	10	N/C




- 2.4.11 : CN17 for COM5 box header

CN17 : 2 x 5 header, pitch 2.00 mm			
Pin	Signal	Pin	Signal
1	DCD, Data carrier detect	2	DSR, Data set ready
3	RXD, Receive Data	4	RTS, Request to send
5	TXD, Send Data	6	CTS, Clear to se
7	DTR, Data Terminal Ready	8	RI, Ring indicator
9	GND	10	N/C




- 2.4.12 : CN18 for 24-bit Dual Channel LVDS

CN18 : connector type : DF13A-40DP-1.25V					
Pin	Signal	Pin	Signal	Pin	Signal
1	LVDS_VCC	15	LVDSA_1+	29	GND
2	LVDS_VCC	16	LVDSB_1+	30	GND
3	LVDS_VCC	17	GND	31	DDC_Clock
4	LVDS_VCC	18	GND	32	DDC_Data
5	GND	19	LVDSA_2-	33	GND
6	GND	20	LVDSB_2-	34	GND
7	LVDSA_0-	21	LVDSA_2+	35	LVDSA_3-
8	LVDSB_0-	22	LVDSB_2+	36	LVDSB_3-
9	LVDSA_0+	23	GND	37	LVDSA_3+
10	LVDSB_0+	24	GND	38	LVDSB_3+
11	GND	25	LVDSA_Clock-	39	SMB_Clock
12	GND	26	LVDSB_Clock-	40	SMB_Data
13	LVDSA_1-	27	LVDSA_Clock+		
14	LVDSB_1-	28	LVDSB_Clock+		



- 2.4.13 : CN19 for COM6 box header


CN19 : 2 x 5 header, pitch 2.00 mm			
Pin	Signal	Pin	Signal
1	DCD, Data carrier detect	2	DSR, Data set ready
3	RXD, Receive Data	4	RTS, Request to send
5	TXD, Send Data	6	CTS, Clear to se
7	DTR, Data Terminal Ready	8	RI, Ring indicator
9	GND	10	N/C



- 2.4.14 : CN20 for COM2 , RS232/422/485

Note: COM2 RS-232/422/485 can be set by BIOS setting. Default is RS-232.

CN20 : 2 x 5 header , Pitch 2.00 mm			
Pin	RS232 mode	RS422 mode	RS485 mode
1	DCD, Data carrier detect	TXD-	TXD-
2	DSR, Data set ready		
3	RXD, Received Data	TXD+	TXD+
4	RTS, Request to send		
5	TXD, Transmitted Data	RXD+	
6	CTS, Clear to sent		
7	DTR, Data terminal ready	RXD-	
8	RI, Ring indicator		
9	GND		
10	N/C		




- 2.4.15 : CN22 for Half-size Mini-PCiE WLAN LED indicator

CN22 : 1 x 2 , 2-pin wafer			
Pin	Signal	Pin	Signal
1	LED_WLAN	2	+3.3V


Note: Half-size Mini-PCiE card could support USB , SATA or PCIe signal.

You can select different modes in the BIOS . The default setting is PCIe signal.




- 2.4.16 : CN23 for Full-size Mini-PCIe WLAN LED indicator

CN23 : 1 x 2 , 2-pin wafer			
Pin	Signal	Pin	Signal
1	LED_WLAN	2	+3.3V



- 2.4.17 : CN24 for Full-size Mini-PCIe socket

Pin	Signal	Pin	Signal
1	WAKE	27	GND
2	+3.3V AUX	28	+1.5V
3	N/C	29	GND
4	GND	30	SMBCLK
5	N/C	31	PETN0
6	+1.5V	32	SMBDATA
7	CLKREQ	33	PETP0
8	UIM_PWR	34	GND
9	GND	35	GND
10	UIM_DATA	36	USB_D-
11	REFCLK-	37	GND
12	UIM_CLK	38	USB_D+
13	REFCLK+	39	+3.3V AUX
14	UIM_RESET	40	GND
15	GND	41	+3.3V AUX
16	UIM_VPP	42	LED_WWAN
17	UIM_C8	43	GND
18	GND	44	LED_WLAN
19	UIM_C4	45	N/C
20	W_Disable	46	N/C
21	GND	47	N/C
22	PERST	48	+1.5V
23	PERN0	49	N/C
24	+3.3V AUX	50	GND
25	PERP0	51	N/C
26	GND	52	+3.3V AUX




- 2.4.18 : CN25 for Half-size Mini-PCiE socket.

Note: Half-size Mini-PCiE card could support SATA or PCIe signal. The default setting is PCIe signal.


You can select different mode in the BIOS

Pin	Signal	Pin	Signal
1	WAKE	27	GND
2	+3.3V AUX	28	+1.5V
3	Reserved	29	GND
4	GND	30	SMBCLK
5	Reserved	31	PETN0
6	+1.5V	32	SMBDATA
7	CLKREQ	33	PETP0
8	Reserved	34	GND
9	GND	35	GND
10	UIM_DATA	36	USB_D-
11	REFCLK-	37	Reserved
12	Reserved	38	USB_D+
13	REFCLK+	39	Reserved
14	Reserved	40	GND
15	GND	41	Reserved
16	Reserved	42	LED_WWAN
17	Reserved	43	Reserved
18	GND	44	LED_WLAN
19	Reserved	45	Reserved
20	Reserved	46	N/C
21	GND	47	Reserved
22	PERST	48	+1.5V
23	PERN0	49	Reserved
24	+3.3V AUX	50	GND
25	PERP0	51	Reserved
26	GND	52	+3.3V




- 2.4.19 : CN26 for SIM holder

CN26 : SIM card holder			
Pin	Signal	Pin	Signal
C1	VCC	C2	RESET
C3	CLOCK	C4	Reserved
C5	GND	C6	VPP
C7	I/O	C8	Reserved




- 2.4.16 : CN27 for SMBUS pin header

CN27 : 1 x 5 pin header , 2.00 mm pitch			
Pin	Signal	Pin	Signal
1	+5V	2	Clock
3	Data	4	N/C
5	GND		




- 2.4.17 : CN28 for internal 4-pin power input

CN28 : ATX 2 x 2			
Pin	Signal	Pin	Signal
1	GND	2	GND
3	8V ~ 32V DC input	4	8V ~ 32V DC input



- 2.4.13 : CN38 for front panel Audio pin header


CN38 : 2 x 5 header, pitch 2.00 mm			
Pin	Signal	Pin	Signal
1	Mic-In_L	2	GND
3	Mic-In_R	4	N/C
5	Line-Out_R	6	Mic-In_JD
7	GND	8	N/C
9	Line-Out_L	10	Line-Out_JD



3. BIOS setting Menu


- 3.1 Main Menu

The Main Menu of BIOS Setup Utility provides a quick overview of basic system information and the ability to change the systems: date, time, etc.



- 3.2 Advanced Menu

The Advanced Menu of BIOS Setup Utility allows users to configure advanced system settings.



- 3.2.1 Advanced Menu

PCI Express Setting:

Description: This item manually sets the maximum read request size of the PCI Express device or allows the system BIOS to choose the value (Auto). The options are Auto, 128 Bytes, 256 Bytes, 512 Bytes, 1024 Bytes, 2048 Bytes and 4096 Bytes.

```

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
Advanced
PCI Express Device Register Settings
Relaxed Ordering                [Disabled]
Extended Tag                    [Disabled]
No Snoop                       [Enabled]
Maximum Payload                 [Auto]
Maximum Read Request           [Auto]

PCI Express Link Register Settings
ASPM Support                    [Disabled]
WARNING: Enabling ASPM may cause some
          PCI-E devices to fail
Extended Synch                  [Disabled]

Link Training Retry             [5]
Link Training Timeout (uS)     100
Unpopulated Links              [Keep Link ON]
Restore PCIE Registers         [Disabled]

++: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.15.1236. Copyright (C) 2012 American Megatrends, Inc.


```

- 3.2.2 Advanced Menu

ACPI Setting:

Enable ACPI Auto Configuration < Disable >

Description: Use this feature to configure Advanced Configuration and Power Interface (ACPI) power management settings for your system.



- 3.2.3 Advanced Menu

Trusted Computing:

Security Device Support < Disable >

Description: Select Enabled to activate support for trusted platforms (TPM 1.1/1.2) and allow the BIOS to automatically download the drivers needed to provide support for the platforms specified. The options are Disable and Enable.



- 3.2.4 Advanced Menu

CPU Configuration:

This item displays the current CPU Revision, Current CPU1 Memory Frequency, Memory Type and Memory Reference Code Revision.

Hyper-threading :

Intel® Hyper Threading Technology (Available when supported by the OS and the CPU). Select Enabled to enable HyperThreading support to increase CPU performance. The options are Enabled and Disabled.

Active Processor Cores :

Set to Enabled to use a processor's Second Core and beyond. (Please refer to Intel's web site for more information.) The options are All, 1, 2 and 3.

```

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
  Advanced
CPU Configuration
Intel(R) Core(TM) i7-4700HQ CPU @ 2.40GHz
CPU Signature          306c3
Microcode Patch       8
Max CPU Speed         2400 MHz
Min CPU Speed         800 MHz
CPU Speed             3200 MHz
Processor Cores       4
Intel HT Technology    Supported
Intel VT-x Technology Supported
Intel SMX Technology   Not Supported
64-bit                Supported
EIST Technology        Supported
CPU C3 state          Supported
CPU C6 state          Supported
CPU C7 state          Supported

L1 Data Cache         32 KB x 4
L1 Code Cache         32 KB x 4
L2 Cache              256 KB x 4
L3 Cache              6144 KB

Hyper-threading       [Enabled]
Active Processor Cores [All]

Enabled for Windows XP and
Linux (OS optimized for
Hyper-Threading Technology)
and Disabled for other OS (OS
not optimized for
Hyper-Threading Technology).
When Disabled only one thread
per enabled core is enabled.

++: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.15.1236. Copyright (C) 2012 American Megatrends, Inc.
  
```


- 3.2.5 Advanced Menu

SATA Configuration:

When this submenu is selected, the AMI BIOS automatically detects the presence of the IDE Devices and displays the following items:

SATA Mode Selection:


This item selects the mode for the installed drives. The options are Disabled, IDE Mode, AHCI Mode and RAID Mode.



- 3.2.6 Advanced Menu

Intel® Rapid Start Technology: < Disabled >


Description: Intel® Rapid Start Technology enables your system to get up and running faster from even the deepest sleep, saving time and power consumption.



- 3.2.6 Advanced Menu

Intel® AMT: < Enabled >

Description: This option enables Intel® AMT support. The options are Enabled and Disabled.




- 3.2.6 Advanced Menu

USB Configuration:

This feature enables support for USB function parameters. The options are Enabled, and Disabled.

Legacy USB Support:

This feature enables support for legacy USB devices. Select Auto to disable legacy support if USB devices are not present. Select Disable to have USB devices available only for EFI applications. The options are Enabled, Disabled and Auto.



- 3.2.6 Advanced Menu

SATA PCIE select:

Select Half-size Mini-PCIe socket to support SATA signal or PCIe signal.

Default is support STAT signal

COM2 port mode:


Select COM2 port to support RS232, RS-422 or RS485 mode.

Default is RS232 mode.

WatchDog™ Function:

Allows AMT to reset or power down the system if the operating system or BIOS hangs or crashes.


The options are Disabled, and Enabled.



- 3.2.6 Advanced Menu

F81866 Super IO Configuration:

Description: Select Enabled to enable the onboard serial port. The options are Enabled and Disabled.




- 3.2.7 Advanced Menu

F81866 H/W monitor:

Smart Fan Mode Configuration < Enabled/Disabled >


Description: This feature allows the user to check CPU temperature and the fan speed. And also displays the current voltages of the above voltage monitors.



- 3.2.8 Advanced Menu

Smart Fan Mode Configuration

This feature allows the user to decide how the system controls the speeds of the onboard fans. The CPU temperature and the fan speed are correlative. When the CPU on-die temperature increases, the fan speed will also increase for effective system cooling. Select "Full Speed" to allow the onboard fans to run at full speed (of 100% Pulse Width Modulation Duty Cycle) for maximum cooling.



- 3.2.10 Advanced Menu

Serial Port Console Redirection

Console Redirection < Disabled >

Description: This feature allows the user to remotely access the entire boot sequence via a serial console. Default setting is Disabled.




- 3.3 Chipset Menu

Serial Port Console Redirection

Console Redirection < Disabled >

Description : This feature allows the user to remotely access the entire boot sequence via a serial console. Default setting is Disabled.



- 3.3.1 Chipset Menu

PCH LAN Controller:

Select Enabled to enable the onboard gigabit Ethernet controller. The settings are Enabled and Disabled

Wake on LAN:

Select Enabled to enable the capability to 'wake-up' the system from the S5~power state (Soft Off State) through the Ethernet controller. The settings are Enabled and Disabled.

Restore AC Power Loss:

Use this feature to set the power state after a power outage. Select Power-Off for the system power to remain off after a power loss. Select Power-On for the system power to be turned on after a power loss. Select Last State to allow the system to resume its' last power state before a power lost. The options are Power-On, Power-Off and Last State.

```

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
  Chipset

Intel PCH RC Version          1.4.0.0
Intel PCH SKU Name           QM87
Intel PCH Rev ID              05/C2

▶ PCI Express Configuration
▶ USB Configuration
▶ PCH Azalia Configuration

PCH LAN Controller           [Enabled]
  Wake on LAN                 [Enabled]
  SLP_LAN# Low on DC Power    [Enabled]
Board Capability              [SUS_PWR_DN_ACK]
GP27 Wake From DeepSx        [Enabled]
SLP_S4 Assertion Width       [1-2 Seconds]
Restore AC Power Loss         [Last State]

PCI Express Configuration settings

+*: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit


Version 2.15.1236. Copyright (C) 2012 American Megatrends, Inc.

```

- 3.3.2 Chipset Menu

PCI Express Configuration:


Description: Use this feature to enable or disable PCIe slot Option ROMs. The options are Disabled and Enabled.



- 3.3.3 Chipset Menu

PCH Azalia Configuration:

Description: Select Enabled to enable the Azalia High Definition Audio feature. The settings are Enabled and Disabled.




- 3.3.4 Chipset Menu

VT-d Capability: (Available when supported by the CPU)

VT-d < Disabled/enabled >

Description: Select Enabled to enable Intel's Virtualization Technology support for Direct I/O VT-d by reporting the I/O device assignments to VMM through the DMAR ACPI Tables. This feature offers fully-protected I/O resource sharing across the Intel platforms, providing the user with greater reliability, security and availability in networking and data-sharing. The settings are Enabled and Disabled.



- 3.3.6 Chipset Menu


Graphics Configuration:

Description: Select primary video device that BIOS will use to for output

Default setting is <Auto>

IGT : Integrated Graphics Device.

PEG : PCI Express Graphics




- 3.3.7 Chipset Menu

PCH-IO Configuration:

LCD Control

Description: This feature allows the user to select different LVDS Panel modes, resolutions and backlight level.




- 3.3.7 Chipset Menu

Memory Information

This item displays the current Memory Frequency, Memory Type and Memory Reference Code Revision.

Memory Frequency:

Description: This feature allows the user to select the memory speed. Under normal conditions, please set this to Auto.



Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
Chipset

Memory Information	
Memory RC Version	1.4.0.3
Memory Frequency	1600 Mhz
Total Memory	4096 MB (DDR3)
Memory Voltage	1.35v
DIMM#0	4096 MB (DDR3)
DIMM#2	Not Present
CAS Latency (tCL)	11
Minimum delay time	
CAS to RAS (tRCDmin)	11
Row Precharge (tRPmin)	11
Active to Precharge (tRASmin)	28
XMP Profile 1	Not Supported
XMP Profile 2	Not Supported
DIMM profile [Default DIMM profile]	
Memory Frequency Limiter	[Auto]
DDR Reset Wait Time	0
Max TOLUD	[Dynamic]
Enh Interleave Support	[Enabled]
RI Support	[Enabled]
DLL Weak Lock Support	[Enabled]
Mc Lock	[Enabled]
Ch Hash Support	[Enabled]

Select DIMM timing profile that should be used.

++: Select Screen
 ↑↓: Select Item
 Enter: Select
 +/-: Change Opt.
 F1: General Help
 F2: Previous Values
 F3: Optimized Defaults
 F4: Save & Exit
 ESC: Exit

Version 2.15.1236. Copyright (C) 2012 American Megatrends, Inc.


- 3.4 Boot Menu

Boot Configuration:

This feature allows the user to specify which devices are boot devices and the order of priority from which the systems boots from during startup.

Fast Boot:

This feature allows booting with initialization with a minimal set of devices required to launch an active boot option. The options are Disabled, and Enabled.



- 3.5 Security Menu

Password Description:

Description:

Administrator Password: Press Enter to create a new, or change an existing Administrator password.

User Password: Press Enter to create a new or change an existing User password.

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.					
Main Advanced Chipset Boot Security Save & Exit					
<p>Password Description</p> <p>If ONLY the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup.</p> <p>If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User will have Administrator rights.</p> <p>The password length must be in the following range:</p> <table> <tr> <td>Minimum length</td> <td>3</td> </tr> <tr> <td>Maximum length</td> <td>20</td> </tr> </table> <p>Administrator Password</p> <p>User Password</p>	Minimum length	3	Maximum length	20	<p>Set Administrator Password</p> <hr/> <p> ⇧⇩: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit </p>
Minimum length	3				
Maximum length	20				
Version 2.15.1236. Copyright (C) 2012 American Megatrends, Inc.					


- 3.6 Save & Exit Menu

Description:

Save Change and Reset: When you have completed the system configuration changes, select this option to leave the BIOS Setup Utility and reboot the computer, so the new system configuration parameters can take effect. Select Save Changes and Exit from the Exit menu and press <Enter>

Discard Changes and Reset: Select this option to quit the BIOS Setup without making any permanent changes to the system configuration, and reboot the computer. Select Discard Changes and Exit from the Exit menu and press <Enter>.

Restored Defaults : To set this feature, select Restore Defaults from the Exit menu and press <Enter>. These are factory settings designed for maximum system stability, but not for maximum performance.



4.1 GPIO Sample Program for DOS environment

```
//WIN GPIO Program for MB-73320 (DOS Version)
#include <stdio.h>
#include <dos.h>
#include <inlines/pc.h>

#define index_port 0x2E      //Super IO Index Port Address
#define data_port 0x2F      //Super IO Data Port Address

void Enter_sio_config();
void Exit_sio_config();
void help();

int main(int argc, char *argv[])
{
    int val, GPIO_SEL;

    if (argc!=2){
        help();
        return;
    }

    Enter_sio_config();
    if(strcmp(argv[1], "-r") == 0){
        printf("Read GP80~GP83\n");
        outportb(index_port, 0x8A);
        val = inportb(data_port);

        if ((val&0x01) == 0x00)
            printf("GPI80 -> Low\n");
        else
            printf("GPI80 -> High\n");

        if ((val&0x02) == 0x00)
            printf("GPI81 -> Low\n");
```

```
else
    printf("GPI81 -> High\n");

if ((val&0x04) == 0x00)
    printf("GPI82 -> Low\n");
else
    printf("GPI82 -> High\n");

if ((val&0x08) == 0x00)
    printf("GPI83 -> Low\n");
else
    printf("GPI83 -> High\n");
}
else if(strcmp(argv[1], "-84h") == 0){
    printf("(GPO84 High >> 3.3v)\n");
    GPIO_SEL = 0x10;
    outportb(index_port, 0x89);
    val = inportb(data_port)|GPIO_SEL;
    outportb(data_port, val);
}
else if(strcmp(argv[1], "-84l") == 0){
    printf("(GPO84 Low >> 0.0v)\n");
    GPIO_SEL = 0x10;
    outportb(index_port, 0x89);
    val = inportb(data_port)&(~GPIO_SEL);
    outportb(data_port, val);
}

else if(strcmp(argv[1], "-85h") == 0){
    printf("(GPO85 High >> 3.3v)\n");
    GPIO_SEL = 0x20;
    outportb(index_port, 0x89);
    val = inportb(data_port)|GPIO_SEL;
    outportb(data_port, val);
}
else if(strcmp(argv[1], "-85l") == 0){
    printf("(GPO85 Low >> 0.0v)\n");
```

```

        GPIO_SEL = 0x20;
        outportb(index_port, 0x89);
        val = inportb(data_port)&(~GPIO_SEL);
        outportb(data_port, val);
    }

else if(strcmp(argv[1], "-86h") == 0){
    printf("(GPO86 High >> 3.3v)\n");
    GPIO_SEL = 0x40;
    outportb(index_port, 0x89);
    val = inportb(data_port)|GPIO_SEL;
    outportb(data_port, val);
}

else if(strcmp(argv[1], "-86l") == 0){
    printf("(GPO86 Low >> 0.0v)\n");
    GPIO_SEL = 0x40;
    outportb(index_port, 0x89);
    val = inportb(data_port)&(~GPIO_SEL);
    outportb(data_port, val);
}

else if(strcmp(argv[1], "-87h") == 0){
    printf("(GPO87 High >> 3.3v)\n");
    GPIO_SEL = 0x80;
    outportb(index_port, 0x89);
    val = inportb(data_port)|GPIO_SEL;
    outportb(data_port, val);
}

else if(strcmp(argv[1], "-87l") == 0){
    printf("(GPO87 Low >> 0.0v)\n");
    GPIO_SEL = 0x80;
    outportb(index_port, 0x89);
    val = inportb(data_port)&(~GPIO_SEL);
    outportb(data_port, val);
}

else{
    help();
}

```

```
Exit_sio_config();
return;
}

void help()
{
    printf("WIN GPI Program\n");
    printf("Usage:\n");
    printf("GPIO -r (Read F81866 GP80~GP83)\n");
    printf("GPIO -xh (x=84~87, and set GPx to high)\n");
    printf("GPIO -xl (x=84~87, and set GPx to low )\n");
    printf("ex:          \n");
    printf("GPIO -84h (Set GP84 to high)\n");
}

void Enter_sio_config()
{
    outportb(index_port, 0x87);
    delay(1);          //delay some time
    outportb(index_port, 0x87);
    outportb(index_port, 0x07);
    outportb(data_port, 0x06);
}

void Exit_sio_config()
{
    outportb(index_port, 0xAA);
}
```

4.2 Watchdog timer Sample Program for DOS environment

```
//WIN Watch dog program for MB-73320 (DOS Version)
#include <stdio.h>
#include <string.h>
#include <dos.h>
#include <stdlib.h>
#include <inlines/pc.h>

#define index_port 0x2E           //Super IO Index port address
#define data_port  0x2F         //Super IO Data port address

void Enter_sio_config();
void Exit_sio_config();
void help();

int main(int argc, char *argv[])
{
    int data_rw8, time;

    if (argc<2){
        help();
        return;
    }

    if(strcmp(argv[1], "-s") == 0){
        //Show Watchdog Register Settings
        Enter_sio_config();
        outportb(index_port, 0xF5);
        data_rw8 = inportb(data_port)&0x08;
        if(data_rw8 == 0x00){
            //second mode
            outportb(index_port, 0xF6);
            data_rw8 = inportb(data_port);
            printf("Second mode: %d second\n", data_rw8);
        }
    }
}
```

```

else{
    //minute mode
    outportb(index_port, 0xF6);
    data_rw8 = inportb(data_port);
    printf("Minute mode: %d minute\n", data_rw8);
}
}
else if(strcmp(argv[1], "-t") ==0){
    //Set Time-out Value
    if(argv[2] == NULL){
        help();
        return;
    }
    else{
        Enter_sio_config();
        outportb(index_port, 0xF6);
        outportb(data_port , 0x00);           //Clear Status
        outportb(index_port, 0xF5);
        data_rw8 = 0x32;
        outportb(data_port, data_rw8);
        sscanf(argv[2], "%d", &time);
        outportb(index_port, 0xF6);
        outportb(data_port, time);
        if(time==0){
            //Disable count
            outportb(index_port, 0xF5);
            data_rw8 = inportb(data_port)&0xCF;
            outportb(data_port , data_rw8);
        }
        else{
            outportb(index_port, 0xFA);
            outportb(data_port , 0x01);           //Enable reset function
        }
        printf("Watchdog Timer will count down for %d second(s)\n", time);
    }
}
}
else if(strcmp(argv[1], "-m") ==0 ){

```

```

//Set Time-out Value
if(argv[2] == NULL){
    help();
    return;
}
else{
    Enter_sio_config();
    outportb(index_port, 0xF6);
    outportb(data_port , 0x00);           //Clear Status
    outportb(index_port, 0xF5);
    data_rw8 = 0x32;
    data_rw8 |= 0x08;
    outportb(data_port, data_rw8);
    sscanf(argv[2], "%d", &time);
    outportb(index_port, 0xF6);
    outportb(data_port, time);
    if(time==0){
        //Disable count
        outportb(index_port, 0xF5);
        data_rw8 = inportb(data_port)&0xCF;
        outportb(data_port , data_rw8);
    }
    else{
        outportb(index_port, 0xFA);
        outportb(data_port , 0x01);       //Enable reset function
    }
    printf("Watchdog Timer will count down for %d minute(s)\n", time);
}
}
Exit_sio_config();
return;
}

void Enter_sio_config()           //Enter W83627EHF Configuration
{
    outportb(index_port, 0x87);
    delay(1);                     //Delay some time
}

```

```
    outportb(index_port, 0x87);
    outportb(index_port, 0x07);           //Super IO Selct Bank Register Number
    outportb(data_port , 0x07);         //Select logical device 7
}

void Exit_sio_config()                  //Exit W83627EHF Configuration
{
    outportb(index_port, 0xAA);
}

void help()
{
    printf("WIN Watchdog Timer Program\n");
    printf("Usage: WDT -s   (Show Watchdog Register Settings)\n");
    printf("Usage: WDT -t xxx (Set Time-out Value)\n");
    printf("    xxx = 1 ~ 255 seconds\n");
    printf("    xxx = 0 : Time-out Disable \n");
    printf("Usage: WDT -m xxx (Set Time-out Value)\n");
    printf("    xxx = 1 ~ 255 minutes\n");
    printf("    xxx = 0 : Time-out Disable \n");
}
```




Device Resources