RENESAS

R0E510Y16LVB00

Low voltage OCD Board for RL78/G10 Groups

1. Overview

R0E510Y16LVB00 is a debug board for R5F10Y16ASP, R5F10Y14ASP in RL78/G10 groups, which is enabled to effective debug of hardware and software on low voltage user system.

This product is used with E1 emulator. And a box connector of 2.45mm pitch is needed to connecting user system.

Also refer to E1/E20 Emulator Additional Document for User's Manual (Notes on Connecting RL78), when you use this product.




Figure 1 System Configuration

2. Specifications

Table 1 shows the functional specifications of this product.

	Table 1 Specifications of this product	
Item	Specification	
Target MCU	R5F10Y16ASP, R5F10Y14ASP	
Support Emulator	E1 emulator (E20 emulator is not supported)	
Target I/F	8510-4500 : 10-pin type connecter, Sumitomo 3M Limited	
Power supply for this product	Emulator or Target system*	
Operating voltage	2.0V to 5.0V	
Operating temperature	5 to 35°C (No condensation)	
Storage temperature	-15 to 60°C (No condensation)	
Dimensions	60mm * 60mm (Does not include projection) Refer to figure2.	
Weight	16g	

Note* If the user system power supply is turned on be before starting debugger, this product uses 150mA current from user system.



R20UT2451EJ0100 Rev.1.00 Dec 20, 2012

3. Dimensions of This Product




Figure 2 Dimensions of this product (R0E510YLVB00)

4. Internal Circuit





Figure 3 Internal circuit of this product (R0E510YLVB00)



5. Connecting Low voltage OCD board with user system

For connecting Low voltage OCD board with user system, need to mount a connector on user system. Refer to this chapter and user manual of devices, when you design your system.

5.1 The connector for connecting user system and mounting connector



The connector for mounting user system and mounting connector Figure 4

5.2 Pin assignments of the connector on the user system

Table 2 Pin assignments of the connector				
Pin No.	Pin Name	Input/Output*	Remarks	
1	P40	-	P40 is connected with target power supply through 100k ohm.	
2	P125/RESET	Output	-	
3	P137	Output	-	
4	VSS	-	-	
5	VDD	-	-	
6	P00	Input / Output	-	
7	P01	Input / Output	-	
8	P02	Input / Output	-	
9	P03	Input / Output	-	
10	P04	Input / Output	-	

Table 2	Din accimments	of the connector
Table 2	Pin assignments	of the connector

Note* As seen from this product (R0E510Y16LVB00)

6. Use procedure

Use this product (R0E510Y16LVB00) by the following procedure.

Connecting this product with emulator.
Connect CN1 of this product with user interface connector of E1 emulator using 14-pin user interface cable.
\downarrow
Connecting this product with user system
Connect CN2 of this product with user system.
↓
Connecting the emulator with host machine
Connect the emulator with host machine using USB cable.
\downarrow
Starting debugger
Start debugger and download user program.
(When you start debugger, you set a setting for using low voltage OCD board. About the method of detail setting, refer to user's manual of debugger)
About the method of detail setting, refer to user's manual of debugger)
Turning on the power supply of user system
Turn on the power supply of user system. You can start debug.
Turning off the power supply of user system
After finishing the debug, turn off the power supply of user system while user program stop.
(After turn off the power supply, do not operate anything besides exiting debugger)
↓
Exiting debugger
Exit debugger.
\downarrow
Disconnecting the emulator from host machine
Disconnect USB cable from the emulator and host machine.
↓
Disconnecting this product from user system
Disconnect CN2 of this product from user system.
↓
Disconnecting this product from the emulator
Disconnect user interface cable from this product and the emulator.



7. Notes on Usage

Read the following notes before using this product. Incorrect operation will damage this product, the user system and the user program.

Notes on Connecting the Low voltage OCD board:

- Cables must not be connected or disconnected while the user system power is on.
- Before connecting this product with the user system, check that the pin 1 locations on both sides.

Note on Rewriting the Flash Memory:

• The number of MCU's flash memory rewriting on this product is limited. If an erasing error occurs during debugging, replace this product.

Notes on Debugging:

• P40 is not connected microcontroller for debug on this product. It is not possible to debug of P40 port function in this product.

Note on the Flash Programming Software Products (Renesas Flash Programmer, etc.):

• Do not use the flash programming software products for this product.

Note on the RESET:

• After resetting, It occurs the break of hundreds msec for internal debugger process

Note on the data retention lower limit supply voltage:

• Minimum value of the data retention lower limit supply voltage differs from target devises. The data retention lower limit supply voltage of this product is 1.8V(typ.) / 2.0V(max.).

Note on the A/D Converter:

• The characteristic of the A/D converter differs from target devices because there are some analog selectors and other devices between the MCU and the user system.



Appendix Compliance Sheet

CAUTION

This is a Test- and Measurement equipment with possibility to be significantly altered by user through hardware enhancements/modifications and/or test or application software. Thus, with respect to Council Directive 2004/108/EC (Directive on compliance with the EMC protection requirements), this equipment has no autonomous function. Consequently this equipment is not marked by the CE-symbol.

EEDT-ST-005-20

CAUTION

This equipment should be handled like a CMOS semiconductor device. The user must take all precautions to avoid build-up of static electricity while working with this equipment. All test and measurement tool including the workbench must be grounded. The user/operator must be grounded using the wrist strap. The connectors and/or device pins should not be touched with bare hands.

EEDT-ST-004-10



For customers in the European Union only

The WEEE (Waste Electrical and Electronic Equipment) regulations put responsibilities on producers for the collection and recycling or disposal of electrical and electronic waste. Return of WEEE under these regulations is applicable in the European Union only. This equipment (including all accessories) is not intended for household use. After use the equipment cannot be disposed of as household waste, and the WEEE must be treated, recycled and disposed of in an environmentally sound manner. Renesas Electronics Europe GmbH can take back end of life equipment, register for this service at http://www.renesas.eu/weee

Device files and sample code download(*1)

For target boards the device files and ready-to-use sample Application(s) are available for download from the Renesas TOOLWEB,www.renesas.eu/update.

Please mark "Target-Board/Adapter" as tool type and then Select your target board from the list of products.

*1: Applicable in the European Union Only.



Notice

- Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
- Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
- 3. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or
- technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
- 4. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics product.
- Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

*Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; and safety equipment etc.

Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (nuclear reactor control systems, military equipment etc.). You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application for which it is not intended. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.

- 6. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- 7. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or systems manufactured by vou.
- 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 9. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You should not use Renesas Electronics products or technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. When exporting the Renesas Electronics products or technology described in this document, you should comply with the applicable export control laws and regulations.
- It is the responsibility of the buyer or distributor of Renesas Electronics products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the contents and conditions set forth in this document, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties as a result of unauthorized use of Renesas Electronics products.
- 11. This document may not be reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



SALES OFFICES

Refer to "http://www.renesas.com/" for the latest and detailed information

Renesas Electronics Corporation

http://www.renesas.com

Renesas Electronics America Inc.

2880 Scott Boulevard Santa Clara, CA 95050-2554, U.S.A.

Tel: +1-408-588-000, Fax: +1-408-588-6130

Renesas Electronics Canada Limited

101 Nicholson Road, Newmarkst, Ontario L3Y 9C3, Canada

Tel: +1-905-9898-5441, Fax: +1-905-898-3220

Renesas Electronics Europe Limited

Dukes Meadow, Millocard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K

Tel: +49-211-65030, Fax: +44-1628-651-804

Renesas Electronics Europe GmbH

Arcadiastrasse 10, 40472 Düsseldorf, Germany

Tel: +92-211-65030, Fax: +449-211-6503-1327

Renesas Electronics (Shanghal) Co., Ltd.

7th Floor, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100083, P.R.China

Tel: +86-21-657-1518, Fax: +86-21-08235-7679

Renesas Electronics (Shanghal) Co., Ltd.

Unit 204, 205, AZIA Center, No.1233 Lujiazu Ring Rd., Pudong District, Shanghai 200120, China

Tel: +86-27-8587-7858 / -7889

Renesas Electronics Taiwan Co., Ltd.

Unit 1001-1613, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong

Tel: +85-2886-9318, Fax: +852 2886-9022/9044

Renesas Electronics Taiwan Co., Ltd.

137, No. 33, Fu Shing North Road, Taipei, Taiwan

Tel: +85-24175-9900, Fax: +8862 24175-9907

Renesa