

# UV Measurement For Formulators



Paul Mills  
EIT Instrument Markets  
*[pmillsoh@aol.com](mailto:pmillsoh@aol.com)*

***Anything that you can measure, you have a better chance of controlling. Things that you do not measure become the cause of mysterious problems***

- Larry Goldberg, Beta Industries

***Not everything that counts can be counted, and not everything that can be counted counts.***

- Albert Einstein

# EIT Facilities

---



# EIT Facilities

---





# UV Measurement Needs

## End-Users

- Is the process running consistently?
- Is the process running within the spec?
- Troubleshooting
- Record keeping/Traceability
  
- Tend to be *relative* measurements.

## Formulators/Suppliers

- Establish a specification
- Determine a process window
- Optimize a process
- Help customers troubleshoot
  
- Tend to be *absolute* measurements.

# UV Measurement Needs

## End-Users

- Is the process running consistently?
- Is the process running within the specification?
- Troubleshooting
- Record keeping/Traceability
- Tend to be *relative* measurements.


## Formulators/Suppliers

- Establish a specification
- Determine a process
- Optimize a process
- Help customers troubleshoot
- Tend to be *absolute* measurements.

Communication

# Powder Cure Requirements

Manufacturer's Recommended Specifications







# Content

- Principles of UV Measurement
- What to measure
- How to measure
- Role of UV Sources
- Specification details
- Instrument/User error
- Instrument selection





## **Practical Advice or Numerical Examples**



Wavelength

Peak Irradiance



Energy Density

## Terms / Units

Wavelength = Nanometers  
("light")

Peak Irradiance = Watts / cm<sup>2</sup>  
("intensity") ("watts")

Energy Density = Joules / cm<sup>2</sup>  
("dose") ("joules")




**Wavelength**

Peak Irradiance

Energy Density



Example lamp output power 10 kW



Ultra-violet radiation:

25 - 30%

2.5 - 3.0 kW

Visible light radiation:

5 - 10%

0.5 - 1.0 kW

Infra-red radiation:


60 - 65%

6 - 6.5 kW




$\lambda$  = Wavelength

For UV Curing  $\sim$  **200 nm** through  $\sim$  **400 nm**







## ULTRAVIOLET SPECTRUM




- **UVA**: 320-390nm Long-wave, black light, UV Inks,
- **UVB**: 280-320nm Middle-wave, erythematous response, medical applications – helps provide durability.
- **UVC**: 200-280nm Short-wave, germicidal (254 nm), absorbed by DNA, clear coats, surface cure, tack, chemical or scratch resistance
- **UVV**: 395-445nm Ultra Long-wave, wood products, opaques/whites, thick coats, adhesion, depth of cure
- **VUV** (Vacuum UV): 100-200 nm, Ozone < 200 nm









# UV Relative Penetration





Wavelength

**Peak Irradiance**


Energy Density


# UV Lamp “Power” Designations

Describing a lamp is not the same as describing it's output.



A 600 watt/inch lamp does not produce 600 watts/inch it consumes it.

This is a measure of power applied **to** the “bulb” (the actual power consumption may be much higher still!)







surface area =  $4\pi r^2$









Wavelength

Peak Irradiance

**Energy Density**




# Energy Density $\leftrightarrow$ Irradiance

- Irradiance does not change with time.
- However both time and irradiance affect energy density
- Time can be the length of time a fixed object is exposed to a part, the time exposure of a moving part (e.g. a conveyORIZED part), or a moving lamp.

# Powder Cure Requirements

Manufacturer's Recommended Specifications



# Poor Specifications

- Nordson Gallium Lamp
- “5 Seconds under Mercury Lamp”
- “5 Seconds under a 600W/inch lamp”
- “5 Seconds under a Fusion H lamp”
- “Expose to Mercury Lamp at 10 fpm”

## Not much better

- Mercury Lamp – 5 Joules
- Fusion D lamp – 3 Watts
- American Ultraviolet Hg Lamp – 3”

# Getting Better

- Fusion V Lamp – 1200 mW/cm<sup>2</sup> / 2100 mJ/cm<sup>2</sup>

# Good Specification

- Nordson Iron Additive Lamp, UVA = 1100 mw/cm<sup>2</sup>, 2100 mJ/cm<sup>2</sup>



# Proper Specification

- Fusion V lamp, 600W/in @ 100%

Band	Irradiance (mw/cm2)	Energy Density (mJ/cm2)
UVA	1100	2100
UVB	1500	2600
UVC	360	450

- Measured with EIT PowerPuck II @ 2.5" from lamp face.

## A Reasonable UV Cure Specification:

- 1.The peak irradiance at relevant wavelengths
- 2.The energy density requirement at the same wavelengths
- 3.The instrument to be used for this measurement
- 4.The type of lamp (e.g. mercury, iron additive)

Relevant ?

- 1.Line speed
- 2.Distance from the lamp
- 3.Lamp manufacturer
- 4.Reflector type
- 5.Temperature
- 6.Material thickness



# Sample Specification

- Coating thickness 1.0 to 1.5 mils
- Cured with a mercury lamp
- UV Readings EIT PowerPuck II


	Irradiance	Energy Density
UVA	2259 mw/cm <sup>2</sup>	2908 mJ/cm <sup>2</sup>
UVB	506 mw/cm <sup>2</sup>	696 mJ/cm <sup>2</sup>
UVC	57 mw/cm <sup>2</sup>	75 mJ/cm <sup>2</sup>
UVV	969 mw/cm <sup>2</sup>	1275 mJ/cm <sup>2</sup>



	J/CM2	W/CM2
UVA	2,908	2,259
UVB	0,696	0,506
UVC	0,075	0,057
UVV	1,275	0,969
-	-	-
RUN		




**Bulb Type & Focus Reminder**



# Powder Cure Requirements


Manufacturer's Recommended Specifications





# Optimization

- Minimum irradiance
  - Lower lamp power
  - Increase distance
- Minimum energy density
  - Less time
  - Faster line speed
- Find point of failure?










Temperature


Time



Wavelength

Energy

Time



There is a non-linear benefit to increased peak irradiance on overall curing for many UV chemistries.

# High Peak Irradiance Automotive Lighting Comparison


## Low Peak Irradiance

- 10 x 600 W/in lamps
- 6-8 total Joules UV


## High Peak Irradiance



- 1 robot 600W lamp
- 2.5 total Joules UV

**Coating: Red Spot UVT-200**



# Sources of Measurement Error







**Wavelength**

Peak Irradiance

Energy Density


# Single Broadband Instrument









# Optics Designs




**Note the location of the sensor versus the location of the part.**




# Multiple Band Instrument



# UVA-Spectral Bandwidth Comparisons




# UV Bandwidths-UVA, UVB, UVC, UVV








UV Lamp Output Data



# UV Bandwidths - UVA2






Wavelength

**Peak Irradiance**

Energy Density



$$E_{\theta} = E \times \text{Cos}\theta$$




Cosine Error in Measurement

$$E_{\theta} = E \times \text{Cos}\theta$$


45° = .7 Watt

90° = 1.0 Watt




Cosine Error in Measurement


# Cosine Response Error




# Spatial Response of Instruments Goal: Cosine Response



# Optics Designs






Solarization of Optics affects absolute measurement and requires maintenance

# Radiometer Variations-Temperature



- Unknowingly introduce variations to readings based on the internal temperature of the unit
- As detector temperature raises, readings may drop
- Try to maintain consistent conditions and avoid rapid, repeated, long duration high intensity runs
- Typical detector variation: -0.2% per °C
- If it's too hot to touch – it's too hot to measure
- Internal temperature alarms (65 ° C)



Wavelength

Peak Irradiance

**Energy Density**




# When is a Joule not a Joule?

- Bandwidths are not defined and vary from manufacturer to manufacturer
  - EIT      UVA    320-390 nm, CWL 365 nm (narrow)
  - IL        UVA    250-415 nm, CWL 365 nm (broad)


ANYthing that affects IRRADIANCE affects energy density.

Filters, cosine angle, solarization, etc.


But there are some factors that do not affect irradiance and do affect energy density.




# Equal Joules $\neq$ Equal Cure





Low Sampling Rate = Less accurate for both Peak and Energy Density






What works well at one line speed...

Sample 2 Hz





May not work well at another.

Sample 2 Hz




The sampling rate must be appropriate for the process. Typical rates can vary From 25 to 30,000 samples/second

Sample 6 Hz






# Pulsed Xenon Source



# Pulsed Lamp Source - 4 Pulses




X-Axis  
Milli  
second  
s

Sequence of Four Flash Tube Output Pulses


# UV Power Puck<sup>®</sup> FLASH

- Modified electronics for pulsed sources
- Power Puck Flash-four UV Bandwidths
- Electronics designed for pulses between 100-120 times/second
- Provides energy density values
- User selectable parameters
- User changeable batteries





# Radiometer Variations-Threshold




# Radiometer Variations-Threshold

- Start threshold: Irradiance level which causes the unit to start measuring UV
  - Counts all UV past that point
  - Varies due to scale, electronic response, optics, design
- Data threshold: Software allows user to discard all readings below a set range
- Challenge: Long slow runs of low irradiance
  - Potential for wide variation in energy density-Joules

# **Some Practical Examples of UV Measurement Related Issues**


# Radiometer Variations - Sample Rate



Speed: 33 fpm/10 mpm

Total Time under UV reflector:  
0.83 seconds

Time under Peak irradiance: 0.30  
seconds



Inst. Sample  
Rate (#/sec)


Samples

25	20
40	33
128	106
256	212
1024	850
2048	1700






# Radiometer Variations - Sample Rate



Speed: 240 fpm/74 mpm

Total Time under UV reflector:  
0.18 seconds

Time under Peak irradiance: 0.08 seconds




<u>Inst.Sample Rate (#/sec)</u>	<u>Samples</u>
25	4
40	7
128	23
256	46
1024	184
2048	368




## Dwell Time or Belt/Line Speed

- Affects the amount of energy reaching the substrate
- Actual speeds may vary widely from settings on the speed controller and may not be linear ( $\pm 25\%$ )
- Independently test and confirm dwell time or belt/line speed




Effects of varying the process speed from 4 fpm (blue) to 10 (black) fpm






## Across the bulb-middle to end comparison (Inadequate Cooling/Air flow)




Sagging-15 % difference in irradiance levels middle to end

Data collected with EIT PowerMAP






# Focused lamp





Time in seconds



Parabolic Reflector




Elliptical Reflector




Parabolic vs. Elliptical reflectors








# Parabolic Lamp



Not always bad-gloss control on wood for example




- Readings on a two lamp system
  - Energy Density: 953 mJ/cm<sup>2</sup> (UVA EIT 320-390)
  - Irradiance: 313 mW/cm<sup>2</sup> (UVA EIT 320-390)
- After: Readings on the same system
  - Energy Density: 1203 mJ/cm<sup>2</sup> (UVA EIT 320-390) + 26%
  - Irradiance: 449 mW/cm<sup>2</sup> (UVA EIT 320-390) + 43%
- Only one thing done Reflectors were cleaned



**One little thing can have a big impact in the amount of UV reaching the cure surface**




With 600 hours of run time would you change this bulb?



**UVA Energy Density: 537 to 487 mJ/cm<sup>2</sup>**  
**UVA Irradiance: 309 to 290 mW/cm<sup>2</sup>**



# Change Now?




**UVV Energy Density: 737 to 1331 mJ/cm<sup>2</sup>**  
**UVV Irradiance: 397 to 734 mW/cm<sup>2</sup>**



# Radiometer Variations & Limitations

- Users expect the same accuracy as other instruments - current radiometer technology  $\pm 10\%$
- Why can't radiometers do better than  $\pm 10\%$ ?
- Optics
  - Filter and detector specifications
  - Spatial response
  - Design
    - Balance between optical stability (minimal solarization) and repeatable electronic signal level
- Electronics
  - Temperature sensitivity
  - Sample rates/Data Collection Speeds
  - Improvements in electronics since early EIT instruments
- Calibration Methodology
- User Induced Errors and Comparisons (Real vs. Perceived)
  - Comparison to other products within EIT family and from other manufacturers

# Radiometer Variations-Optics/Filters



- Normal to expect small variations between filters
- Tradeoff is \$ vs. performance
- EIT is careful to test each filter to avoid wide variations
- Select & test the optics for better performance and unit to unit comparisons

# Why Calibrate?

- Balance the amount of IR, Visible and UV the optics and detector “see” with the output signal from the detector
- Compensate for changes in the optics over time
  - Solarization
- Instruments used in harsh production & manufacturing environments
  - Irradiance levels:
    - Sunlight: +/- 20 mW/cm<sup>2</sup>
    - Production UV levels: 100’s to 1000’s mW/cm<sup>2</sup>
  - Physical damage to instrument
    - Drop, crush instrument, scratch optics
  - Optics/instrument coated with ?
- Electronics checkup
  - Physical and/or heat related damage



# Instrument Selection


---

- **Right Instrument/Product**
  - Continuous, storage or mapping,
- **Right Dynamic Range**
  - Exposure vs. curing
  - But I get readings.....
- **Right Application**
  - Size, Flat or 3D, etc.
- **Right Source**
  - Traditional
  - Flash
  - LED
- **Right Expectations**



# Radiometer Types

- Continuous Reading



- Logging





- Profiling




- Multiple sensors - e.g. 3D Cure




# Relative Instrument Examples






# Process Sensors

Examples of Compact Sensors used with either spotcure light guides (left) or quartz pick-up rod (below)



# Modern Logging Radiometer




# High Speed Loggers for Xenon Lamps

- Modified electronics for pulsed sources
- Electronics designed for pulses between 100-120 times/second
- Provides energy density values
- User adjustable parameters
- User changeable batteries



# Profiling Radiometer



File

View

Tools

Help

Sample Reference

UVA

REFA

OFF

OFF

OFF


OFF


UVV

REFV

OFF

OFF







**Data View**

**PowerView by EIT** **Data View**

File View Tools Help

<b>Total Energy Density (cm2)</b>		Sample	Reference	Diff.	% Diff.
UVA	mJ	152.78	134.28	18.500	13.8
UVB	mJ	125.71	108.94	16.763	15.4
UVC	mJ	13.435	12.487	0.948	7.6
UVV	mJ	95.687	88.735	6.952	7.8

<b>Average Temp</b>		Sample	Reference	Diff.
TEMP	C	34	28	6

<b>Peak Power Density (cm2)</b>		Sample	Reference	Diff.	% Diff.
UVA	mW	692.43	641.53	50.896	7.9
UVB	mW	586.43	531.28	55.149	10.4
UVC	mW	60.706	58.688	2.017	3.4
UVV	mW	416.07	416.04	0.037	0.0

<b>Peak Temp</b>		Sample	Reference	Diff.
TEMP	C	39	33	6



SMOOTH ON      CURSORS OFF      REF (sec) 0.000      SMPL(sec) 0.000      THRESHOLD OFF      Threshold (mW) 10.00



Sample:	Reference:
<b>D:\PowerView\Data-UVSE tests\uvse</b> Collection Unit: Power Map, Rev 1.02/1.00, s/h #19981004 Optics Unit: Power Map, Rev 1.00, s/h #19981015,A/B/C/V Data Config:2048 HZ, A/B/C/V Start: 17JAN 00 19:20:54, 33C, 2.6V  nicollet, mercury, 80 fpm, 307 WPI PP UVA 131 mj, 528 mw, UVB 118 mj, 577 mw, UVC 14 mj, 66 mw, UVV 65 mj, 301 mw	<b>D:\PowerView\Data-UVSE tests\uvse</b> Collection Unit: Power Map, Rev 1.02/1.00, s/h #19981004 Optics Unit: Power Map, Rev 1.00, s/h #19981015,A/B/C/V Data Config:2048 HZ, A/B/C/V Start: 17JAN 00 12:06:35, 25C, 2.7V  UVSE HG, 82 FPM, 307 WPI, PP UVA 124 mj, 555 mw, UVB 109 mj, 496 mw, UVC 14 mj, 68 mw, UVV, 68 mj, 124 mw

# 3DCURE™ A Multi-Dimensional Measurement System For UV Curing Applications



# 3DCure System Examples





974

972

978

Sensor on end.  
977

980

Sensor on end.  
970

975

976

# 3DCure Data Screen (Cure3D)

**EIT**  
Instrument  
Markets

3DCure Multi-Dimensional  
Radiometer Measurement System

CURE 3D DATA SCREEN

Get Data Save Text File Setup Exit

UNIT S/N	UNIT TYPE	PEAK IRRADIANCE (mW/cm <sup>2</sup> )	ENERGY DENSITY (mJ/cm <sup>2</sup> )	LED
SN:1000	UVA-S	731.5	485.3	●
SN:1001	UVA-S	522.4	340.1	●
SN:1002	UVA-S	536.3	374.8	●
SN:1003	UVA-S	587.2	300.5	●
SN:1004	UVA-S	958.6	1338.5	●
SN:1005	UVA-S	523.3	334.7	●
SN:1007	UVA-S	474.4	806.8	●
SN:1009	UVA-S	691.2	1235.6	●

3D Cure Software (Above)

ActiveX Custom Control Example (Right)

Microsoft Excel - RF\_Part1\_Trial

ENERGY

POWER

Microsoft Excel - RF\_Part1\_Trial

Reset Get Data

SN	ENERGY (mJ)	PEAK POWER (mWPOWER (mW))
1 000	3153.195	429.977
2 000	4261.512	694.757
3 000	3714.950	556.674
4 000	2747.921	370.346
5 000	6727.644	805.715
6 000	4291.024	562.300
7 000	3304.947	294.244
8 000	5138.938	383.795
9 000	4286.088	644.205
10 000		
11 10 000		



# Summary

- A good specification contains information about lamp type, irradiance and energy density (dose) measurements on a specified and appropriate instrument.
- Wavelength is affected by optics, and band-pass filtering
- Irradiance is affected by source intensity, distance (inverse square), temperature and reflector optics (e.g. solarization)
- Energy Density is affected by irradiance as well as sampling rate, and threshold.

# Summary

- Edge effects, sagging, poor cooling, reflector design and condition, focus, etc. effect results.
- Calibrate! Instrument variation of +/- 10% is a practical, and unavoidable condition but time and solarization affect accuracy.
- Instrument selection depends on dynamic range, sampling rate, sensitivity, cost, size, etc. as well as many practical issues – the lab should replicate what happens in the field. A common instrument eases comparison.



# Acknowledgements

- *Fusion UV, UV Robotics, Phoseon Technology, Doug DeLong – DDU, and Xenon Corp.*
- *Colleagues at EIT; Jim Raymont and Sue Casacia*

# Thank You !

## UV Measurement For Formulators



**EIT Instrument Markets**  
**108 Carpenter Drive**  
**Sterling, VA 20164 USA**  
**Phone:703-478-0700**  
**uv@eitinc.com**  
**Web: eitinc.com**

Paul Mills  
EIT Instrument Markets  
*pmillsoh@aol.com*