# **Test Floor Management Software**

# Automated Correlation Wafer Management and Processing

White Paper

Jeffrey C. Quinton DELPHI ELECTRONICS & SAFETY

F. B. Lynch III & Steve Sato ELECTROGLAS, INC.

#### Who is Delphi?

- Delphi is a world leader in mobile electronics and transportation components and systems technology
- Multi-national Delphi
  - Conducts its business operations through various subsidiaries and has headquarters in Troy, Mich., USA, Paris, Tokyo and São Paulo, Brazil.
- Delphi's two business sectors
  - Dynamics, Propulsion, Thermal, and Interior Sector
  - Electrical, Electronics, and Safety Sector
- Delphi has approximately 185,000 employees and operates 171 wholly owned manufacturing sites,
  - 42 joint ventures, 53 customer centers and sales offices and
  - 33 technical centers in 40 countries.



Delphi Electronics and Safety Delphi Microelectronics Center



Key Semiconductor Technologies

#### Dept 8436 - Wafer Test, Saw and Sort

- 150 Products
  - CMOS, Bipolar, Smart Power, IGBT, Micro Machine, and Sensors
  - Flip Chip and Pad Devices
- 87 Test Cells
  - Teradyne A5xx, A3xx, J9xx, J750, Eagle 300 Sentry SZ M3020 - LTX 77, CP80, Synchro HT, Fusion HT, HF, CX
  - EG2001, EG4090 and TEL P8XL, WDF, WDP Probers
  - Offline Ink
- Test 1,000,000 Die Per Day
  - 3 Shifts, 5 Days/Week Operation
- Automatic Visual Inspect, Saw, and Sort
- Packaging and Final Test DIP, QUAD PAK, SOIC, BGA...

#### Current Correlation Wafer Process

- Typical Correlation wafer uses:
  - Prior to Device / Product or hardware changeovers
  - After Corrective or Preventive Maintenance
  - Verify / validate test cell integrity anytime yield or test results are in question

- Current practice is to run an entire wafer to verify the test system setup based on the repeated yield of the correlation wafer.
  - Performed manually by an operator with simple pass/fail criteria.
    We use the good count +/-5% to determine a min and max number of good die.
  - The correlation wafer passes if the number of good die on subsequent runs falls within the min and max values.
  - This process is simple for the operator but it does not systematically indicate if the test system is performing optimally.

### **Current Correlation Process Concerns**

- Correlation result integrity
  - What if we get more good die than the max number?
  - Are we now calling bad die good?
  - What does it mean if we get less good die than the min?
- Correlation wafer integrity and lifespan
  - A correlation wafer can be run 5, 10, 20 times before it is "worn out" or scraped
  - Often, one cannot tell if a failure is due to some part of the test system or due to the correlation wafer integrity
- Throughput cost
  - Test times range between 15 min and 3.5 hours per wafer
    - 600 to 10,000 die per wafer
- Correlation wafer cost
  - Typically correlation wafers are scraped which impacts revenue

#### How Can The Process Be Improved?

- Implement automate statistical correlation wafer result analysis to improve correlation integrity
  - Rule based bin analysis
  - Good die remain good and bad die remain bad
- Enhance correlation wafer integrity and lifespan
  - Control the number of die tested with each correlation run
  - Control the number of touchdowns per die
- Reduce Cost
  - Improve throughput
    - Not necessary to probe the entire correlation wafer for a valid assessment of the test cell setup
    - Reduce test time used in correlation process


- Reduce Correlation Wafer Cost
  - Extend the life of correlation wafers
  - Controlled use of the wafers enables them to be sold as product for revenue

#### What is Correlation Wafer Manager (CWM)

- CWM uses automated map management and rule based SPC to automate the correlation wafer process and provides substantial cost savings with increased production throughput
- CWM Features:
  - Identifies correlation wafer(s) from previously probed production wafers in the automated map manager
  - Manages correlation wafer usage
  - Creates correlation follow maps for the prober enabling the testing of a subset of the die on the correlation wafer
  - Analyzes the correlation results based on rules created for each product, or default rules
  - Messages the prober with correlation results
  - Provides simple solution for production with automated analysis and sends the prober a message indicating passage or failure, with failure details

#### How CWM Functions

- The Core Technology
  - Web-based
  - Automated map manager
  - Two-way prober communication
  - Statistical and graphical reporting engine provides SPC
- CWM Setup
  - Correlation wafer is selected
  - Correlation rules setup
  - Product recipe created for prober



Automated Map Manager Integration

### How Many Die To Test?

• There are many variables in determining the correlation sample size. We assumed around 90% yield for the device and that Alpha would be 0.1 (90% confidence) and Beta would be 0.2 (risk of missing something significant). Based on that we looked at the comparison of two proportions and got the following:

1% shift	1,000 die
2% shift	275 die
3% shift	125 die
4% shift	75 die
5% shift	50 die
<b>5% shift</b> 6% shift	<b>50 die</b> 40 die
• • • • • • • • • • • • • • • • • • • •	
6% shift	40 die

• The actual number is going to vary based on the individual device maturity and yield trend. Based on this testing 50 die will find a 5% shift while it will take over 100 to find a 3% shift. Looking for 1-2% shifts impacts the cost effectiveness and best utilized with immature devices.


# Correlation Rules Setup

				PS478 CO	RR.txt	Continue
lf Bin		Bin Gro	The second second second			Back to Limits Lis
this bi	in/bingroup	to test	"Min % Match	h" is the minimum allow	ved % of die of this bin	remaining this bin. "Max %
Trans	ition" is the	maxim Bin		of die not of this bin to Min # To Test	o change to this bin. Min % Match	Max % Transition
Trans <u>Edit</u>	ition" is the <u>Delete</u>		um allowed %	The second s		Max % Transition
			um allowed % Bin Group	Min # To Test	Min % Match	
<u>Edit</u>	Delete	Bin 1	um allowed % Bin Group *	Min # To Test	Min % Match 90	
<u>Edit</u> Edit	Delete Delete	<b>Bin</b> 1 2	um allowed % Bin Group * *	Min # To Test 25 0	Min % Match 90 0	


Web Interface for CWM Rule Setup

# CWM Map Examples

- Initial correlation wafer
- (4) Individual correlation regions of the wafer used for correlation



## CWM Prober Message Example = Fail



The Correlation "Failed" the Bin 1 Transition Rule

#### Benefits

- Correlation Analysis Integrity
  - Implement automate statistical correlation wafer result analysis to improve correlation integrity
    - Rule based bin analysis
    - Good die remain good and bad die remain bad.
    - Removed operator analysis portion (pass/fail) (subjective), making it a statistical rule based decision made by CWM
    - CWM is integrated one device at a time with the flexibility to easily change number of die to test, number of times to probe a wafer section and pass/fail criteria.
- Correlation Wafer Management
  - CWM provides a record of correlation wafer inventory and usage
- Enhanced correlation wafer integrity and lifespan
  - Control the number of die tested with each correlation run
  - Control the number of touchdowns per die
- Reduced Cost
  - Improve throughput
  - Extend the life of correlation wafers