

DataChart 1250 Overview

The DC1250 is a feature rich digital recording system offering 2 universally configurable isolated inputs for measuring DC voltage, DC current, thermocouples, RTD's as well as frequency and pulse inputs. 4 internal alarm setpoints, 2 alarm relay outputs and 1 digital control input are all standard. Combining small package size with extreme flexibility make the DataChart 1250 a powerful, yet economical, digital data recording system.

A maximum sample storage rate of 100 samples per second can be set for both channels allowing for capture of short duration process signals anomalies. CompactFlash cards up to 2 Gigabyte size can be used allowing many data points to be stored over long periods of time.

With intuitive operation, flexible input configuration and large memory capability, the DataChart 1250 is a powerful, compact digital recorder.

DataChart 1250 Features

Communicate

A front accessible USB port is available. It provides access to data stored on the CompactFlash $^{\text{TM}}$ card. Simply connect your laptop to the DC1250 using the supplied USB cable to extract your data or collect real-time information.

Bright and Clear Display

The DC1250 has a highly reflective twisted nematic LCD display with a bright white LED backlight. The graphic user interface can be configured to display real time data in digital or trend format. Configuring the 1250 is an intuitive process which uses an easy to follow menu system.

Versatile Power

The DC1250 is supplied with a universal wall transformer power supply (North American plug) that can operate from 100 to 240Vac 50/60Hz. An optional transformer with an interchangeable plug set is available.

An isolated input power of 12-24Vdc is also available for use with instrument power supplies or external batteries.

The DC1250's real time clock and internal RAM have a battery back-up to preserve data in the event of a power loss.

If losing data during a power outage is a concern, the user can add the rechargeable battery pack option. With the battery pack option installed, the DC1250 automatically keeps the rechargeable NiMH batteries charged to capacity. In the event of a power loss, the DC1250 automatically switches over to internal battery power. All functions continue to operate as normal for up to 8 hours! This option is also great for using the DC1250 in areas where no AC or DC power is available.


Measure RPM

The DC1250 can be used in conjunction with many of Monarch's speed measurement sensors. Power for sensors is provided from the DC1250 rear terminals. Measure, display and record RPM ranges from 5 - 600,000. Choose the sensor best suited for your application or take your existing signal (0 - 5V TTL) directly into the 1250.



DataChart 1250 Paperless Recorder


















MT-190W magnetic sensor

DataChart 1250 Specifications

Input Power:

Standard:

9 Vdc +/- 0.5Vdc @ 5VA (depends

external loads) provided by

external

AC wall transformer (provided),

non-

on

isolated. 100-240Vac 50/60Hz Option:

Isolated 12-24 Vdc input power available (not compatible with internal

battery pack option below).

Internal battery pack provides Option:

uninterrupted operation and con-

trolled

shutdown during blackout. 6Vdc, 2400mAH NiMH - Backup Time; 8

hours typical (depends on external load).

Output:

2 outputs 5Vdc @ 50mA to power external

sensors.

Number of Channels: 2 universal, user selectable.

Isolation: 300V AC/DC channel input to chassis ground

DC Input:

Voltage

Ranges: 0-250mV; 0-1.25V; 0-2.5V; 0-5V;

0-12.5V; 0-25V 0.1% of reading Accuracy: Resolution: 0.025% of full scale

Current

Ranges: 0-20mA; 4-20mA; 0-50mA; 10-50mA

0.1% of reading excluding 250 ohm Accuracy:

external shunt (required).

Resolution: 0.025% of full scale

Thermocouple:

RTD:

Accuracy: 0.3% of full scale (typical). Ambient Temperature Sensor Accuracy: ±1.5°C

Type Range

J -100 to 760°C ±2°C (-148 to 1400°F ±3°) K^1 -100 to 1000°C ±2°C (-148 to 1832°F ±3°) (32 to 2498°F ±3°) K² 0 to 1370°C ±2°C

T -100 to 400°C ±2°C

(-148 to 750°F ±3°)

E -80 to 400°C ±2°C

(-112 to 750°F ±3°)

Accuracy: 0.3% of full scale (typical).

Resolution: 0.1°C

Internal current source: 1mA

Type Range

100 Ohm Pt 385 -100 to 750°C (-148 to 1380°F)

100 Ohm Pt 392 -100 to 750°C (-148 to 1380°F)

2 or 3 wire.

Frequency Input (Hz)/Range: 0 - 10,000 Hz / 0 - 600,000 RPM Speed Input (RPM): Accuracy:

Freq: ±1 Hz; RPM: ±1 RPM below

9,999 RPM; ±10 RPM above 9,999 RPM

Input: Low <1.0Vdc; High >3.0 <12.0Vdc Pulse width: 10 microsecond minimum.

DataChart 1250 Dimensions 5.22 3.62 [132.46] Panel 3.62 3.78 [96.00] [92.00] Cutout 3.78 [96.00] 4.07 [103.38]

Input Impedance: >100k ohms

Measurement Rate: Up to 100 samples/sec per channel.

Math Function: Y = mx + b; average, hi peak, low peak.

Media: Compact Flash to 2 GB.

Display: LCD Graphics, 160 x 80 pixels, black FSTN with

white LED backlight. User controlled backlight

level and contrast adjust (electronic).

Display Modes: Trending (horizontal), Large dual digital

readout, mixed mode.

User Interface: 5 button keypad (dual function buttons).

Clock: Auto leapyear and daylight savings adjustment.

Internal battery back-up.

Relay Output: Two alarm outputs: 30V 0.5A Form A relays

Opto-isolated Input: One input, 5 to 12Vdc activation @ 10mA typical.

Audible: Internal beeper (multiple tones).

Dimensions: Front panel: 96mm x 96mm (1/4 DIN) x 152mm

(3.78 x 3.78 x 6 inches).

Environmental: Indoor Use Only

> Installation Category II per IEC 664 Pollution Degree Level II per IEC61010-1 Temperature: -10°C to 50°C operating per IEC

61010-1

Humidity: maximum relative humidity 80% for temperatures up to 31°C, decreasing linearly to

50% relative humidity at 40°C.

Electrical Safety: Meets EN610610-1:2001, EC low voltage directive

72/23/EEC and 93/68/EEC. Power supply certified

UL, cUL.

Optional USB: Front panel USB 2.0 slave port for data and

remote real-time display when using Navigator

software


Ethernet: Real time data display, historic data transfer, remote control and recorder configuration when using Navigator Software. Built in web server


displays current measured values.



Rear Panel

DataChart Navigator Software





DataChart Navigator software makes reviewing, printing and exporting data easier than ever. Simply start the program, double click the data file and Navigator does the rest. Your data file is displayed in one graphic window complete with the scales as programmed in the DC1250 as well as Date and time stamps. You can expand, compress or use the box zoom to display specific areas of data as needed. The print preview feature allows review prior to printing.

Exporting data is as simple as clicking the Excel™ Icon in the Data table export window. Navigator automatically converts the historic data, starts up Excel™ and loads your data into an organized spreadsheet.

Minimum system Requirements: PC running Windows® 2000 or XP, 10 MB free disk space and CD ROM Drive.

DataChart 1250 Ordering Information

DC1250 -0 None USB Comms. Mini-USB port for downloading 1 data directly to PC. Front access. Ethernet 10/100BaseT Ethernet, rear access RJ45 connector. Allows network access to recorder. 0 None Rechargeable NiMH battery pack will Battery Backup* operate recorder up to 6 hours in the event of power loss. S Standard AC Adapter 100-240Vac wall adapter with North American Plug U Universal AC Adapter 100-240Vac wall adapter with interchangeable Plug Set D DC Input Power 12-24Vdc input power Isolated

*Not Available with Option "D" DC Input Power.











DataChart 1250 Accessories

Description Model No.

Navigator Windows Compatible Software for

graphic analysis, printing transfer and

exporting

CFCR CompactFlash™ Card Reader USB 2.0

compatible

MAS250R 250 ohm Precision Resistor for current

inputs. 0.1% 0.5 watt

NIST-1250 N.I.S.T. Calibration with data

CompactFlash™ Memory Cards

MC64MBCF 64 Megabyte MC128MBCF 128 Megabyte

MC256MBCF 256 Megabyte MC512MBCF 512 Megabyte MC1024MBCF 1 Gigabyte MC2048MBCF 2 Gigabyte

Sensors (Plug and Play)

THS-W Temp/Humidity Sensor with 8 foot cable ROS-W Remote Optical Sensor with 8 foot cable,

mounting bracket and 12 inches of

reflective tape

MT-190W Magnetic Trigger Sensor/Amplifier with 8

foot cable

IRS-W Infrared Sensor with 8 foot cable, tinned

wires and mounting bracket

All Trademarks remain the exclusive property of their respective owners. Monarch Instrument pursues a policy of continuous product improvement. The specifications in this document may therefore be subject to change without notice. The information provided in this document is intended for guidance only. Monarch Instrument accepts no responsibility for any losses arising from errors or omissions in this document.



15 Columbia Drive Amherst, NH 03031-2334

Tel: (603) 883-3390 Fax: (603) 886-3300 email: sales@monarchinstrument.com Web: www.monarchinstrument.com

MADE IN THE USA

Distributed by: