# Magnetic field sensor for pneumatic cylinders **BIM-QST-Y1X**




-		<ul> <li>ATEX category II 2 G, Ex zone 1</li> <li>ATEX category II 1 D, Ex zone 20</li> <li>SIL2 as per IEC 61508</li> <li>Rectangular, height 12 mm</li> <li>Front active face</li> <li>Plastic, PA12-GF30</li> <li>Magnetic-inductive sensor</li> <li>DC 2-wire, nom. 8.2 VDC</li> <li>Output acc. to DIN EN 60947-5-6 (NMUR)</li> <li>Cable connection</li> </ul>
		 Wiring Diagram
Type code	BIM-QST-Y1X	
Ident no.	1058000	
		BN
Pass speed	≤ 10 m/s	
Repeatability	≥ ± 0.1 mm	
Temperature drift	≤ 0.1 mm	
Hysteresis	≤ 1 mm	
Ambient temperature	-25+70 °C	
		Functional principle
Output function	2-wire, NAMUR	Magnetic field sensors are activated by
Switching frequency	1 kHz	netic fields and are especially suited for
Voltage	Nom. 8.2 VDC	ton position detection in pneumatic cylin
Non-actuated current consumption	≤ 1.2 mA	Based on the fact that magnetic fields c
Actuated current consumption	≥ 2.1 mA	5
		permeate non-magnetizable metals, it is
Approval acc. to	KEMA 02 ATEX 1090X	<ul> <li>sible to detect a permanent magnet atta</li> </ul>
		to the piston through the aluminium wall
Construction	rectangular, QST	— cylinder.
Dimensions	20 x 12 x 12 mm	
Housing material	Plastic, PA12-GF30	
Active area material	Plastic, PA12-GF30	
Connection	cable	
Cable quality	4 mm, Blue, Lif9YYW, PVC, 2m	
Cable cross section	2 x 0.25 mm <sup>2</sup>	
Vibration resistance	55 Hz (1 mm)	
Shock resistance	30 g (11 ms)	
Protection class	IP67	
MTTF	6198 years acc. to SN 29500 (Ed. 99) 40 °C	
Mounting on the following profiles	· · · · ·	
mounting on the following promote		

Switching state

LED yellow

6 (NA-



by magfor pisylinders. s can it is posattached wall of the



Automation

Magnetic field sensor for pneumatic cylinders BIM-QST-Y1X

# Magnetic field sensor for pneumatic cylinders BIM-QST-Y1X



# Accessories

Type code	ldent no.	Description	
KLQ 1-Z KLEMMSTÜCK	6971911	Mounting on 💭 tie-rod cylindes; diameter 3263 mm, mate- rial: Anodized aluminium; please order fixing clamp separate- ly	28 max. 28 max. 17 30 max.
KLQ 2-Z KLEMMSTÜCK	6971912	Mounting on 💭 tie-rod cylindes; diameter 50125 mm, ma- terial: Anodized aluminium; please order fixing clamp sepa- rately	17 38 max.
KLQ 1 KLEMMSTÜCK	6971901	Mounting on 💭 profile cylinders; cylinder diameter 3250 mm, material: Anodized aluminium; please order fixing clamp separately	28 max. 28 max. 17 30 max.
KLQ 2 KLEMMSTÜCK	6971902	Mounting on $\bigcap$ profile cylinders; cylinder diameter 50100 mm, material: Anodized aluminium; please order fixing clamp separately	33 max. 33 max. 17 40 max.
IM1-22EX-R	7541231	Isolating switching amplifier, 2-channel; 2 relay outputs; in- put NAMUR signal; selectable ON/OFF mode for wire-break and short-circuit monitoring; adjustable output mode (NO / NC mode); removable terminal blocks; width 18 mm; univer- sal power supply unit	104

# Magnetic field sensor for pneumatic cylinders BIM-QST-Y1X



#### **Operating manual**

### Intended use

This device fulfills the directive 2014/34/EC and is suited for use in explosion hazardous areas according to EN 60079-0:2012 + A11 and EN 60079-11:2012.

Further it is suited for use in safety-related systems, including SIL2 as per IEC 61508. In order to ensure correct operation to the intended purpose it is required to observe the national regulations and directives.

#### For use in explosion hazardous areas conform to classification

II 2 G and II 1 D (Group II, Category 2 G, electrical equipment for gaseous atmospheres and category 1 D, electrical equipment for dust atmospheres).

## Marking (see device or technical data sheet)

 $\circledast$  II 2 G and Ex ia IIC T6 Gb and  $\circledast$  II 1 D Ex ia IIIC T95 °C Da acc. to EN 60079-0, -11

## Local admissible ambient temperature

-25...+70 °C

## Installation / Commissioning

These devices may only be installed, connected and operated by trained and qualified staff. Qualified staff must have knowledge of protection classes, directives and regulations concerning electrical equipment designed for use in explosion hazardous areas. Please verify that the classification and the marking on the device comply with the actual application conditions.

This device is only suited for connection to approved Exi circuits compliant to EN60079-0 and -11. Please observe the maximum admissible electrical values.

After connection to other circuits the sensor may no longer be used in Exi installations. When interconnected to (associated) electrical equipment, it is required to perform the "Proof of intrinsic safety" (EN60079-14).

When employed in safety systems to IEC 51408 it is required to assess the failure probability (PFD) of the complete circuitry.

#### Installation and mounting instructions

Avoid static charging of cables and plastic devices. Please only clean the device with a damp cloth. Do not install the device in a dust flow and avoid build-up of dust deposits on the device.

If the devices and the cable could be subject to mechanical damage, they must be protected accordingly. They must also be shielded against strong electro-magnetic fields.

The pin configuration and the electrical specifications can be taken from the device marking or the technical data sheet.

#### service / maintenance

Repairs are not possible. The approval expires if the device is repaired or modified by a person other than the manufacturer. The most important data from the approval are listed.