

AMETEK's Elgar SW and California Instruments CSW Form, Fit and Functions Comparison

Introduction

The purpose of this technical note is to compare the differences between the discontinued Elgar SW Series and the **New!** California Instruments CSW. The Elgar SW was a flag ship product for AMETEK Programmable Power and unfortunately has come to the end of its feasible design life due to several obsolete components.

The SW featured high performance power amplifiers offering low Vthd and high frequency output. California Instruments products' lines include some of the most advanced DSP controllers available. The natural path for AMETEK Programmable Power to integrate the best of both worlds!

Front Panel Display and Data Entry

Display

The CSW display features a LED back-light with a very high contrast ratio in comparison to the SW. The CSW allows adjustment of the viewing angle so whether used on a bench or mounted in a cabinet, the display is clear and easy to read.

VOLTA	GE/CURRENT	CONTROL SETUP ABC
	=REG	TRIP DELAY =0.20S
OL MODE	=CC	VOLT REF =INT
BOOST	=OFF	NO. OUTPUT =THREE

Figure 1: Display

Data Entry

Intuitive programming structure. Source programming available via key pad entry or shuttle knob.







Mechanical

The CSW chassis utilizes the same chassis as the SW. Several improvements have been made to the rear panel.

The SW uses rear fuses to as protection against input line faults. The CSW includes an input circuit breaker located on the front panel so no more rear panel fuses are required. The CSW CB also helps to protect against over voltage conditions which the fuses do not.

Another benefit of this improvement is that the CSW is truly disconnected from the utility supply when turned OFF from the front panel.

Input power connections are made using a terminal block instead of the fuses mounted block.



Figure 3: SW Rear Panel



Figure 4: CSW Rear Panel

Power Input

	SW Series		CSW S	eries	
	Std.	Opt.	Std.	Opt.	Comments
Voltage Input	187-264Vrms	187-264Vrms	187-264Vrms		Three phase, three wire
	187-457Vrms	187-457Vrms	187-457Vrms		
Input PF	0.35-0.6	0.99	0.99		CSW PFC Input Standard
Efficiency	70%	70%	70%		
Ride Through	3msec	10msec	10msec		

Table 1



Power Output

	SW S	Series	CSW S	Series	
	Std.	Opt.	Std.	Opt.	Comments
AC/DC Voltage	156/312		156/312		
Range					
DC Offset	NI / A	NI / A	0.11/		
Resolution	N/A	N/A	0.1V		
Frequency	DC / 40-5kHz	DC / 2-8kHz	DC / 40-5kHz	DC / 16-8kHz	-HF Option
Range					
Output	16A to 115V in		16A at 115V in		Constant Power Mode
Current	156V range;		156V range;		
	8.0A to 230V in		8.0A at 230V in		
	312V range		312V range		
Crest Factor	4:1		4:1		
% THD	0.25% 100Hz		0.25% 100Hz		
	.5% 500Hz 1%		.5% 500Hz 1%		
	1kHz + 1% to		1kHz + 1% to		
	5khz		5khz		
AC Noise	>60db rms 40-		>60db rms 40-		Load dependant Variable Fan
	500Hz		500Hz		Speed
Amplitude	±0.1%		±0.1%		
Stability					
Load	0.025% Above		0.025% Above		
Regulation	1kHz add		1kHz add		
	0.015%/kHz		0.015%/kHz		
Line	±0.025% of full		±0.025% of full		
Regulation	scale for a		scale for a		
	±10% input		±10% input		
	line change		line change		
Voltage	0.1% of range.		0.1% of range.		
Accuracy	Above 1Khz		Above 1Khz		
	.2%/Khz		.2%/Khz		
Voltage			Front Panel:		
Resolution			0.1		
	0.050%		voltRemote:		
			0.0025 volts		
			(156 range)		
			0.005 volts		
-			(312 range)		
Frequency	0.01Hz 40-		0.01 HZ: 40.00		
Resolution	99.99HZ		10 81.91HZ		
			U.1HZ: 82.UHZ		
	999.9HZ .5HZ -				
	TKHZ-2KHZ				
			SKHZ		



Frequency Accuracy	0.01%	±0.01% at 25°C ±0.001%/°C	
Phase Angle Accuracy	1° 40-1Khz plus 1%/kHz above 1kHz	±1°, 40Hz to 1kHz, plus ±1°/kHz above 1 kHz.	
Programmable Phase Angle Res.	0.1°	0.1°	

Table 2

<u>Measurements</u>

	SW Serie	S	CSW Se	ries	
	Std.	Opt.	Std.	Opt.	Comments
Voltage L-N	0V to 350.0V		0V to 312V		
	plus sign bit for				
	DC mode				
Accuracy	±0.3% of		±0.1% of range		
	range, DC or		from 5 to 156V		
	47 Hz to 1kHz;		or 10 to 312V		
	±0.5% of		Above 1kHz		
	range, 40 to 47		add 0.2%/kHz		
	Hz and for 1				
	kHz to 5kHz				
Voltage L-L	0V to 700V				
Accuracy	±0.3% of		N/A		
	range, DC or				
	47 Hz to 1 kHz;				
	±0.5% of				
	range, 40 to 47				
	Hz and for				
	1kHz to 5kHz				
RMS Current					
Range 1	0A to 7.5A,				
	plus sign bit for				
	DC mode; 3-				
	phase mode,				
	312V range				



Range 2 Range 3 Range 4	OA to 15A, plus sign bit for DC mode; 3-phase mode, 156V range OA to 22.5A, plus sign bit for DC mode; parallel mode, 312V range OA to 45A, plus sign bit for DC mode; parallel	±1% of range add ±1.5%/kHz above 500 Hz Ranges: 0.5 to 16A: 156V range 0.5 to 8A: 312V range Multiply by 3	
	mode 156V	for 1 where	
	11002, 1500	for 1-phase	
	range	mode	
Accuracy	±1.0% of range, DC or 40 Hz to 500 Hz; add ±1.5%/kHz above 500 Hz. Accuracies are specified for a maximum crest factor of 4.0		
Resolution		0.001A	
Peak Current			
Bongo 1	04 to 284, 2		
Kange 1	phase mode, 312V range	+E% of range	
Range 2	0A to 56A; 3-	40 to 500Hz;	
	phase mode,	add ±1%/kHz	
	156V range	500Hz to 5kHz	
Range 3	OA to 84A; parallel mode, 312V range	Ranges: 0 to 56A; 156V	
Range 4	OA to 168A; parallel mode, 156V range	312V range Multiply by 3	
Accuracy	±5% of range, 40 to 500 Hz; add ±1%/kHz, 500 to 5kHz	for 1-phase mode	
Resolution	XXXX	0.01A	



	1		1
Power			
Range 1	0 kW to 1.8		
	kW; 3-phase		
	mode		
Range 2	0 kW to 5.6		
C C	kW; parallel	±2.5% 01	
	mode and total	range, DC or	
	3-phase power	40 to 500. Add	
Δςςμείον	+2 5% of	±1%/kHz	
Accuracy		above 500 Hz.	
	40 to 500 Hz	Ranges:	
	for crost	1.8kW; 3-	
	for crest $r_{2,0}$	phase mode	
	$Add \pm 1\%$ for	5.6kW: 1-	
	Add 11% IOI	phase mode	
		P	
	up to 4.0. Add		
	±1%/KHZ		
	above 500 Hz		
Resolution	1W	1W	
VA			
Range 1	0 kW to 1.8		
	kVA; 3-phase		
	mode		
Range 2	0 kW to 5.6	+2 5% of	
	kVA; parallel	range DC or	
	mode and total		
	3-phase power	+1%/bH7	
Accuracy	±2.5% of		
-	range, DC or		
	40 to 500 Hz	Ranges:	
	for crest	1.8kVA; 3-	
	factors <2.0.	phase mode	
	Add +1% for	5.6kVA; 1-	
	crest factors	phase mode	
	up to 4.0 Add		
	+1%/kHz		
	above 500 Hz		
Resolution		1W	
Power Factor	1		
Range		0.00-1.0	
		1 Phase Mode	
Accuracy		0.02% 2 Phase	
		0.03%, 3 Flase	
Frequency			
Baselution		0.01 Hz to	
Resolution			
		81.91HZ	
1		U.1HZ (0	



		819.1Hz	
		1Hz > 819.1Hz	
Accuracy		0.01Hz to	
		81.91Hz	
		0.1 Hz to	
		819.1Hz	
		1Hz > 819,1Hz	
Phase Angle			
Resolution	±1° (for	0. 1°	
	outputs above		
	20 VRMS)		
Accuracy	±2°, 40 to 500		
	Hz; add		
	±2°/kHz above		
	500 Hz.	±2°, 40 to	
	For sine wave,	500Hz, add	
	balanced	±2°/kHz above	
	resistive load,	500Hz. (0 to	
	10% to 100%	45°C)	
	of voltage		
	measurement		
	range		
Crest Factor	N/A		
Range		1.0-10	
Accuracy		1.5%	
Resolution		0.01	

Table 4

Remote Programming

SW Series	CSW Series
GPIB - Conforms to all specifications for devices as defined in IEEE 488.2, and complies with SCPI command syntax version 1995	GPIB - All AC source functions are programmable over the GPIB interface. ANSI/IEEE Std. 488.2-1987 IEEE Standard Codes, Formats, Protocols, and Common Commands.
	USB - All AC source functions are programmable over the USB interface. The USB interface operates internally at a fixed baudrate of 460800 baud but USB 2.0 burst transfer rates are supported.
	RS232- All AC source functions are programmable over the RS232C interface. Baudrates from 9600 to 115200 are supported.
	LAN - All AC source functions are programmable over the



LAN (Ethernet) interface if the –LAN option is installed. The LAN interface operates internally at a fixed baudrate of 460800 baud but autodetection of 10Base-T, 100Base-T and 1000Base-T is supported.

Graphical Users Interface (control software suite)

The CSW features a new Graphical Users Interface (GUI) based on the popular California Instruments platform. The software operates in SIMULATION MODE and can be downloaded at:

http://www.elgar.com/products/Ls-Lx/Ls-Lx_Series_Downloads.htm

Prequency 16 0utput Mode: G AC C DC C AC+DC Phase Control Ampl(VD 50 50 50 50 50 50 50 50 50 50 50 50 50	\$000 \$000	Output Relay:	
Prese (*)	C SNEWAVE		

Figure 5: GUI in Simulation Mode

Calibration

The CSW can be calibrated for all functions by using the front panel or GUI. Those functions are the Voltage, Current, Phase Angle and all External Signal inputs. Only the Voltage and Current measurements must be calibrated for both the programmed and measured values.



Figure 6: GUI Calibration



Figure 7: Calibration Setup



Unique SW and CSW Features

External Modulation

Like the SW the CSW includes an External Modulation function. A 0 to 5Vrms provides 0 to \geq 20% modulation to each of the three output phases (±2% of full scale output).

An added benefit of the CSW is the ability to separate inputs from the other External Inputs. This allows the modulation function to be performed for any programmed function, Internal or External.

👿 Modulati	Modulation Control			
File Help				
<u>S</u> tart	Voltage Frequency	1		
<u>A</u> bort	Voltage Modulation: V Average: 230 Vrms	Phase:		
	Mod Depth: 0.3 ± Vrms			
Output OFF	Rep Rate: 10.00 Hz			
	Run time: 1 Secs.			
Ready				

Figure 8: Modulation Entry via GUI



Figure 9: Modulated Waveform

External Sync Input

Elgar SW	California Instruments CSW
A TTL input to frequency synchronize the outputs. The Phase A output can be programmed relative to the external input. For this function the SW uses a Phase Locked Loop. This requires that the frequency to which the power source is to be synched must first be programmed ±10%. When the Synch is then enabled the frequency will be tracked. There is phase jitter between the external input and the output voltages.	The tracked frequency does not have to be programmed. When this function is enabled the output frequency will be tracked and the Phase A output will be phase locked to the TTL input. Unlike the SW the output phase angle of Phase A output can be programmed relative to the edge of the external TTL input. There is no jitter between the outputs and the external TTL input. (demonstration)



External Direct Input

Elgar SW	California Instruments CSW
Normal Amplifier, 0 to 5 VRMS (DC to 5kHz) or ±5 VDC input for zero to full scale programmed voltage output (±2% of full scale output). All outputs must be programmed to the same External Direct Input function.	Significant benefit of the CSW allows any number of output phases programmed to the External Direct Input. For example Phase A and B could be programmed for the Internal signal generator while phase C could be programmed for the External Direct Input. The CSW also sets the output voltage from 0 to a full-scale output instead of 0 to the programmed value like the SW

External Gain Control

Elgar SW	California Instruments CSW
0 to \pm 7.07 VDC provides zero to full scale programmed voltage output (\pm 2% of full scale output). The input pins are the same as those used for the other external input functions. This function is not independent. In other words all phases must be programmed to the External Gain Control function.	Significant benefit of the CSW allows any number of output phases programmed to the External Gain Control. For example Phase A and B could be programmed for the Internal signal generator while phase C could be programmed for the External Gain Control input.



Multi-Chassis Configurations

Elgar SW	California Instruments CSW
For systems with more than one power source all SW systems required an external Power Distribution Unit. The external PDU has some electronics for combining the current measurement signals. In addition there were modifications required to the SW Analog board for both the Master and Auxiliary power sources. Up to 4 power sources can be connected in the system.	For systems the only requirement is to use a System Interface cable . One cable is required for each Auxiliary power source. Up to 6 power sources may be connected in the system. There are no changes required for either the Master or Auxiliary power sources. Multi-Chassis system can be separated into individual stand alone sources by simply removing the interface cable. No internal jumpers or firmware reconfiguration is required! The CSW features auto detect and will automatically configure for Master / Auxiliary



Figure 10: Elgar SW with PDU



Figure 3-4: Output Power Connections for 1 Source and Multi-source Systems

Figure 11: California Instruments CSW



Clock and Lock

Elgar SW	California Instruments CSW
Programmed to the CLOCK mode; configures BNC to output pulses at programmed frequency for loads 2 kW. Vout 1V Low State; Vout 2.4V High State. Negative edge is at 0° ±30ms. LOCK configures BNC to input 'TTL' frequency; signal needs to supply pull down current of 15 mA with voltage drop of 0.6V; no pull up needed. Negative edge is at 0° ±30 ms. This is used for the PLL input and a similar function as the California Instruments External Synch function. See above for more complete comparison	There will be the California Instrument version of the Clock/ Lock function. What was called the CLOCK will be available as an output from the LOCK BNC connector when the Clock/ Lock option is ordered. What the SW called the LOCK function will be the same as the CSW External Synch feature as described above for the PLL Specification. The CSW CLOCK/LOCK will be available as an option .

Sync Output

Elgar SW	California Instruments CSW
An input to trigger a function. For loads ≥2kΩ: Vout ≤1V Low State; Vout ≥2.4V High State; Negative edge is at 0° ±30µsec	Sync Out BNC connector: Rear panel BNC connector the same function as the front panel Trigger BNC connector. An input to trigger a function. A TTL input to frequency synchronize the outputs. The Phase A output can be programmed relative to the external input